MP Series Cone Crusher Spare Parts Number			
No	**Part Number**	**Description**	**Model**
1	1050218746	Jack shaft Assembly	MP800
2	1094200284	Main Frame assembly	MP800
3	1094200001	Clearing Jack assembly	MP800
4	1048517583	Frame seat Liner	MP800
5	1064668568	Fulkrum Bar	MP800
6	1057610203	Thrust Bearing -Lower	MP800
7	1004590351	Bractivator	MP800
8	1063916919	Frame Ring	MP800
9	1048519601	Main Frame liner	MP800
10	1038060005	Arm Guard	MP800
11	1033786661	Main Frame	MP800
12	1094200001	Clearing jack assy	MP800
13	1065634326	Piston Rod	MP800
14	1037711892	Cylinder Head	MP800
15	1028563351	Cylinder	MP800
16	1054914500	Piston	MP800
17	1007255487	Piston seal	MP800
18	1094200201	Adjustment Ring	MP800
19	61879702	Clamp Ring	MP800
20	94300295	Clamping Cylinder Assembly	MP800
21	13107801	Cylinder Bracket	MP800
22	3396950	Spring Tension Pin	MP800
23	4425 2024	Hose Assembly	MP800
24	4425 2026	Hose Assembly	MP800
25	4425 2033	Hose Assembly	MP800
26	6361 8047	Dust Shell	MP800
27	1998 8240	Release Cylinder Boss	MP800
28	6187 0052	Adjustment Ring	MP800
29	1021 0050	Mounting Adapter	MP800
30	9420 0192	Roller Assembly	MP800
31	0207 7140	Adapter	MP800
32	0207 6150	Adapter	MP800
33	2145 8708	Roller Support	MP800
34	2856 5586	Cylinder Weldment	MP800
35	5491 4410	Piston	MP800
36	6319 2551	Wear Ring	MP800

WWW.ONACASTING.COM

37	0725 6406	Piston Seal	MP800
38	0540 4108	Retaining Ring	MP800
39	6874 0091	Roller Shaft	MP800
40	6621 1762	Roller	MP800
41	7304 4968	Bushing	MP800
42	5710 7702	Thrust Plate	MP800
43	1094200185	Tramp Release Cylinder Assy	MP800
44	1094205045	Tramp Release Cylinder Sub-Assy	MP800
45	1094205052	Accumulator Assy	MP800
46	1021343532	Mounting Strip	MP800
47	10 38041396	Bumper	MP800
48	1067920029	Rod Seal	MP800
49	1094205045	Tramp Release Cyl Assy	MP800
50	1028564004	Cylinder	MP800
51	1042622051	Cylinder Head	MP800
52	1054915580	Piston	MP800
53	1065634371	Piston Rod	MP800
54	1063583434	Wiper Ring	MP800
55	1007256405	Rod Seal	MP800
56	1063192525	Rod Wear Ring	MP800
57	1063192950	Piston Wear Ring	MP800
58	1079145204	Accumulator	MP800
59	1094200256	Countershaft Box Assy	MP800
60	1094205003	Countershaft Sub-Assembly	MP800
61	1036802120	Pinion	MP800
62	1068636576	Countershaft	MP800
63	1027476797	Cover	MP800
64	1063085321	Piston Ring	MP800
65	1063193002	Wear Ring	MP800
66	1038069630	Box guard	MP800
67	1063587664	Oil Flinger	MP800
68	1045376436	Countershaft Box	MP800
69	1038000901	Shield	MP800
70	1094200285	Oil Piping Assembly	MP800
71	5454 1507	Pipe Assembly	MP800
72	5454 1505	Pipe Rssembly	MP800
73	5454 1506	Pipe Assembly	MP800
74	5460 0009	Pipe Assembly	MP800

WWW.ONACASTING.COM

75	4425 3950	Hose Assembly	MP800
76	3805 2040	Guard	MP800
77	1094200219	Eccentric Assembly	MP800
78	94200219	Eccentric Assembly	MP800
79	94205047	Eccentric Sub-Assy	MP800
80	1031140006	Eccentric	MP800
81	1022075485	Eccentric Bushing	MP800
82	1057610201	Thrust Bearing	MP800
83	1036802121	Gear	MP800
84	1094205048	Counterweight Sub-Assy	MP800
85	1086428472	Counterweight	MP800
86	1038018176	Counterweight Guard	MP800
87	1063510103	U-Seal	MP800
88	1063510101	T-Seal	MP800
89	1094200120	Socket Assembly	MP800
90	1094205036	Socket Sub-Assy	MP800
91	1048724031	Socket Liner	MP800
92	1027152291	Socket	MP800
93	1094200221	Head Assembly	MP800
94	1063510102	T-Seal	MP800
95	1022147761	Head Bushing	MP800
96	1022147770	Head Busing	MP800
97	1057605146	Head Ball	MP800
98	1042472700	Head	MP800
99	1027465105	Locking Bar Cover Plate	MP800
100	1094200105	Feed Plate Assembly	MP800
101	5598 8665	Feed Plate	MP800
102	6273 1725	Locking Nut	MP800
103	1094200082	Liner Assembly	MP800
104	4831 5232	Bowl Liner	MP800
105	1048315258	Bowl Liner	MP800
106	1050143957	Mantle	MP800
107	86342225	Wedge	MP800
108	56839335	Lock Plate	MP800
109	14622650	Retainer Bar	MP800
110	1094200146	Bowl Assembly	MP800
111	2005755	Bowl	MP800
112	22819351	Adjustment Cap	MP800

WWW.ONACASTING.COM

113	18780315	Wedge Retainer	MP800
114	1094200148	Hopper Assembly	MP800
115	44180391	Hopper	MP800
116	26187502	Feed Cone	MP800
117	1094200220	Tools Assembly	MP800
118	67271621	Jackscrew-Socket Liner	MP800
119	67272626	Jackscrew-Socket Shaft Box	MP800
120	94200290	Accessories Assembly	MP800
121	1094200267	Crusher Sheave Assembly	MP800
122	1059238506	Crusher Sheave	MP800
123	1094200289	Motor Sheave Assy	MP800
124	1094200283	Air Cooler Assembly	MP800
125	2674 0279	Air Cooler	MP800
126	1094200282	Air Cooler 鹅ping Assy	MP800
127	79160001	Oil Tank	MP800
128	1050218746	Jackshaft Assy	MP800
129	1094200284	Main Frame Assembly	MP800
130	1094200001	Clearing Jack Assembly	MP800
131	1048517583	Frame Seat Liner	MP800
132	1057610203	Thrust Bearing- Lower	MP800
133	1054440227	Main Frame Pin	MP800
134	1063510100	Seal Ring Segment	MP800
135	1063916919	Frame Ring	MP800
136	1048519601	Main Frame Liner	MP800
137	1038060005	Arm Guard	MP800
138	1033786661	Main Frame	MP800
139	1019988240	Release Cylinder Boss	MP800
140	1094200001	Clearing Jack assy	MP800
141	1065634326	Piston Rod	MP800
142	1037711892	Cylinder Head	MP800
143	1028563351	Cylinder	MP800
144	1054914500	Piston	MP800
145	1007255487	Piston Seal	MP800
146	1094200201	Adjustment Ring Assy	MP800
147	6187 9702	Clamp Ring	MP800
148	9430 0295	Clamping Cylinder Assembly	MP800
149	1310 7801	Cylinder Bracket	MP800
150	0339 6950	Spring Tension Pin	MP800

WWW.ONACASTING.COM

151	4425 2024	Hose Assembly	MP800
152	4425 2026	Hose Assembly	MP800
153	4425 2033	Hose Assembly	MP800
154	6351 8905	Adjustment Cap Seal	MP800
155	6361 8047	Dust Shell	MP800
156	1094300295	Clamping Cylinder	MP800
157	1094200202	Vibration Meter Assy	MP800
158	1094200239	Bowl Adjustment Assy	MP800
159	2715 2290	Mounting Plate	MP800
160	2145 6548	Gear Bracket	MP800
161	1094200033	Hydraulic Drive Assy	MP800
162	1094305033	Pump	MP800
163	MM0352663	Main Frame Assembly	MP1000
164	MM0236529	Main Frame Assy.Instructions	MP1000
165	MM0301297	Main Frame Sub-Assembly	MP1000
166	MM0236528	Main Frame Sub-Assembly Instructions	MP1000
167	1094300074	Clearing Jack Assembly	MP1000
168	MM0313986	Adjustment Ring Assembly	MP1000
169	MM0236590	Adjustment Ring Sub-Assy	MP1000
170	1094300295	Clamping Cylinder Assembly	MP1000
171	MM0310179	Tramp Release Cylinder Assembly	MP1000
172	1094300592	Tramp Release Cylinder Sub-Assembly	MP1000
173	MM0310178	Accumulator Assembly	MP1000
174	MM0345191	Countershaft Box Assembly	MP1000
175	MM0260591	Crusher Oil Piping Assembly	MP1000
176	MM0359051	Eccentric Assembly	MP1000
177	MM0354111	Eccentric Sub-Assembly	MP1000
178	MM0351619	Counter Weight Sub-Assembly	MP1000
179	1094300683	Socket Assembly	MP1000
180	1094305046	Socket Sub-Assembly	MP1000
181	MM0391730	Head Assembly	MP1000
182	1094300597	Feed Plate Assembly	MP1000
183	MM0416137	Liner Assembly	MP1000
184	MM0264431	Bowl Assembly	MP1000
185	1094300109	Hopper Assembly	MP1000
186	MM0350015	Tools Assembly	MP1000
187	1094290423	Charging Assembly	MP1000
188	MM0408348	Accessories Assembly With Tags	MP1000

WWW.ONACASTING.COM

189	MM0408342	Accessories Assembly	MP1000
190	MM0406109	Countershaft Temperature Sensor	MP1000
191	MM0406108	Eccentric Temperature Sensor Assembly	MP1000
192	MM銃€412872	Cavity Level Sensor Assembly	MP1000
193	MM0371459	Speed Monitor Assembly	MP1000
194	MM0360915	Vibration Sensor Assembly	MP1000
195	MM0409849	Air Flow Meter Assembly	MP1000
196	MM0411491	Proximity Switch Enclosure Assembly	MP1000
197	MM0236587	Frame I.D.Plate Assembly	MP1000
198	MM0237262	Adjustment Ring I.D.Plate Assembly	MP1000
199	MM0330319	I.D.Plate Assembly	MP1000
200	MM408350	Water Cooler Assembly With Tags	MP1000
201	MM0408343	Water Cooler Assembly	MP1000
202	MM0411490	Water Cooler Junction Box Assembly	MP1000
203	MM0408274	Temperature Sensor Assembly	MP1000
204	MM0408352	Lube System Assembly With Tags	MP1000
205	MM0408355	Lube System Assembly (P/L)	MP1000
206	MC001560	Lube System Assembly(G/A)	MP1000
207	MM0378133	Lube Pump Plate Assembly	MP1000
208	MM0408274	Drain Temperature Sensor Assembly	MP1000
209	MM0408272	Lube Temperature Sensor Assembly	MP1000
210	MM0242682	Differential Pressure Transmitter	MP1000
211	MM0411489	Electrical Enclosure Assembly	MP1000
212	MM0200067	Spinner Plate Assembly	MP1000
213	MM0244559	Hydraulic Circuit Assembly	MP1000
214	MM0372963	Crusher Sensor Electrical Enclosure	MP1000
215	MM0343466	Hydraulic Drive Adjustment Assembly	MP1000
216	1094300480	Hydraulic Drive Assembly	MP1000
217	MM0408354	Hyd.Power Unit Assembly With Tags	MP1000
218	MM0408356	Hyd.Power Unit Assembly (P/L)	MP1000
219	MM0246451	Valve Module Assembly (Main)	MP1000
220	MM0246447	Manifold Assembly(Pump)	MP1000
221	MM0408288	Pressure Transmitter Manifold	MP1000
222	MM0411488	Local Control Enclosure Assembly	MP1000
223	MM0295819	Maintenance Control Station Assembly	MP1000
224	MM0408274	Temperature Transmitter Sensor	MP1000
225	MM0411487	Power Unit Electrical Enclosure	MP1000
226	MM0331103	Accumulator Assembly	MP1000

WWW.ONACAST.INC.COM

227	MM0233526	Air Cleaner Assembly	MP1000
228	MM0409302	Torque Limiter	MP1000
229	1094300574	Hydraulic Motor Circuit Assembly	MP1000
230	MM0408365	Blower And Air Cleaner Assembly	MP1000
231	MM0352663	Main Frame Assembly	MP1000
232	MM0301297	Main Frame Sub-Assy	MP1000
233	1057605260	Thrust Bearing	MP1000
234	1070589865	Shim	MP1000
235	1070589868	Shim	MP1000
236	1070589873	Shim	MP1000
237	1070589876	Shim	MP1000
238	1003724578	Screw	MP1000
239	1048519630	Main Frame Liner	MP1000
240	1025130036	Liner Clamp	MP1000
241	1003725064	Screw	MP1000
242	MM0351616	Guard Pin	MP1000
243	1003723134	Screw	MP1000
244	1003010051	Hex Nut	MP1000
245	MM0351617	Stationary Shield	MP1000
246	1038069780	Arm Guard	MP1000
247	1094300074	Clearing Jack	MP1000
248	MM0301297	Main Frame Sub-Assy	MP1000
249	MM0301295	Mainframe	MP1000
250	1054440240	Main Frame Pin	MP1000
251	1057108300	Pin Retainer	MP1000
252	1003725106	Screw	MP1000
253	1064669612	Fulcrum Bar	MP1000
254	1019988118	Guard Block	MP1000
255	1063519430	Seal Ring Segment	MP1000
256	1004590348	Adhesive Kit	MP1000
257	1024709103	Hose Clamp	MP1000
258	1063916922	Frame Ring	MP1000
259	1019988010	Hanger Block	MP1000
260	1016395500	Bearing Cup	MP1000
261	MM0325218	Seat Liner Segment Set	MP1000
262	1019988240	Release Cylinder Boss	MP1000
263	1012982101	Guard(Oil Sump Drain Plug)	MP1000
264	1010286488	Coupling	MP1000

WWW.ONACASTING.COM

265	1001558853	Pipe Plug	MP1000
266	1002098744	Plug	MP1000
267	1001863032	Flange	MP1000
268	1094300074	Clearing Jack	MP1000
269	1028563351	Cylinder Sub-Assy	MP1000
270	1065634325	Piston Rod	MP1000
271	1054914500	Piston	MP1000
272	1007255487	Piston Seal	MP1000
273	1037711892	Cylinder Head	MP1000
274	MM0313986	Adjustment Ring Assy	MP1000
275	MM0236590	Adjustment Ring Sub-Assy	MP1000
276	1061879701	Clamp Ring	MP1000
277	1094300295	Clamping Cylinder	MP1000
278	1002076640	Straight Long Adapter	MP1000
279	1027458890	Pin Cover	MP1000
280	1044252820	Hose Assy	MP1000
281	1001983540	Elbow	MP1000
282	1044252046	Hose Assy	MP1000
283	1044252054	Hose Assy	MP1000
284	1001955140	Elbow Swivel	MP1000
285	1001986340	Tee	MP1000
286	1003727253	Screw	MP1000
287	1013107801	Cylinder Bracket	MP1000
288	1027279851	Cover	MP1000
289	1072993062	Spacer	MP1000
290	1003723064	Screw	MP1000
291	1003010051	Hex Nut	MP1000
292	1003722578	Screw	MP1000
293	1004826371	Thread Sealant	MP1000
294	1003386968	Dowel	MP1000
295	1073044966	Spacer	MP1000
296	1094300295	Clamping Cylinder Assembly	MP1000
297	1028565586	Cylinder Weldment	MP1000
298	1054914410	Piston	MP1000
299	1063192551	Wear Ring	MP1000
300	1007256406	Piston Seal	MP1000
301	1063902234	Modular Back-Up Ring	MP1000
302	1005404108	Retaining Ring	MP1000

WWW.ONACASTING.COM

303	MM0310179	Tramp Release Cylinder	MP1000
304	1094300592	Tramp Release Cylinder Assy	MP1000
305	MM0310178	Accumulator Assy	MP1000
306	1021456425	Mounting Bracket	MP1000
307	1024561920	Mounting Strap	MP1000
308	1003724078	Screw	MP1000
309	1016373001	Cone	MP1000
310	1016373003	Cone	MP1000
311	1003010111	Hex Nut	MP1000
312	1029300222	Accumulator	MP1000
313	1003724634	Screw	MP1000
314	1004826354	Loctite	MP1000
315	MM0310178	Accumulator Assy	MP1000
316	MM0310177	Accumulator	MP1000
317	MM0300393	O Ring	MP1000
318	MM0300395	Bladder	MP1000
319	MM0300397	Valve Adaptor	MP1000
320	MM0300398	Valve Cap	MP1000
321	MM0300399	Valve Core	MP1000
322	1051470452	Jam Nut	MP1000
323	MM0300401	Protective Cap	MP1000
324	MM0300404	O Ring	MP1000
325	MM0300405	Spacer	MP1000
326	MM0300407	Gasend Adaptor	MP1000
327	MM0300408	Anti-Extrusion Ring	MP1000
328	MM0300415	O Ring	MP1000
329	MM0300416	O Ring	MP1000
330	MM0300418	Flange	MP1000
331	MM0300428	O Ring	MP1000
332	MM0300429	O Ring	MP1000
333	MM0300430	Metalbackup Ring	MP1000
334	MM0300432	Bleeder Plug	MP1000
335	MM0300444	Locknut	MP1000
336	MM0300446	Spacer	MP1000
337	MM0300447	Hf Anti Extrusion Ring	MP1000
338	MM0300448	O Ring Fluid Port	MP1000
339	MM0300449	Back-Up Ring Port	MP1000
340	1001558643	Pipe Plug	MP1000

WWW.ONACASTING.COM

341	1005102616	Nipple	MP1000
342	NO5241022	Cord Grip	MP1000
343	1005105534	Pull Elbow	MP1000
344	1054541796	Flange Assembly	MP1000
345	1004501053	Gasket	MP1000
346	MM0354111	Eccentric Sub-Assy	MP1000
347	MM0359048	Eccentric Sleeved Assembly	MP1000
348	1022075736	Eccentric Bushing	MP1000
349	1057605258	Hrust Bearing	MP1000
350	1003724578	Screw	MP1000
351	MM0297789	Gear	MP1000
352	1003726183	Screw	MP1000
353	1003344237	Dowel	MP1000
354	1095059960	Backing Compound	MP1000
355	1003343183	Dowel	MP1000
356	MM0351619	Counterweight Sub-Assy	MP1000
357	MM0350690	Counterweight	MP1000
358	MM0351618	Counterweight Guard	MP1000
359	1063519090	Seal Ring Segment -Upper	MP1000
360	1063519460	Seal Ring Segment -Lower	MP1000
361	1003725092	Screw	MP1000
362	1004826400	Silastic	MP1000
363	1004828555	Foam	MP1000
364	1094300683	Socket Assembly	MP1000
365	1048727628	Socket Liner	MP1000
366	10194305046	Socket Sub-Assy	MP1000
367	103736155	Screw	MP1000
368	10194305046	Socket Sub-Assembly	MP1000
369	1073818176	Socket	MP1000
370	1003345503	Dowel	MP1000
371	MM0391730	Head Assembly	MP1000
372	MM0391712	Head Sub-Assembly	MP1000
373	1057605280	Head Ball	MP1000
374	MM0344927	Head Bushing-Upper	MP1000
375	1022148833	Head Bushing-Lower	MP1000
376	1004826405	Silastic	MP1000
377	1063519130	Seal Ring	MP1000
378	1004590348	Adhesive	MP1000

WWW.ONACASTING.COM

379	MM0202913	Spacer	MP1000
380	1003345548	Dowel	MP1000
381	1001558848	Pipe Plug	MP1000
382	MM03764	Bushing Key	MP1000
383	1019142305	Screw	MP1000
384	1003724711	Screw	MP1000
385	7001532415	Screw	MP1000
386	MM0360539	Locking Wire	MP1000
387	1004826353	Loctite	MP1000
388	1003344519	Dowel Pin	MP1000
389	1094300597	Feed Plate Assy	MP1000
390	1055989405	Feed Plate	MP1000
391	1062731759	Locking Nut	MP1000
392	103725162	Screw	MP1000
393	103010071	Hex Nut	MP1000
394	MM0416137	Liner Assembly	MP1000
395	1095059940	Backing	MP1000
396	1051490910	Spherical Nut	MP1000
397	1004590540	Insulation	MP1000
398	1056839408	Plate	MP1000
399	1086345380	Wedge	MP1000
400	1048315551	Bowlliner	MP1000
401	1050144053	Mantle	MP1000
402	1063915735	Torch Ring	MP1000
403	1003075440	Cotter	MP1000
404	1070521000	Shim	MP1000
405	MM0264431	Bowl Assembly	MP1000
406	1022819301	Adjustment Cap	MP1000
407	MM0264427	Bowl	MP1000
408	1003726120	Screw	MP1000
409	1018780310	Wedg Retainer	MP1000
410	MM0264424	Bowl Ring	MP1000
411	1057951852	Plug	MP1000
412	1003724683	Screw	MP1000
413	1003724592	Screw	MP1000
414	1003345518	Pin	MP1000
415	1003725211	Screw	MP1000
416	1094300109	Hopper Assembly	MP1000

WWW.ONACASTING.COM

417	1044180221	Hopper	MP1000
418	1094290423	Charging &Gauging Assy	MP1000
419	1004095128	Dust Cap	MP1000
420	1007016455	Gauge	MP1000
421	1094290424	Hose Assembly	MP1000
422	1004095126	Tank Valve	MP1000
423	4095127	Bleeder Valve	MP1000
424	4095129	Thread Adapter	MP1000
425	MM0408354	Hydraulic Power Unit Assy	MP1000
426	MM0408356	Hydraulic Puwer Unit	MP1000
427	1072984001	Wire Sleeve	MP1000
428	10P1326931	Encljsure Tag Location Assembly	MP1000
429	1003130566	Drive Screws	MP1000
430	10P1326932	Equipmeniiag Lucatiun Assembly	MP1000
431	10P1326898	Plc Program	MP1000
432	MM0331103	Accumulator Assembly	MP1000
433	MM0310180	Accumulator	MP1000
434	MM0331403	Bladder	MP1000
435	1051470452	Jam Nut	MP1000
436	MM0300401	Protective Nut	MP1000
437	MM0300398	Valve	MP1000
438	MM0300399	Valve	MP1000
439	MM0331404	O Ring	MP1000
440	MM0331405	Metalback-Up	MP1000
441	MM0331407	Poppet	MP1000
442	MM0331408	Piston	MP1000
443	MM0331409	Stop Nut	MP1000
444	MM0331410	Spring	MP1000
445	MM0300432	Bleeder Plug	MP1000
446	MM0331411	Dust Cap	MP1000
447	MM0331412	Lock	MP1000
448	MM0331413	Spacer	MP1000
449	MM0300397	Valve Adaptor	MP1000
450	MM0331415	Anti-Extrusion Ring	MP1000
451	MM0300404	Adaptor Oring	MP1000
452	MM0347687	Main Frame Assembly	MP1250
453	MM0347686	Main Frame Assy.Instructions	MP1250
454	MM0346164	Main Frame Sub-Assembly	MP1250

WWW.ONACASTING.COM

455	MM0346165	Main Frame Sub-Assembly Instructions	MP1250
456	1094300074	Clearing Jack Assembly	MP1250
457	MM0332086	Adjustment Ring Assembly	MP1250
458	MM0332096	Adjustment Ring Sub-Assy	MP1250
459	1094300295	Clamping Cylinder Assembly	MP1250
460	MM0336776	Tramp Release Cylinder Assembly	MP1250
461	MM0311407	Tramp Release Cylinder Sub-Assembly	MP1250
462	MM0345191	Countershaft Box Assembly	MP1250
463	MM0260591	Crusher Oil Piping Assembly	MP1250
464	MM0317614	Eccentric Assembly	MP1250
465	MM0317615	Eccentric Sub-Assembly	MP1250
466	MM0325643	Counter Weight Sub-Assembly	MP1250
467	MM0310089	Socket Assembly	MP1250
468	MM0310086	Socket Sub-Assembly	MP1250
469	MM0367404	Head Assembly	MP1250
470	10P1208301	Feed Plate Assembly	MP1250
471	MM0355803	Liner Assembly	MP1250
472	MM0264431	Bowl Assembly	MP1250
473	1094300109	Hopper Assembly	MP1250
474	MM0346247	Tools Assembly	MP1250
475	1094290423	Charging Assembly	MP1250
476	MM0356416	Accessories Assembly With Tags	MP1250
477	MM0356436	Accessories Assembly	MP1250
478	MM0372026	Vibration Sensor Assembly	MP1250
479	MM0371459	Speed Monitor Assembly	MP1250
480	MM0371621	Prox.Switch Enclosure Assembly	MP1250
481	MM0356263	Frame I.D.Plate Assembly	MP1250
482	MM0349809	Adjustment Ring I.D.Plate Assembly	MP1250
483	MM0331007	Ld.Plate Assembly	MP1250
484	MM0301036	Crusher Sheave Assembly	MP1250
485	MM0371293	Motor Sheave Assembly	MP1250
486	MM0301072	Drive V-Belts	MP1250
487	MM0356421	Air Cooler Assembly With Tags	MP1250
488	MM0356402	Air Cooler Assembly	MP1250
489	MM0376694	Air Cooler Master Assembly	MP1250
490	MM0376695	Air Cooler Slave Assembly	MP1250
491	MM0372571	Air Cooler Electrical Assembly	MP1250
492	MM0356425	Pkg.Lube System Assembly With Tags	MP1250

WWW.ONACASTING.COM

493	MM0356414	Pkg.Lube System Assembly(P/L)	MP1250
494	MC001397	Pkg.Lube System Assembly (G/A)	MP1250
495	MM0356410	Lube Pump Plate Assembly	MP1250
496	MM0371620	Electrical Enclosure Assembly	MP1250
497	MM0356413	Spinner Plate Assembly	MP1250
498	MM0335984	Hydraulic Circuit Assembly	MP1250
499	MM0341844	Crusher Sensor Junction Box Assembly	MP1250
500	MM0356438	Hydraulic Drive Adjustment Assembly	MP1250
501	MM0324257	Hydraulic Drive Assembly	MP1250
502	MM0356430	Hyd.Power Unit Assembly With Tags	MP1250
503	MM0356249	Hyd.Power Unit Assembly	MP1250
504	MC001394	Hyd.Power Unit Assembly	MP1250
505	MM0364141	Valve Module Assembly	MP1250
506	MM0364146	Manifold Assembly	MP1250
507	MM0357919	Pressure Transmitter Manifold	MP1250
508	MM0356258	Local Control Enclosure Assembly	MP1250
509	MM0272837	Maintenance Control Station Assembly	MP1250
510	MM0371619	Power Unit Electrical Enclosure	MP1250
511	MM0332165	Accumulator Assembly	MP1250
512	MM0233526	Air Cleaner Assembly	MP1250
513	1094300611	Sole Plate Assembly	MP1250
514	MM0374656	Seismic Stop Assembly	MP1250
515	MM0356803	Blower And Air Cleaner Assembly	MP1250
516	MM0356802	Blower Assembly	MP1250
517	1093100870	Automation Assembly	MP1250
518	1093100871	Plc Assembly	MP1250
519	MM0358846	Motor/Jackshaft Assembly	MP1250
520	MM0347687	Main Frame Assembly	MP1250
521	MM0346164	Main Frame Sub Assembly	MP1250
522	1057605260	Thrust Bearing	MP1250
523	1070589865	Shim	MP1250
524	1070589868	Shim	MP1250
525	1070589873	Shim	MP1250
526	1070589876	Shim	MP1250
527	1003724578	Screw	MP1250
528	1048519630	Main Frame Liner	MP1250
529	1025130036	Hose Clamp	MP1250
530	1003725064	Screw	MP1250

WWW.ONACASTING.COM

531	1054267550	Guard Pin	MP1250
532	1003723134	Screw	MP1250
533	1003010051	Hex Nut	MP1250
534	1038018950	Stationary Shield	MP1250
535	1038069780	Arm Guard	MP1250
536	1094300074	Clearing Jack	MP1250
537	MM0346164	Main Frame Sub-Assy	MP1250
538	MM0301295	Main Frame	MP1250
539	1054440240	Main Frame Pin	MP1250
540	1057108300	Pin Retainer	MP1250
541	1003725106	Screw	MP1250
542	1064669612	Fulcrum Bar	MP1250
543	1019988118	Guard Block	MP1250
544	1063519430	Seal Ring Segment	MP1250
545	1004590348	Adhesive Kit	MP1250
546	MM0335985	Hose Clamp	MP1250
547	1063916922	Frame Ring	MP1250
548	1019988010	Hanger Block	MP1250
549	1016395500	Bearing Cup	MP1250
550	MM0325218	Seat Liner Segment Set	MP1250
551	1019988240	Release Cylinder Boss	MP1250
552	1012982101	Guard(Oil Sump Drain Plug)	MP1250
553	1010286488	Coupling	MP1250
554	1001558853	Pipe Plug	MP1250
555	1002098744	Plug	MP1250
556	1001863032	Flange	MP1250
557	MM0316217	Mounting Bracket	MP1250
558	1094300074	Clearing Jack	MP1250
559	1028563351	Cylinder Sub-Assy	MP1250
560	1065634325	Piston Rod	MP1250
561	1054914500	Piston	MP1250
562	1007255487	Piston Seal	MP1250
563	1037711892	Cylinder Head	MP1250
564	MM0332086	Adjustment Ring Assy	MP1250
565	MM0332096	Adjustment Ring Sub-Assy	MP1250
566	1061879701	Clamp Ring	MP1250
567	1094300295	Clamping Cylinder	MP1250
568	1002076640	Straight Long Adapter	MP1250

WWW.ONACASTING.COM

569	MM0332101	Pin Cover	MP1250
570	1044252820	Hose Assy	MP1250
571	1001983540	Elbow	MP1250
572	1044252046	HoseAssy	MP1250
573	1044252054	Hose Assy	MP1250
574	1001955140	Elbow	MP1250
575	1001986340	Tee	MP1250
576	1003727253	Screw	MP1250
577	1013107801	Cylinder Bracket	MP1250
578	1027279851	Cover	MP1250
579	1072993062	Spacer	MP1250
580	1003723064	Screw	MP1250
581	1003010051	Hex Nut	MP1250
582	1003722578	Screw	MP1250
583	1004826371	Thread Sealant	MP1250
584	1003386968	Dowel	MP1250
585	1073044966	Spacer	MP1250
586	1094300295	Clamping Cylinder Assembly	MP1250
587	1028565586	Cylinder Weldment	MP1250
588	1054914410	Piston	MP1250
589	1063192551	Wear Ring	MP1250
590	1007256406	Piston Seal	MP1250
591	1063902234	Modular Back-Up Ring|	MP1250
592	1005404108	Retaining Ring	MP1250
593	MM0336776	Tramp Rel Ease Assembly	MP1250
594	MM0311407	Tramp Release Cyl Inder Assy	MP1250
595	MM0369348	Relief Valve	MP1250
596	1016373001	Cone	MP1250
597	1016373003	Cone	MP1250
598	1003010111	Hex Nut	MP1250
599	MM0311407	Tramp Release Cylinder Assembl`V	MP1250
600	MM0311409	Cylinder	MP1250
601	1042622051	Cylinder Head	MP1250
602	1054915580	Piston	MP1250
603	1065634376	Piston Rod	MP1250
604	1063583434	Wiper Ring	MP1250
605	1007256405	Rod Seal	MP1250
606	1063915000	Back-Up Ring	MP1250

WWW.ONACASTING.COM

607	1063192525	Rod Wear Ring	MP1250
608	1086109738	Back-Up Ring	MP1250
609	1063902245	Spacer	MP1250
610	1063192950	Piston Wear Ring	MP1250
611	1007259300	Piston Seal	MP1250
612	1063914115	Back-Up Ring	MP1250
613	1086109930	Back-Up Ring	MP1250
614	1003723071	Screw	MP1250
615	MM0311413	Mounting Plate	MP1250
616	1003723050	Screw	MP1250
617	1003724550	Screw	MP1250
618	MM0318373	Hex Head Plug	MP1250
619	1002098746	Hex Head Plug	MP1250
620	MM0341371	Hex Head Plug	MP1250
621	MM0317614	Eccentric Assembly	MP1250
622	MM0317615	Eccentric Sub-Assy	MP1250
623	MM0325643	Counterweight Sub-Assy	MP1250
624	1003726211	Screw	MP1250
625	1004826354	Loctite	MP1250
626	MM0317615	Eccentric Sub-Assy	MP1250
627	MM0316879	Eccentric	MP1250
628	1022075736	Eccentric Bushing	MP1250
629	1057605258	Hrust Bearing	MP1250
630	1003724578	Screw	MP1250
631	MM0297789	Gear-Spiral Bevel	MP1250
632	1003726183	Screw	MP1250
633	1003344237	Dowel	MP1250
634	1095059960	Locking Compound	MP1250
635	1004826354	Loctite	MP1250
636	1003343183	Dowel	MP1250
637	MM0325643	Counterweight Sub-Assy	MP1250
638	MM0298467	Counterweight	MP1250
639	MM0298469	Counterweight Cover Assy	MP1250
640	1063519090	Seal Ring Seg.-Upper	MP1250
641	1063519460	Seal Ring Seg.-Lower	MP1250
642	1004590348	Adhesive Kit	MP1250
643	1003724564	Screw	MP1250
644	MM0365682	Special Screw	MP1250

WWW.ONACASTING.COM

645	MM0310089	Socket Assembly	MP1250
646	MM0310086	Socket Sub-Assy	MP1250
647	MM0309830	Socket Liner	MP1250
648	1003726148	Screw	MP1250
649	MM0310086	Socket Sub-Assembly	MP1250
650	MM0309832	Socket	MP1250
651	1003345503	Dowel	MP1250
652	MM0367404	Head Assembly	MP1250
653	MM0384670	Head	MP1250
654	MM0325330	Head Ball	MP1250
655	MM0288343	Head Bushing-Upper	MP1250
656	1022148833	Head Bushing-Lower	MP1250
657	1004826405	Silastic	MP1250
658	1063519130	Seal Ring	MP1250
659	1004590348	Adhesive	MP1250
660	MM0202913	Spacer	MP1250
661	1003345548	Dowel	MP1250
662	1001558848	Pipe Plug	MP1250
663	MM0382550	Bushing Key	MP1250
664	MM0382673	Screw	MP1250
665	1003724711	Screw	MP1250
666	7001532415	Screw	MP1250
667	MM0360539	Locking Wire	MP1250
668	1004826353	Octite	MP1250
669	1003344519	Dowel Pin	MP1250
670	10P1208301	Feed Plate Assembly	MP1250
671	10P1207901	Feed Plate	MP1250
672	MM0371478	Ocking Nut Sub-Assembly	MP1250
673	1003725169	Screw	MP1250
674	1003010071	Hex Nut	MP1250
675	MM0355803	Liner Assembly	MP1250
676	1095059940	Backing	MP1250
677	1051490910	Spherical Nut	MP1250
678	1070521000	Shim	MP1250
679	1056839408	Lockplate	MP1250
680	1086345380	Wedge	MP1250
681	1048315551	Bowl Liner	MP1250
682	MM0355 638	Mantle	MP1250

WWW.ONACASTING.COM

683	MM0367200	Torch Ring	MP1250
684	1003075440	Cotter Pin	MP1250
685	1004590540	Insulation (Feet)	MP1250
686	MM0264431	Bowlassembly	MP1250
687	1022819301	Adjustment Cap Assy	MP1250
688	MM0264427	Bowl	MP1250
689	103726120	Screw	MP1250
690	1018780310	Wedge Retainer	MP1250
691	MM0264424	Bowl Ring	MP1250
692	1057951852	Plug	MP1250
693	1003724683	Screw	MP1250
694	103724592	Screw	MP1250
695	1003345518	Pin	MP1250
696	1003725211	Screw	MP1250
697	1094300109	Hopper Assembly	MP1250
698	1044180221	Hopper	MP1250
699	1076415670	Seal Strip	MP1250
700	1004590250	Adhesive	MP1250
701	MM0356416	Accessdries Assembly	MP1250
702	MM0356436	Accessdries Assembly	MP1250
703	10P1120120	Instrument Tags	MP1250
704	1087167202	Wire Rope	MP1250
705	1072984001	Wire Sleeve	MP1250
706	10P1120124	Enclusure	MP1250
707	1003130566	Drivescrews	MP1250
708	10P1120160	Equipment Tags Enclosure Assembly	MP1250
709	MM0372026	Vibration Sensor Assy	MP1250
710	MM0215551	Accelerometer	MP1250
711	1005104050	Conduit Seal Ring	MP1250
712	1003722029	Screw	MP1250
713	1035682104	Gasket,Base	MP1250
714	1020299233	Box,Protection	MP1250
715	1035682103	Gasket Cover	MP1250
716	1027240042	Cover	MP1250
717	1003721022	Screw	MP1250
718	1005103808	Cord Grip	MP1250
719	1005104014	Conduit	MP1250
720	MM0371459	Speed Sensor Assembly	MP1250

WWW.ONACASTING.COM

721	MM0346440	Inductive Prdx Switch	MP1250
722	MM0346442	Cable	MP1250
723	MM0301036	Crusher Sheave Assy	MP1250
724	MM0301039	Crusher Sheave Sub-Assy	MP1250
725	MM0301035	Crusher Sheave	MP1250
726	1073057562	Crusher Sheave Bushing	MP1250
727	1002326901	Screw	MP1250
728	1002784114	Screw	MP1250
729	1002775851	Screw	MP1250
730	1047013480	Countershaft Key	MP1250
731	MM0371293	Motor Sheave Assy	MP1250
732	MM0371292	Motor Sheave	MP1250
733	1073056594	Motor Sheave Bushing	MP1250
734	1002326346	Screw	MP1250
735	MM0301072	V-Belt	MP1250
736	MM0356421	Air Cdoler Assembly	MP1250
737	MM0356402	Aircoolerassembly	MP1250
738	10P1120121	Instrumenttags	MP1250
739	1087167202	Wirerope	MP1250
740	1072984001	Wire Sleeve	MP1250
741	10P1120125	Enclosure Tag	MP1250
742	1003130566	Drive Screws	MP1250
743	10P1120161	Equipment Tag Locatidn Assembly	MP1250
744	MM0356402	Air Cddler Piping Assembly	MP1250
745	MM0328624	Oil Tank	MP1250
746	MM0328621	Oil Tank Return Hood Assy	MP1250
747	MM0356410	Lube Pump Plate Assembly	MP1250
748	MM0217156	Pump Motor Adapter	MP1250
749	N03461021	Spider	MP1250
750	MM0200044	Pump	MP1250
751	MM0356413	Spinner Plate Assembly	MP1250
752	MM0356438	Adjmech Assy	MP1250
753	MM0331792	Drive Ring	MP1250
754	MM0343468	Mounting Plate	MP1250
755	MM0324257	Hyd Drive Assy	MP1250
756	1037070801	Pinion	MP1250
757	1010214626	Flange	MP1250
758	1027152289	Cover	MP1250

WWW.ONACASTING.COM

759	1021456546	Support Bracket	MP1250
760	MM0343469	Mounting Plate	MP1250
761	MM0242574	Pad Mounting Bracket	MP1250
762	MM0241319	Wear Plate	MP1250
763	MM0242301	Bushing	MP1250
764	MM0242294	Retaining Plate	MP1250
765	MM0324257	Hydraulic Drive Assembly	MP1250
766	1061030499	Gear Reducer	MP1250
767	MM0342007	Brake	MP1250
768	MM0335185	Hydraulic Motor	MP1250
769	MM0356430	Hydraulic Puwer Unit Assy	MP1250
770	MM0356249	Hydraulic Power Unit -P/L	MP1250
771	10P1120123	Instrument Tags	MP1250
772	1087167202	Wire Rope	MP1250
773	1072984001	Wire Sleeve	MP1250
774	10P1120127	Enclusure Ags	MP1250
775	1003130566	Drivescrews	MP1250
776	MM0332165	Accumulator Assembly	MP1250
777	MM0347113	Accumulator	MP1250
778	MM0331403	Bladder	MP1250
779	1051470452	Jam Nut	MP1250
780	MM0300401	Protective Nut	MP1250
781	MM0300398	Valve Cap	MP1250
782	MM0300399	Valve Core	MP1250
783	MM0331404	O Ring	MP1250
784	MM0331408	Piston	MP1250
785	MM0331409	Stop Nut	MP1250
786	MM0331410	Spring	MP1250
787	MM0300432	Bleeder Plug	MP1250
788	MM0331411	Dust Cap Fluid Port	MP1250
789	MM0331412	Lock Nut Fluid Port	MP1250
790	MM0331413	Spacer	MP1250
791	MM0300397	Valve Adaptor	MP1250
792	MM0331415	Anti-Extrusion Ring	MP1250
793	MM0300404	Adaptor O Ring	MP1250
794	MM0233526	Air Cleaner Assy	MP1250
795	1021880064	Air Cleaner	MP1250
796	1021347700	Bracket Assembly	MP1250

WWW.ONACASTING.COM

797	1094300611	Sole Plate Assy	MP1250
798	1057526220	Sole Plate	MP1250
799	1057526221	Sole Plate	MP1250

WWW . ONACASTING . COM