

Cone Crusher Spare Parts Number			
No	Part Number	Description	Model
1	442.9871-00	Bottom Shell	CH420
2	442.6564-00	Cover	CH420
3	843.1267	Stud Screw	CH420
4	847.0147-00	Washer	CH420
5	845.0030-00	Lock Nut	CH420
6	442.6174-01	Liner-Pinion Shaft Arm	CH420
7	442.6175-01	Liner-Narrow Arm	CH420
8	900.0026-00	Pipe Angle	CH420
9	442.6131-01	Bottom Shell Bushing	CH420
10	853.0464-00	Pin	CH420
11	900.0921-00	Swivel Branch Tee Adapter	CH420
12	900.1412-00	Pipe	CH420
13	900.0276-00	Cover	CH420
14	442.6132-01	Dust Collar	CH420
15	840.0634-00	Screw	CH420
16	853.0464-00	Pin	CH420
17	840.0069-00	Screw	CH420
18	847.0016-00	Washer	CH420
19	442.6143-01	Backing Lip	CH420
20	442.6212-01	Shim	CH420
21	442.6212-02	Shim	CH420
22	442.6212-03	Shim	CH420
23	442.6212-05	Shim	CH420
24	841.0250-00	Screw	CH420
25	442.6216-01	Gasket	CH420
26	442.6146-01	Seal Inner	CH420
27	840.0069-00	Screw	CH420
28	847.0120-00	Washer	CH420
29	840.0718-00	Screw	CH420
30	845.0221-00	Nut	CH420
31	847.0162-00	Washer	CH420
32	899.0229-00	Protective Cap	CH420
33	442.6243-01	Screw	CH420
34	899.0229-00	Protective Cap	CH420
35	442.6183-01	Eccentric	CH420
36	442.9657-01	Eccentric Bushing	CH420

37	442.9658-01	Eccentric Bushing	CH420
38	442.9659-01	Eccentric Bushing	CH420
39	442.6152-01	Hub	CH420
40	442.6145-01	Ring	CH420
41	840.0046-00	Screw	CH420
42	847.0147-00	Washer	CH420
43	442.9607-01	Key	CH420
44	841.0026-00	Screw	CH420
45	841.0518-00	Screw	CH420
46	847.0180-00	Washer	CH420
47	442.6127-00	Gear, Complete	CH420
48	857.0328-00	Key	CH420
49	442.6130-01	Wearing Plate	CH420
50	853.0619-00	Dowel	CH420
51	442.9872-01	Hydroset Cylinder	CH420
52	840.0542-00	Screw	CH420
53	847.0124-00	Washer	CH420
54	442.9873-01	Hydroset Cylinder Bushing	CH420
55	840.0019-00	Screw	CH420
56	847.0012-00	Washer	CH420
57	873.0439-00	O-Ring	CH420
58	442.9655-00	Piston	CH420
59	853.0645-00	Pin	CH420
60	442.6139-01	Piston Wearing Plate	CH420
61	442.6137-01	Step Washer	CH420
62	442.6153-00	Hydroset Packing	CH420
63	442.6179-01	Packing Clamp Plate	CH420
64	841.0267-00	Screw	CH420
65	442.9660-00	Hydroset Cylinder Cover	CH420
66	840.0542-00	Screw	CH420
67	847.0124-00	Washer	CH420
68	900.2302-00	Plug	CH420
69	873.0830-00	O-Ring	CH420
70	873.1274-00	O-Ring	CH420
71	442.8783-01	Plug	CH420
72	873.0111-00	O-Ring	CH420
73	840.0023-00	Screw	CH420
74	847.0012-00	Washer	CH420

75	840.0019-00	Screw	CH420
76	442.6627-00	Pinion Shaft Housing Assembly	CH420
77	442.6134-01	Pinion Shaft Housing	CH420
78	442.6214-02	Gasket	CH420
79	442.6214-01	Gasket	CH420
80	442.6214-03	Gasket	CH420
81	868.0801-00	Bearing	CH420
82	868.0801-00	Bearing	CH420
83	442.6148-01	Spacer	CH420
84	442.6148-01	Spacer	CH420
85	873.0777-00	O-Ring	CH420
86	873.0777-00	O-Ring	CH420
87	873.1012-00	Seal	CH420
88	873.1012-00	Seal	CH420
89	442.6213-01	Gasket	CH420
90	442.6213-01	Gasket	CH420
91	873.0383-00	Sealing Ring Tredo 16	CH420
92	873.0385-00	Tredo No.	CH420
93	442.6127-02	Pinion	CH420
94	442.6144-01	Plate	CH420
95	442.6144-01	Plate	CH420
96	840.0035-00	Screw	CH420
97	847.0144-00	Washer	CH420
98	840.0035-00	Screw	CH420
99	847.0144-00	Washer	CH420
100	900.0717-00	Filter Plug	CH420
101	442.6202-01	Plug	CH420
102	442.6133-01	Pinion Shaft	CH420
103	857.0051-00	Key	CH420
104	442.2018-01	Plug	CH420
105	900.0269-00	Barrel Nipples	CH420
106	900.0275-00	Socket	CH420
107	442.6201-01	Glass Gauge	CH420
108	855.0020-00	Retaining Ring	CH420
109	840.0956-00	Screw	CH420
110	845.0009-00	Nut	CH420
111	442.7591-00	Main Shaft Assembly Excl. Mantle	CH420
112	442.7450-01	Main Shaft	CH420

113	442.6140-01	Main Shaft Sleeve	CH420
114	853.0645-00	Pin Prym	CH420
115	442.6138-01	Main Shaft Step	CH420
116	855.0020-00	Retaining Ring	CH420
117	442.7449-01	Head Centre	CH420
118	442.9698-01	Mantle	CH420
119	442.6197-01	Mantle	CH420
120	442.7000-01	Mantle	CH420
121	442.9761-01	Mantle	CH420
122	442.6194-00	Head Nut With Burning Ring	CH420
123	442.6193-01	Inner Head Nut	CH420
124	442.6217-01	Burning Ring	CH420
125	442.6906-01	Dust Seal Ring	CH420
126	442.6141-01	Retainer	CH420
127	442.6931-01	Retainer	CH420
128	442.6932-01	Scraper	CH420
129	840.0046-00	Screw	CH420
130	840.0048-00	Screw	CH420
131	847.0147-00	Washer	CH420
132	442.9674-00	Topshell Assembly Excl. Concaves	CH420
133	442.9675-00	Filler Ring Assembly	CH420
134	442.9554-00	Top Shell	CH420
135	442.9568-01	Arm Shield	CH420
136	900.0425-00	Compression Fittings	CH420
137	808.0220-00	Steel Pipe	CH420
138	914.0093-00	Lubrication Nipple	CH420
139	442.8362-01	Spider Cap	CH420
140	912.0114-00	Air Filter	CH420
141	900.0169-00	Nipple	CH420
142	900.0002-00	Elbow	CH420
143	873.0831-00	O-Ring	CH420
144	840.0067-00	Screw	CH420
145	847.0120-00	Washer	CH420
146	442.8363-01	Spider Bushing	CH420
147	840.0069-00	Screw	CH420
148	847.0016-00	Washer	CH420
149	442.8364-01	Seal	CH420
150	900.0981-00	Plug	CH420

151	442.9569-01	Concave Ring	CH420
152	442.9587-01	Concave Ring	CH420
153	442.9586-01	Concave Ring	CH420
154	442.9585-01	Concave Ring	CH420
155	442.9584-01	Concave Ring	CH420
156	442.9583-01	Concave Ring	CH420
157	873.1112-00	Sealing Compound 0.75 Liters	CH420
158	442.9596-01	Filler Ring	CH420
159	442.9595-01	Ring	CH420
160	442.9614-01	O-Ring	CH420
161	840.0070-00	Screw	CH420
162	847.0016-00	Washer	CH420
163	840.1093-00	Screw	CH420
164	845.0203-00	Nut Lock	CH420
165	442.9572-00	Sleeve	CH420
166	442.9573-00	Washer	CH420
167	863.0065-00	Disc Spring	CH420
168	442.9570-01	Support Ring	CH420
169	442.9571-00	Dowel Pin	CH420
170	442.6530-00	Hydroset	CH420
171	442.6637-00	Wrench And Tool Set	CH420
172	442.6174-01	Liner-Pinionshaft Arm	CH420
173	442.6175-01	Liner-Narrow Arm	CH420
174	442.8901-00	Wearing Plates Complete Set	CH420
175	442.8902-01	Wearing Plates	CH420
176	442.8903-01	Wearing Plates	CH420
177	442.8904-01	Wearing Plates	CH420
178	442.8905-01	Wearing Plates	CH420
179	442.8906-01	Wearing Plates	CH420
180	442.8901-06	Square Bar	CH420
181	847.0059-00	Washer	CH420
182	840.0047-00	Screw	CH420
183	442.9612-00	Feed Hopper Distributor Complete	CH420
184	442.9574-00	Feed Hopper	CH420
185	840.0049-00	Screw	CH420
186	845.0007-00	Nut	CH420
187	847.0002-00	Washer	CH420
188	847.0147-00	Washer	CH420

189	442.9598-00	Feed Distributer-Rh	CH420
190	442.9598-90	Feed Distributer-Lh	CH420
191	442.9597-01	Holder	CH420
192	840.0045-00	Screw	CH420
193	845.0007-00	Nut	CH420
194	847.0147-00	Washer	CH420
195	442.9613-00	Feed Hopper With Cone Complete	CH420
196	442.9574-00	Feed Hopper	CH420
197	840.0049-00	Screw	CH420
198	845.0007-00	Nut	CH420
199	847.0002-00	Washer	CH420
200	847.0147-00	Washer	CH420
201	442.9575-00	Feed Hopper Cone	CH420
202	442.9606-90	Feed Hopper Cone	CH420
203	442.6635-00	Rubber Compression Mounting For	CH420
204	845.0216-00	Nut	CH420
205	847.0124-00	Washer	CH420
206	442.6643-00	Top Plate	CH420
207	864.0070-00	Rubber Compression Mounting	CH420
208	840.0044-00	Screw	CH420
209	847.0147-00	Washer	CH420
210	442.6644-00	Fixing Plate, Lower	CH420
211	442.6635-90	Rubber Compression Mounting For	CH420
212	864.0070-00	Rubber Compression Mounting	CH420
213	840.0044-00	Screw	CH420
214	847.0147-00	Washer	CH420
215	442.6644-00	Fixing Plate, Lower	CH420
216	840.0047-00	Screw	CH420
217	845.0030-00	Nut	CH420
218	840.0045-00	Screw	CH420
219	847.0147-00	Washer	CH420
220	442.7396-01	Clamp	CH420
221	873.0390-00	Sealing Ring	CH420
222	900.0659-00	Adapter	CH420
223	650.0173-01	Hydraulic Hose	CH420
224	640.0055-00	Hexagon Bolt	CH420
225	847.0060-00	Washer	CH420
226	442.8624-00	Check Valve	CH420

227	442.8397-00	Protection	CH420
228	919.0231-00	Adapter	CH420
229	442.6508-00	Connection Piece	CH420
230	442.6407-01	Seat	CH420
231	442.6403-01	Valve	CH420
232	127.0004-30	Spring	CH420
233	442.6406-01	Body	CH420
234	873.0130-00	O-Ring	CH420
235	442.6405-01	Valve Guide	CH420
236	442.6402-01	Flange	CH420
237	840.0532-00	Screw	CH420
238	919.0074-00	Protection Plug Outside	CH420
239	919.0070-00	Protection Plug Outside	CH420
240	919.0217-00	Accumulator Charging Pressure	CH420
241	919.0217-90	Accumulator Charging Pressure With	CH420
242	919.0204-00	Bladder Complete	CH420
243	919.0125-00	Charging Equipment Fp Unit	CH420
244	442.8642-00	Over Pressure Unit	CH420
245	442.8642-90	Over Pressure Unit For Compressed Air	CH420
246	900.1424-00	Hose Coupling	CH420
247	900.1358-00	Clips	CH420
248	819.0187-00	Hose	CH420
249	900.0040-00	Tee	CH420
250	900.0365-00	Hexagon Nipple	CH420
251	900.0022-00	Elbow	CH420
252	900.1139-00	Clip Rsgu	CH420
253	900.0005-00	Elbow	CH420
254	442.9325-00	Over Pressure Fan	CH420
255	912.0138-00	Air Filter Purolator	CH420
256	900.0108-00	Wrought Iron Pipe Fittings	CH420
257	900.0209-00	Plug	CH420
258	900.0022-00	Elbow	CH420
259	900.1139-00	Clip Rsgu	CH420
260	900.0005-00	Elbow	CH420
261	900.0180-00	Nipple	CH420
262	912.0113-00	Air Filter 504-2S 5 Micron	CH420
263	900.0169-00	Nipple	CH420
264	902.0645-00	Regulator	CH420

265	900.0182-00	Nipple	CH420
266	900.0054-00	Tee	CH420
267	900.0209-00	Plug	CH420
268	923.0267-00	Pressure Gauge	CH420
269	900.0172-00	Nipple	CH420
270	879.0322-00	V-Belt Pulley	CH420
271	869.0221-00	Bushing	CH420
272	857.0052-00	Key	CH420
273	442.6162-01	Washer	CH420
274	847.0016-00	Washer	CH420
275	840.0065-00	Screw	CH420
276	869.0221-00	Bushing	CH420
277	869.0187-00	Bushing	CH420
278	869.0189-00	Bushing	CH420
279	869.0188-00	Bushing	CH420
280	869.0258-00	Bushing	CH420
281	875.0285-00	V-Belt Spc	CH420
282	875.0243-00	V-Belt Spc	CH420
283	875.0323-00	V-Belt Spc	CH420
284	875.0244-00	V-Belt Spc	CH420
285	875.0285-00	V-Belt Spc	CH420
286	875.0244-00	V-Belt Spc	CH420
287	869.0221-00	Bushing	CH420
288	869.0187-00	Bushing	CH420
289	869.0189-00	Bushing	CH420
290	869.0188-00	Bushing	CH420
291	869.0258-00	Bushing	CH420
292	879.0322-00	V-Belt Pulley	CH420
293	442.6162-01	Washer	CH420
294	847.0016-00	Washer	CH420
295	840.0067-00	Screw	CH420
296	857.0052-00	Key	CH420
297	869.0221-00	Bushing	CH420
298	879.0494-00	V-Belt Pulley	CH420
299	869.0328-00	Bushing	CH420
300	442.6162-00	Washer	CH420
301	847.0016-00	Washer	CH420
302	840.0067-00	Screw	CH420

303	879.0616-00	V-Belt Pulley	CH420
304	869.0331-00	Bushing	CH420
305	879.0620-00	V-Belt Pulley	CH420
306	875.0365-00	V-Belt	CH420
307	857.0052-00	Key	CH420
308	126.0383-001	Risk Of Crushing	CH420
309	126.0384-001	Warning Flying Fragments	CH420
310	126.0385-001	Warning Sign Read Manual	CH420
311	126.0441-001	Sandvik Logotype Silver	CH420
312	126.0412-001	Sign Product Name	CH420
313	885.0250-00	Sign To Mark Centre Of Gravity	CH420
314	126.5007-01	Identification Plate	CH420
315	885.0267-00	Warning Sign Danger	CH420
316	442.6143-01	Locating Bar	CH420
317	442.6212-01	Shim	CH420
318	442.6212-02	Shim	CH420
319	442.6212-03	Shim	CH420
320	442.6212-05	Shim	CH420
321	841.0250-00	Screw	CH420
322	442.6214-01	Gasket	CH420
323	442.6214-02	Gasket	CH420
324	442.6214-03	Gasket	CH420
325	868.0801-00	Bearing	CH420
326	442.6148-01	Spacer	CH420
327	873.0777-00	O-Ring	CH420
328	873.1012-00	Seal	CH420
329	442.6213-01	Gasket	CH420
330	873.0383-00	Sealing Ring Tredo	CH420
331	873.0385-00	Sealing Ring Tredo	CH420
332	840.1093-00	Screw	CH420
333	845.0203-00	Nut Lock	CH420
334	442.9572-00	Sleeve	CH420
335	442.9573-00	Washer	CH420
336	863.0065-00	Disc Spring	CH420
337	442.6174-01	Pin Shaft Arm Liner	CH420
338	442.6175-01	Narrow Arm Liner	CH420
339	442.8902-01	Wearing Plates	CH420
340	442.8903-01	Wearing Plates	CH420

341	442.8904-01	Wearing Plates	CH420
342	442.8905-01	Wearing Plates	CH420
343	442.8906-01	Wearing Plates	CH420
344	442.8901-06	Square Bar	CH420
345	847.0059-00	Washer	CH420
346	840.0047-00	Screw	CH420
347	912.0126-00	Filter	CH420
348	912.0129-00	Filter Cartridge	CH420
349	912.0139-00	Filter Cartridge	CH420
350	912.0155-00	Filter Cartridge	CH420
351	442.9961-00	Basic Design	CH430
352	442.7908-901	Bottomshell Assembly	CH430
353	442.7201-00	Cover	CH430
354	843.1267-00	Stud Screw	CH430
355	847.0147-00	Washer	CH430
356	845.0030-00	Lock Nut	CH430
357	442.7915-01	Liner-Pin Shaft Arm	CH430
358	442.7914-01	Liner-Narrow Arm	CH430
359	900.0027-00	Elbow	CH430
360	452.4190-001	Bottom Shell Bushing	CH430
361	853.0464-00	Pin	CH430
362	900.0921-00	Swivel Branch Tee Adapter	CH430
363	900.1412-00	Pipes Pipe	CH430
364	900.0276-00	Cover	CH430
365	442.7929-01	Dust Collar	CH430
366	840.0634-00	Screw	CH430
367	442.7932-01	Ring	CH430
368	853.0464-00	Pin	CH430
369	840.1034-00	Screws	CH430
370	847.0016-00	Washer	CH430
371	452.4194-001	Locating Bar	CH430
372	442.7933-01	Shim	CH430
373	442.7933-02	Shim	CH430
374	442.7933-03	Shim	CH430
375	442.7933-04	Shim	CH430
376	841.0019-00	Screw	CH430
377	442.7934-01	Gasket	CH430
378	442.7931-01	Seal Ring- Inner	CH430

379	840.0070-00	Screw	CH430
380	847.0060-00	Washer	CH430
381	840.0720-00	Screws	CH430
382	845.0221-00	Nut	CH430
383	847.0162-00	Washer	CH430
384	899.0229-00	Protective Cap	CH430
385	442.9529-02	Screw	CH430
386	899.0229-00	Protective Cap	CH430
387	442.7921-01	Eccentric	CH430
388	452.4191-001	Eccentric Bushing	CH430
389	452.4192-001	Eccentric Bushing	CH430
390	452.4193-001	Eccentric Bushing	CH430
391	442.7926-01	Hub	CH430
392	442.7930-01	Ring	CH430
393	840.1156-00	Screws	CH430
394	847.0147-00	Washer	CH430
395	442.9608-01	Key	CH430
396	841.0026-00	Screw	CH430
397	841.0024-00	Screw	CH430
398	847.0180-00	Washer	CH430
399	442.7802-00	Gear And Pinion Set	CH430
400	442.8011-01	Key	CH430
401	452.4188-001	Ecc. Wearing Plate	CH430
402	853.0474-00	Spring Pin Prym	CH430
403	442.7889-01	Hydroset Cylinder	CH430
404	840.0542-00	Screws	CH430
405	847.0124-00	Washer	CH430
406	442.7892-01	Hydroset Cylinder Bushing	CH430
407	840.0019-00	Screws	CH430
408	847.0012-00	Washer	CH430
409	873.0836-00	Seals	CH430
410	442.9668-00	Piston	CH430
411	853.0118-00	Pins	CH430
412	442.7893-01	Piston Wearing Plate	CH430
413	442.7894-01	Step Washer	CH430
414	442.7897-00	Chevron Packing	CH430
415	442.7896-01	Packing Clamp Plate	CH430
416	841.0266-00	Screw	CH430

417	442.9667-00	Hydroset Cylinder Cover	CH430
418	840.0670-00	Screw	CH430
419	847.0124-00	Washer	CH430
420	900.2302-00	Plug	CH430
421	873.0157-00	O-Ring	CH430
422	873.1275-00	O-Ring	CH430
423	442.8783-01	Plug	CH430
424	873.0111-00	O-Ring	CH430
425	840.0023-00	Screws	CH430
426	847.0012-00	Washer	CH430
427	840.0019-00	Screws	CH430
428	442.9962-901	Pinionshaft Housing Assembly	CH430
429	442.7949-01	Pinion Shaft Housing	CH430
430	442.7953-01	Gasket	CH430
431	442.7953-02	Gasket	CH430
432	442.7953-03	Gasket	CH430
433	442.7802-02	Pinion	CH430
434	868.0790-00	Bearing	CH430
435	868.0805-00	Bearing	CH430
436	442.7954-01	Spacer	CH430
437	442.7954-01	Spacer	CH430
438	873.0778-00	Seals O-Ring	CH430
439	873.0778-00	Seals O-Ring	CH430
440	873.1097-00	Oil Seal Ring	CH430
441	873.1097-00	Oil Seal Ring	CH430
442	442.7951-01	Bearing Cover	CH430
443	442.7950-01	Bearing Cover	CH430
444	840.0021-00	Screw	CH430
445	840.0046-00	Screw	CH430
446	847.0147-00	Washer	CH430
447	442.7957-01	Gasket	CH430
448	442.7956-01	Gasket	CH430
449	442.7956-02	Gasket	CH430
450	900.0717-00	Filter Plug	CH430
451	853.0590-00	Spring Pin	CH430
452	442.7959-01	Plug	CH430
453	873.0383-00	Sealing Ring Tredo	CH430
454	442.9936-01	Pinion Shaft	CH430

455	857.0046-00	Key	CH430
456	442.2018-01	Plug	CH430
457	900.0269-00	Barrel Nipples	CH430
458	900.0275-00	Wrought Iron Pipe Fittings Socket 3/4	CH430
459	442.7958-01	Nipple Oil Level	CH430
460	873.0385-00	Tredo	CH430
461	855.0103-00	3_Retaining Rings Retaining Ring Sga	CH430
462	840.1063-00	Screw	CH430
463	845.0009-00	Nut	CH430
464	442.8313-901	Mainshaft Assembly Excl. Mantle	CH430
465	442.8313-902	Mainshaft Assembly With Mantle	CH430
466	442.7902-01	Main Shaft	CH430
467	442.7913-01	Main Shaft Sleeve	CH430
468	853.0118-00	Pins Cp	CH430
469	442.7895-01	Main Shaft Step	CH430
470	855.0103-00	3_Retaining Rings Retaining Ring Sga	CH430
471	442.7910-01	Head Center	CH430
472	452.1502-001	Mantle Ef	CH430
473	442.7989-01	Mantle B	CH430
474	442.9759-01	Mantle Hc	CH430
475	442.7988-01	Mantle A	CH430
476	442.7912-00	Head Nut With Burn Ring	CH430
477	442.7918-01	Inner Head Nut	CH430
478	442.7911-01	Burn Ring	CH430
479	442.8017-01	Dust Seal Ring	CH430
480	442.8020-01	Retaining Ring	CH430
481	442.8021-01	Retainer	CH430
482	442.8022-01	Scraper	CH430
483	840.0068-00	Screw	CH430
484	840.0070-00	Screw	CH430
485	847.0016-00	Washer	CH430
486	442.8314-901	Topshell Assembly Excl. Crushing	CH430
487	442.8315-00	Filler Ring Ass	CH430
488	442.8316-00	Filler Ring Ass	CH430
489	442.7981-00	Top Shell	CH430
490	442.7984-01	Arm Shield	CH430
491	900.1162-00	Pipe Couplings	CH430
492	808.0220-00	Steel Pipe	CH430

493	914.0093-00	Lubrication Nipple	CH430
494	442.7976-01	Spider Cap	CH430
495	912.0114-00	Air Filter	CH430
496	900.0169-00	Nipple	CH430
497	900.0002-00	Eblow	CH430
498	873.0833-00	Seals	CH430
499	840.0069-00	Screw	CH430
500	847.0120-00	Washer	CH430
501	442.6473-01	Spider Bushing	CH430
502	840.0080-00	Screw	CH430
503	847.0132-00	Washer	CH430
504	442.6470-01	Oil Seal Ring	CH430
505	900.0981-00	Plug	CH430
506	452.1216-001	Concave Mf	CH430
507	442.8246-01	Concave Ring M	CH430
508	442.8251-01	Concave Ring F	CH430
509	442.8630-01	Concave Ring Ef	CH430
510	442.8248-01	Concave Ring C	CH430
511	442.8247-01	Concave Ring Mc	CH430
512	442.8249-01	Concave Ring Ec	CH430
513	873.1112-00	Sealing Compound	CH430
514	442.8245-01	Filler Ring	CH430
515	442.8008-01	Filler Ring	CH430
516	442.8009-01	Ring	CH430
517	442.8009-01	Ring	CH430
518	442.8010-01	O-Ring	CH430
519	840.0079-00	Screw	CH430
520	847.0132-00	Washer	CH430
521	442.8695-00	Wearing Ring	CH430
522	442.8001-01	Screw	CH430
523	845.0216-00	Nut Lock	CH430
524	442.7996-01	Sleeve	CH430
525	442.7997-01	Washer	CH430
526	847.0264-00	Spherical Washer	CH430
527	847.0265-00	Conical Washer	CH430
528	863.0032-00	Disc Spring	CH430
529	840.0542-00	Screws	CH430
530	442.7999-01	Head	CH430

531	847.0124-00	Washer	CH430
532	442.8317-00	Hydroset	CH430
533	442.8045-00	Wrench And Tool Set	CH430
534	442.7908-901	Bottomshell Assembly	CH430
535	442.7915-01	Liner Pinionshaft Arm	CH430
536	442.7914-01	Liner Narrow Arm	CH430
537	442.7201-90	Cover	CH430
538	843.1267-00	Stud Screw	CH430
539	847.0147-00	Washer Round	CH430
540	845.0030-00	Lock Nut	CH430
541	853.0464-00	Pin	CH430
542	442.8870-00	Liner Bottomshell	CH430
543	853.0464-00	Pin	CH430
544	853.0474-00	Spiral Pin	CH430
545	442.9962-901	Pinionshaft Housing Assembly	CH430
546	442.7949-01	Pinionshaft Housing	CH430
547	868.0790-00	Bearing	CH430
548	868.0805-00	Bearing	CH430
549	442.7954-01	Spacer	CH430
550	873.0778-00	O-Ring	CH430
551	873.1097-00	Oil Seal Ring	CH430
552	442.7951-01	Bearing Cover	CH430
553	442.7957-01	Gasket	CH430
554	442.7956-01	Gasket	CH430
555	442.7956-02	Gasket	CH430
556	900.0717-00	Filter Plug	CH430
557	442.7959-01	Plug	CH430
558	442.9936-01	Pinionshaft	CH430
559	442.2018-01	Plug	CH430
560	442.7958-01	Oil Level Gauge	CH430
561	900.0269-00	Hose Coupling	CH430
562	442.8313-901	Mainshaft Assembly Excl. Mantle	CH430
563	442.7913-01	Mainshaft Sleeve	CH430
564	442.7918-01	Head Nut Inner	CH430
565	853.0118-00	Parallel Pin	CH430
566	855.0103-00	Retaining Ring	CH430
567	442.2614-00	Transport Rack	CH430
568	899.0299-00	Lifting Eye Bolt	CH430

569	442.8313-902	Mainshaft Assembly With Mantle	CH430
570	442.7988-01	Mantle A	CH430
571	442.7989-01	Mantle B	CH430
572	452.1502-001	Mantle Ef	CH430
573	442.9759-01	Mantle Hc	CH430
574	452.6115-001	Mantle Flexifeed B	CH430
575	442.8020-01	Retaining Ring	CH430
576	442.8017-01	Dust Seal Ring	CH430
577	442.7912-00	Head Nut	CH430
578	442.7913-01	Mainshaft Sleeve	CH430
579	442.7918-01	Head Nut Inner	CH430
580	442.8021-01	Retainer	CH430
581	442.8022-01	Scraper	CH430
582	853.0118-00	Parallel Pin	CH430
583	855.0103-00	Retaining Ring	CH430
584	840.0068-00	Screw	CH430
585	840.0070-00	Screw	CH430
586	847.0016-00	Washer	CH430
587	831.0016-00	Casting Compound	CH430
588	442.2614-00	Transport Rack	CH430
589	899.0299-00	Lifting Eye Bolt	CH430
590	442.8314-901	Topshell Assembly Excl. Crushing	CH430
591	442.7984-01	Arm Shield	CH430
592	808.0220-00	Pipe	CH430
593	900.0425-00	Compression Fittings	CH430
594	900.0169-00	Hexagon Nipple	CH430
595	900.0002-00	Elbow	CH430
596	912.0114-00	Air Filter	CH430
597	914.0093-00	Lubrication Nipple	CH430
598	442.8016-00	Feed Hopper Distributorcomplete	CH430
599	442.7985-00	Feed Hopper	CH430
600	840.0049-00	Screw	CH430
601	845.0007-00	Nut	CH430
602	847.0002-00	Washer	CH430
603	847.0147-00	Washer	CH430
604	442.5677-00	Feed Distributer -Rh	CH430
605	442.5677-90	Feed Distributer-Lh	CH430
606	442.7994-01	Holder	CH430

607	840.0045-00	Screw	CH430
608	845.0007-00	Nut	CH430
609	847.0147-00	Washer	CH430
610	442.8015-00	Feed Hopper With Cone	CH430
611	442.7985-00	Feed Hopper	CH430
612	840.0049-00	Screw	CH430
613	845.0007-00	Nut	CH430
614	847.0002-00	Washer	CH430
615	847.0147-00	Washer	CH430
616	442.8007-00	Feed Hopper Cone-Lh	CH430
617	442.8007-90	Feed Hopper Cone-Rh	CH430
618	442.8015-90	Feed Hopper With Ec Cone	CH430
619	442.7985-00	Feed Hopper	CH430
620	840.0049-00	Screw	CH430
621	845.0007-00	Nut	CH430
622	847.0002-00	Washer	CH430
623	847.0147-00	Washer	CH430
624	442.7986-00	Feed Hopper Cone-Lh	CH430
625	442.7986-90	Feed Hopper Cone-Rh	CH430
626	442.9776-00	Rubber Compression Mountings For	CH430
627	845.0387-00	Nut	CH430
628	847.0124-00	Washer	CH430
629	442.9779-00	Top Plate	CH430
630	864.0080-00	Rubber Compression Mounting	CH430
631	840.0044-00	Screw	CH430
632	847.0147-00	Washer	CH430
633	442.9780-01	Lower Fixing Plate	CH430
634	442.9776-90	Rubber Compression Mountings For	CH430
635	864.0080-00	Rubber Compression Mounting	CH430
636	840.0044-00	Screw	CH430
637	847.0147-00	Washer	CH430
638	442.9780-01	Lower Fixing Plate	CH430
639	840.0048-00	Screws	CH430
640	845.0030-00	Lock Nut	CH430
641	919.0243-00	Accumulator Uncharged	CH430
642	840.0045-00	Screw	CH430
643	847.0059-00	Washer	CH430
644	442.1954-01	Support	CH430

645	442.8777-00	Check Valve Pt.	CH430
646	452.6035-001	Hydraulic Hose	CH430
647	452.6040-901	Hose Protection	CH430
648	873.0390-00	Seal Ring	CH430
649	900.0659-00	Straight Adapter	CH430
650	900.2793-00	Adapter	CH430
651	841.0273-00	Hexagon Socket Head Cap Screw	CH430
652	919.0205-00	Bladder Complete	CH430
653	919.0125-00	Charging Equipment Fp Unit	CH430
654	442.6402-01	Flange	CH430
655	442.6405-01	Valve Guide	CH430
656	442.6406-01	Valve Body	CH430
657	873.0130-00	O-Ring	CH430
658	442.8776-01	Connection	CH430
659	442.6407-01	Seat	CH430
660	442.6403-01	Valve	CH430
661	127.0004-30	Spring	CH430
662	840.0532-00	Screw	CH430
663	879.0437-00	V-Belt Pulley	CH430
664	869.0189-00	Bushing For Grooved Pulleys	CH430
665	857.0346-00	Key	CH430
666	442.9940-00	Spacer	CH430
667	442.7955-01	Washer	CH430
668	847.0016-00	Washer	CH430
669	840.0066-00	Screw	CH430
670	869.0221-00	Bushing	CH430
671	869.0187-00	Bushing	CH430
672	869.0188-00	Bushing	CH430
673	869.0258-00	Bushing	CH430
674	875.0323-00	V-Belt	CH430
675	875.0244-00	V-Belt	CH430
676	869.0187-00	Bushing	CH430
677	869.0189-00	Bushing	CH430
678	869.0258-00	Bushing	CH430
679	879.0437-00	V-Belt Pulley	CH430
680	442.7955-01	Washer	CH430
681	840.0066-00	Screw	CH430
682	847.0016-00	Washer	CH430

683	857.0346-00	Key	CH430
684	442.9940-01	Spacer	CH430
685	869.0189-00	Bushing	CH430
686	879.0495-00	V-Belt Pulley	CH430
687	869.0327-00	Bushing	CH430
688	442.7955-01	Washer	CH430
689	847.0016-00	Washer	CH430
690	840.0066-00	Screw	CH430
691	879.0614-00	V-Belt Pulley	CH430
692	869.0332-00	Bushing	CH430
693	869.0337-00	Bushing	CH430
694	869.0335-00	Bushing	CH430
695	879.0622-00	V-Belt Pulley	CH430
696	875.0364-00	V-Belt	CH430
697	857.0209-00	Key	CH430
698	126.0383-001	Risk Of Crushing	CH430
699	126.0384-001	Warning Flying Fragments	CH430
700	126.0385-001	Warning Sign Read Manual	CH430
701	126.0413-001	Sign Product Name	CH430
702	126.0443-001	Logotype Silver	CH430
703	885.0250-00	Sign To Mark Centre Of Gravity	CH430
704	126.5007-01	Identification Plate	CH430
705	885.0267-00	Warning Sign Danger	CH430
706	452.4194-001	Locating Bar	CH430
707	442.7933-01	Shim	CH430
708	442.7933-02	Shim	CH430
709	442.7933-03	Shim	CH430
710	442.7933-04	Shim	CH430
711	841.0019-00	Screw	CH430
712	442.7953-01	Gasket	CH430
713	442.7953-02	Gasket	CH430
714	442.7953-03	Gasket	CH430
715	868.0790-00	Bearing	CH430
716	868.0805-00	Bearing	CH430
717	442.7954-01	Spacer	CH430
718	873.0778-00	O-Ring	CH430
719	873.1097-00	Seal	CH430
720	442.7957-01	Gasket	CH430

721	442.7956-01	Gasket	CH430
722	442.7956-02	Gasket	CH430
723	873.0383-00	Sealing Ring	CH430
724	873.0385-00	Sealing Ring	CH430
725	442.8001-01	Screw	CH430
726	845.0216-00	Nut Lock	CH430
727	442.7996-01	Sleeve	CH430
728	442.7997-01	Washer	CH430
729	863.0032-00	Disc Spring	CH430
730	442.7915-01	Pin Shaft Arm Liner	CH430
731	442.7914-01	Narrow Arm Liner	CH430
732	442.8864-01	Wearing Plates	CH430
733	442.8865-01	Wearing Plates	CH430
734	442.8866-01	Wearing Plates	CH430
735	442.8867-01	Wearing Plates	CH430
736	442.8868-01	Wearing Plates	CH430
737	442.8869-01	Wearing Plates	CH430
738	442.8799-06	Bar	CH430
739	847.0059-00	Washer	CH430
740	840.0048-00	Screw	CH430
741	452.0230-901	Bottom Shell	CH440
742	442.7201-00	Cover	CH440
743	843.1267	Stud Screw	CH440
744	847.0147-00	Washer	CH440
745	845.0030-00	Lock Nut	CH440
746	442.7140-00	Liner-Pin Shaft Arm	CH440
747	442.7141-00	Liner-Norrow Arm	CH440
748	900.0027-00	Elbow	CH440
749	442.7146-01	Bottom Shell Bushing	CH440
750	853.0464-00	Pin	CH440
751	900.0921-00	Swivel Branch Tee Adapter	CH440
752	900.1412-00	Pipes Pipe	CH440
753	900.0276-00	Cover	CH440
754	442.7106-01	Dust Collar	CH440
755	840.0634-00	Screw	CH440
756	442.7109-01	Ring	CH440
757	853.0464-00	Pin	CH440
758	840.1151-00	Screws	CH440

759	847.0016-00	Washer	CH440
760	442.7110-01	Locating Bar	CH440
761	442.7168-01	Shim	CH440
762	442.7168-02	Shim	CH440
763	442.7168-03	Shim	CH440
764	442.7168-04	Shim	CH440
765	841.0019-00	Screw	CH440
766	442.7170-01	Gasket	CH440
767	442.7108-01	Seal Ring Inner	CH440
768	840.0071-00	Screw	CH440
769	847.0060-00	Washer	CH440
770	840.1073-00	Screws	CH440
771	845.0322-00	Nut	CH440
772	847.0171-00	Washer	CH440
773	899.0278-00	Protective Cap	CH440
774	442.7243-01	Screw	CH440
775	899.0278-00	Protective Cap	CH440
776	442.7151-01	Eccentric	CH440
777	442.9643-01	Eccentric Bushing	CH440
778	442.9642-01	Eccentric Bushing	CH440
779	442.9406-01	Eccentric Bushing	CH440
780	442.7142-01	Hub	CH440
781	442.7169-00	Ring	CH440
782	840.1157-00	Screws	CH440
783	847.0147-00	Washer	CH440
784	442.9609-01	Key	CH440
785	841.0027-00	Screw	CH440
786	841.0025-00	Screw	CH440
787	847.0180-00	Washer	CH440
788	442.7093-00	Gear And Pinion Set	CH440
789	442.7171-01	Key	CH440
790	442.7107-01	Eccentric Wearing Plate	CH440
791	853.0646-00	Pin	CH440
792	442.7163-01	Hydroset Cylinder	CH440
793	840.0671-00	Screw	CH440
794	847.0124-00	Washer	CH440
795	442.7166-01	Hydroset Cylinder Bushing	CH440
796	840.0019-00	Screws	CH440

797	847.0012-00	Washer	CH440
798	873.0892-00	O-Ring	CH440
799	442.9672-00	Piston	CH440
800	853.0119-00	Pin	CH440
801	442.7122-01	Piston Wearing Plate	CH440
802	442.7121-01	Step Washer	CH440
803	442.7112-00	Chevron Packing	CH440
804	442.7167-01	Packing Clamp Plate	CH440
805	841.0266-00	Screw	CH440
806	442.9663-00	Hydroset Cylinder Cover	CH440
807	840.0671-00	Screw	CH440
808	840.0676-00	Screw	CH440
809	847.0124-00	Washer	CH440
810	900.2302-00	Plug	CH440
811	873.0835-00	O-Ring	CH440
812	873.1276-00	O-Ring	CH440
813	442.8783-01	Plug	CH440
814	873.0111-00	O-Ring	CH440
815	840.0023-00	Screw	CH440
816	847.0012-00	Washer	CH440
817	840.0019-00	Screws	CH440
818	442.9966-00	Pinion Shaft Housing Assembled	CH440
819	442.7506-01	Pinion Shaft Housing	CH440
820	442.7136-01	Gasket	CH440
821	442.7136-03	Gasket	CH440
822	442.7136-02	Gasket	CH440
823	442.7093-02	Pinion	CH440
824	868.0282-00	Bearings Spherical Roller	CH440
825	868.0804-00	Tapered Roller Bearing	CH440
826	442.7130-01	Spacer Inner	CH440
827	442.7131-01	Spacer Outer	CH440
828	873.0779-00	Seals O-Ring	CH440
829	873.0399-00	Seals O-Ring	CH440
830	873.1208-00	Oil Seal Ring	CH440
831	873.1208-00	Oil Seal Ring	CH440
832	442.9684-01	Bearing Cover Inner	CH440
833	442.7133-01	Bearing Cover Outer	CH440
834	840.0045-00	Screw	CH440

835	847.0147-00	Washer	CH440
836	840.0066-00	Screw	CH440
837	847.0016-00	Washer	CH440
838	442.7134-01	Gasket	CH440
839	442.7135-01	Gasket	CH440
840	442.7135-02	Gasket	CH440
841	853.0590-00	Spring Pin	CH440
842	442.9937-01	Pinion Shaft	CH440
843	857.0337-00	Key	CH440
844	900.0022-00	Elbow	CH440
845	900.2026-00	Plug	CH440
846	873.0385-00	Tredo	CH440
847	442.7577-01	Oil Level Plug	CH440
848	873.0108-00	O-Ring	CH440
849	442.7578-01	Pipe	CH440
850	855.0108-00	Retaining Rings	CH440
851	840.1063-00	Screw	CH440
852	845.0009-00	Nut	CH440
853	442.7259-00	Main Shaft Ass. Excl Mantle	CH440
854	442.7100-01	Main Shaft	CH440
855	442.7117-01	Main Shaft Sleeve	CH440
856	853.0119-00	Pin	CH440
857	442.7120-01	Main Shaft Step	CH440
858	855.0026-00	Retaining Ring	CH440
859	442.8332-01	Head Centre	CH440
860	442.7230-01	Mantle	CH440
861	442.7225-01	Mantel	CH440
862	442.9073-01	Mantel	CH440
863	442.8039-01	Mantle	CH440
864	442.7105-00	Head Nut With Burn Ring	CH440
865	442.8333-01	Inner Head Ring	CH440
866	442.7115-01	Burn Ring	CH440
867	442.7102-01	Dust Seal Ring	CH440
868	442.7103-01	Retaining Ring	CH440
869	442.7523-01	Retainer	CH440
870	442.7524-01	Scraper	CH440
871	840.0069-00	Screw	CH440
872	840.0071-00	Screw	CH440

873	847.0016-00	Washer	CH440
874	442.8553-00	Top Shell Ass Excl Concave Ring	CH440
875	442.7518-00	Filler Ring Assembly	CH440
876	442.7519-00	Filler Ring Assembly	CH440
877	442.7180-01	Top Shell	CH440
878	442.7190-01	Arm Shield	CH440
879	900.1162-00	Pipe Couplings	CH440
880	808.0220-00	Steel Pipe	CH440
881	914.0093-00	Lubrication Nipple	CH440
882	442.7492-01	Spider Cap	CH440
883	912.0114-00	Air Filter	CH440
884	900.0169-00	Nipple	CH440
885	900.0002-00	Eblow	CH440
886	873.0838-00	Seals	CH440
887	840.0078-00	Screw	CH440
888	847.0165-00	Washer	CH440
889	442.9408-01	Spider Bushing	CH440
890	840.0652-00	Screw	CH440
891	847.0132-00	Washer	CH440
892	442.7193-01	O-Ring	CH440
893	900.0981-00	Plug	CH440
894	442.8416-01	Concave Ring	CH440
895	442.8417-01	Concave Ring	CH440
896	442.8418-01	Concave Ring	CH440
897	442.8420-01	Concave Ring	CH440
898	442.8421-01	Concave Ring	CH440
899	452.3027-001	Concave	CH440
900	442.8419-01	Concave Ring	CH440
901	442.7485-01	Filler Ring	CH440
902	442.7484-01	Filler Ring	CH440
903	840.1074-00	Screw	CH440
904	840.1074-00	Screw	CH440
905	442.7251-03	Washer	CH440
906	442.7251-02	Washer	CH440
907	442.7252-01	Shim	CH440
908	442.7252-02	Shim	CH440
909	442.7252-03	Shim	CH440
910	442.7252-04	Shim	CH440

911	442.7252-01	Shim	CH440
912	442.7252-02	Shim	CH440
913	442.7252-03	Shim	CH440
914	442.7252-04	Shim	CH440
915	442.8908-03	Hose	CH440
916	442.8687-01	Screw	CH440
917	845.0284-00	Lock Nut	CH440
918	442.7253-01	Sleeve	CH440
919	442.7271-01	Washer	CH440
920	863.0058-00	Disc Spring	CH440
921	442.8425-01	Support Ring	CH440
922	442.8290-01	Dowel Pin	CH440
923	442.7273-00	Hydroset	CH440
924	442.7255-00	Wrench And Tool Set	CH440
925	831.0016-00	Casting Compound	CH440
926	442.7140-00	Liner-Pin Shaft Arm	CH440
927	442.7141-01	Liner-Narrow Arm	CH440
928	442.8794-01	Wearing Plates	CH440
929	442.8798-01	Wearing Plates	CH440
930	442.8797-01	Wearing Plates	CH440
931	442.8796-01	Wearing Plates	CH440
932	442.8795-01	Wearing Plates	CH440
933	452.0239-001	Wearing Plates	CH440
934	452.0238-001	Wearing Plates	CH440
935	804.0004-00	Rod	CH440
936	840.0049-00	Screw	CH440
937	847.0059-00	Washer	CH440
938	442.7269-00	Feed Hopper With Distributor Complete	CH440
939	442.7191-00	Feed Hopper	CH440
940	442.7191-90	Feed Hopper With Insp. Door	CH440
941	840.0070-00	Screw	CH440
942	845.0009-00	Nut	CH440
943	847.0016-00	Washer	CH440
944	442.7267-00	Feed Distributer -Rh	CH440
945	442.7267-90	Feed Distributer-Lh	CH440
946	442.7268-01	Bracket	CH440
947	840.0065-00	Screw	CH440
948	845.0009-00	Nut	CH440

949	847.0016-00	Washer	CH440
950	442.7270-00	Feed Hopper With Cone Complete	CH440
951	442.7191-00	Feed Hopper	CH440
952	442.7191-90	Feed Hopper With Insp. Door	CH440
953	840.0070-00	Screw	CH440
954	845.0009-00	Nut	CH440
955	847.0016-00	Washer	CH440
956	442.7192-00	Feed Hopper Cone-Lh	CH440
957	442.7192-90	Feed Hopper Cone-Rh	CH440
958	442.8159-00	Feed Hopper Cone-Lh	CH440
959	442.8159-90	Feed Hopper Cone-Rh	CH440
960	442.8030-00	Feed Hopper Cone-Lh	CH440
961	442.8030-90	Feed Hopper Cone-Rh	CH440
962	442.6635-00	Rubber Compression Mounting For	CH440
963	845.0387-00	Nut Lock	CH440
964	847.0124-00	Washer	CH440
965	442.9779-00	Top Plate	CH440
966	864.0046-00	Rubber Compression Mounting Saw 150	CH440
967	840.0044-00	Screw	CH440
968	847.0147-00	Washer	CH440
969	442.9780-00	Fixing Plate, Lower	CH440
970	442.6635-90	Rubber Compression Mountings For	CH440
971	864.0070-00	Rubber Compression Mounting Saw 150	CH440
972	840.0044-00	Screw	CH440
973	847.0147-00	Washer	CH440
974	442.9780-00	Fixing Plate, Lower	CH440
975	840.0048-00	Screw	CH440
976	845.0030-00	Nut	CH440
977	840.0045-00	Screw	CH440
978	847.0147-00	Washer	CH440
979	442.1954-01	Clamp	CH440
980	873.0390-00	Seal Ring	CH440
981	650.0173-02	Hydraulic Hose	CH440
982	442.8179-00	Protection	CH440
983	900.0659-00	Adapter	CH440
984	442.8624-00	Check Valve	CH440
985	840.0055-00	Screw	CH440
986	847.0060-00	Washer Tbrsb	CH440

987	919.0231-00	Adapter	CH440
988	442.6508-00	Connection Piece	CH440
989	442.6407-01	Seat	CH440
990	442.6403-01	Valve	CH440
991	127.0004-30	Spring	CH440
992	442.6406-01	Body	CH440
993	873.0130-00	O-Ring	CH440
994	442.6405-01	Valve Guide	CH440
995	442.6402-01	Flange	CH440
996	840.0532-00	Screw	CH440
997	919.0074-00	Protection Plug R2" Outside	CH440
998	919.0070-00	Protection Plug R 3/4 Outside	CH440
999	919.0219-00	Accumulator Charching Pressure 5,0	CH440
1000	919.0219-90	Accumulator Charching Pressure 6,0	CH440
1001	919.0206-00	Bladder Complete	CH440
1002	919.0125-00	Charging Equipment Fp Unit	CH440
1003	442.8642-00	Over Pressure Unit	CH440
1004	442.8642-90	Over Pressure Unit For Compressed Air	CH440
1005	900.1424-00	Hose Coupling	CH440
1006	900.1358-00	Clips	CH440
1007	819.0187-00	Hose	CH440
1008	900.0040-00	Tee	CH440
1009	900.0365-00	Hexagon Nippel	CH440
1010	900.0022-00	Elbow	CH440
1011	900.1139-00	Clip	CH440
1012	900.0005-00	Elbow	CH440
1013	442.9325-00	Over Pressure Fan	CH440
1014	912.0138-00	Air Filter Purolator	CH440
1015	900.0108-00	Wrought Iron Pipe Fittings	CH440
1016	900.0209-00	Plug	CH440
1017	900.0022-00	Elbow	CH440
1018	900.1139-00	Clip	CH440
1019	900.0005-00	Elbow	CH440
1020	900.0180-00	Nipple	CH440
1021	912.0113-00	Air Filter	CH440
1022	900.0169-00	Nipple	CH440
1023	902.0645-00	Regulator	CH440
1024	900.0182-00	Nipple	CH440

1025	900.0054-00	Tee	CH440
1026	900.0209-00	Plug	CH440
1027	923.0267-00	Pressure Gauge	CH440
1028	900.0172-00	Nipple	CH440
1029	442.9949-00	V-Belt Drive	CH440
1030	879.0359-00	V-Belt Pulley	CH440
1031	869.0235-00	Bushing	CH440
1032	857.0336-00	Key	CH440
1033	442.9951-01	Spacer Ring	CH440
1034	442.7238-01	Washer	CH440
1035	847.0016-00	Washer	CH440
1036	840.0065-00	Screw	CH440
1037	879.0496-00	V-Belt Pulley	CH440
1038	869.0235-00	Bushing	CH440
1039	857.0336-00	Key	CH440
1040	442.9951-01	Spacer Ring	CH440
1041	442.7238-01	Washer	CH440
1042	847.0016-00	Washer	CH440
1043	840.0065-00	Screw	CH440
1044	879.0359-00	V-Belt Pulley	CH440
1045	442.9929-00	V-Belt Drive	CH440
1046	869.0329-00	Bushing	CH440
1047	442.7238-01	Washer	CH440
1048	847.0016-00	Washer	CH440
1049	840.0066-00	Screw	CH440
1050	879.0617-00	V-Belt Pulley	CH440
1051	879.0624-00	V-Belt Pulley	CH440
1052	879.0356-00	Key	CH440
1053	452.4125	Bottom Shell Assembly	CH660
1054	452.4129	Dust Collar Assembly	CH660
1055	452.4128	Eccentric Assembly	CH660
1056	452.4126	Hydroset Cylinder Assembly	CH660
1057	452.4127	Pinionshaft Housing Assembly	CH660
1058	452.413	Mainshaft Assembly	CH660
1059	452.4131	Top Shell Assembly	CH660
1060	452.4132	Feed Hopper	CH660
1061	442.4978	Hydroset System	CH660
1062	452.4125-901	Bottomshell Assembly	CH660

1063	452.3765-001	Bottomshell	CH660
1064	452.4297-901	Foot Assembly Kit	CH660
1065	840.0669-00	Screw	CH660
1066	847.0124-00	Washer	CH660
1067	442.7907-01	Boss	CH660
1068	842.0013-00	Set Screw	CH660
1069	853.0464-00	Pin	CH660
1070	891.1772-901	Polymer Wear Protection Kit	CH660
1071	853.0646-00	Pin	CH660
1072	452.0441-001	Clamp Pt.	CH660
1073	452.4862-001	Support Accumulator Pt	CH660
1074	840.0048-00	Screw	CH660
1075	847.0059-00	Washer	CH660
1076	840.0650-00	Screw	CH660
1077	847.0132-00	Washer	CH660
1078	900.2108-00	Elbow	CH660
1079	442.8742-01	Bottom Shell Bushing	CH660
1080	900.0921-00	Swivel Branch Tee Adapter	CH660
1081	900.1412-00	Pipes Pipe	CH660
1082	900.0276-00	Cover	CH660
1083	442.8761-01	Ecc. Wearing Plate	CH660
1084	442.8756-01	Foot	CH660
1085	452.4983-901	Foot Plate	CH660
1086	442.4982-901	Foot Plate	CH660
1087	891-1772-901	Polymer Wear Protection Kit	CH660
1088	891.2033-901	Arm Protection Set	CH660
1089	891.2034-901	Arm Protection Set	CH660
1090	891.2133-901	Rubber Lining Wall Protection Kit	CH660
1091	891.1856-901	Wall Protection	CH660
1092	891.1889-901	Wall Protection	CH660
1093	891.1891-901	Wall Protection	CH660
1094	891.1893-901	Wall Protection	CH660
1095	891.1858-901	Wall Protection	CH660
1096	891.1860-901	Wall Protection	CH660
1097	891.1647-902	Inspection Door Pu	CH660
1098	847.0147-00	Washer	CH660
1099	891.2035-901	Bolt And Plug Set	CH660
1100	891.2035-902	Bolt And Plug Set	CH660

1101	845.0030-00	Lock Nut	CH660
1102	891.2133-901	Rubber Lining Wall Protection Kit	CH660
1103	891.1891-901	Wall Protection	CH660
1104	891.1893-901	Wall Protection	CH660
1105	891.1858-901	Wall Protection	CH660
1106	891.1860-901	Wall Protection	CH660
1107	891.1889-901	Wall Protection	CH660
1108	891.1856-901	Wall Protection	CH660
1109	891.2035-901	Bolt And Plug Set	CH660
1110	891.2035-902	Bolt And Plug Set	CH660
1111	891.2134-901	Inspection Door	CH660
1112	891.1647-902	Inspection Door	CH660
1113	847.0147-00	Washer	CH660
1114	845.0030-00	Lock Nut	CH660
1115	442.8733-01	Eccentric	CH660
1116	452.4160-901	Eccentric Bushing Alt.	CH660
1117	442.8729-01	Hub	CH660
1118	442.8743-00	Ring	CH660
1119	840.0066-00	Screw	CH660
1120	847.0016-00	Washer	CH660
1121	442.9610-01	Key	CH660
1122	841.0028-00	Screw	CH660
1123	841.0025-00	Screw	CH660
1124	847.0180-00	Washer	CH660
1125	442.8807-01	Key	CH660
1126	442.8723-00	Gear And Pinion Set Purchase Drawing	CH660
1127	442.8824-01	Eccentric Bushing	CH660
1128	442.8825-01	Eccentric Bushing	CH660
1129	442.8826-01	Eccentric Bushing	CH660
1130	452.4582-901	Rubber Damper Large	CH660
1131	442.5904-01	Fixing Plate	CH660
1132	864.0066-00	Rubber Compression Mounting	CH660
1133	840.1135-00	Screw	CH660
1134	847.0132-00	Washer	CH660
1135	840.0078-00	Screw	CH660
1136	845.0203-00	Nut Lock	CH660
1137	452.4583-901	Rubber Damper Large Single Screw	CH660
1138	845.0273-00	Lock Nut	CH660

1139	847.0162-00	Washer	CH660
1140	442.9781-00	Top Plate	CH660
1141	864.0066-00	Rubber Compression Mounting	CH660
1142	840.1135-00	Screw	CH660
1143	847.0132-00	Washer	CH660
1144	442.5904-01	Fixing Plate	CH660
1145	840.1169-00	Screw	CH660
1146	452.4584-901	Rubber Damper Small	CH660
1147	442.9833-01	Mounting Plate	CH660
1148	840.0044-00	Screw	CH660
1149	847.0147-00	Washer	CH660
1150	864.0080-00	Vibration Damper	CH660
1151	840.0049-00	Screw	CH660
1152	845.0030-00	Lock Nut	CH660
1153	452.4151-001	Dust Collar	CH660
1154	840.0074-00	Screw	CH660
1155	442.8744-01	Ring	CH660
1156	853.0464-00	Pin	CH660
1157	840.1281-00	Screw	CH660
1158	847.0016-00	Washer	CH660
1159	442.8762-01	Locating Bar	CH660
1160	442.8809-01	Shim	CH660
1161	442.8809-02	Shim	CH660
1162	442.8809-03	Shim	CH660
1163	442.8809-04	Shim	CH660
1164	841.0019-00	Screw	CH660
1165	442.8808-01	Gasket	CH660
1166	442.8747-01	Seal Ring Inner	CH660
1167	840.0072-00	Screw	CH660
1168	847.0060-00	Washer	CH660
1169	442.8764-01	Pinion shaft Housing	CH660
1170	442.8803-01	Gasket	CH660
1171	442.8803-02	Gasket	CH660
1172	442.8803-03	Gasket	CH660
1173	868.0799-00	Bearing	CH660
1174	868.0806-00	Bearing	CH660
1175	442.8771-01	Spacer	CH660
1176	873.0128-00	O-Ring	CH660

1177	873.1161-00	Oil Seal Ring	CH660
1178	442.8766-01	Bearing Cover	CH660
1179	442.8765-01	Bearing Cover	CH660
1180	840.0035-00	Screw	CH660
1181	847.0144-00	Washer	CH660
1182	840.0067-00	Screw	CH660
1183	847.0016-00	Washer	CH660
1184	853.0590-00	Spring Pin	CH660
1185	442.8772-01	Pinion shaft	CH660
1186	857.0350-00	Key	CH660
1187	853.0590-00	Spring Pin Prym	CH660
1188	442.8772-01	Pinion shaft	CH660
1189	857.0350-00	Key	CH660
1190	857.0336-00	Key	CH660
1191	900.0022-00	Elbow	CH660
1192	900.0655-00	Adapter	CH660
1193	842.0020-00	Screw	CH660
1194	900.2026-00	Magnetic Plug	CH660
1195	873.0385-00	Tredo Nr.	CH660
1196	442.8778-01	Oil Level Plug	CH660
1197	873.0108-00	Seals O-Ring	CH660
1198	442.7578-01	Pipe	CH660
1199	855.0132-00	Retaining Ring	CH660
1200	845.0009-00	Nut	CH660
1201	840.1063-00	Screw	CH660
1202	452.4130-901	Main shaft Assembly Excl Mantle	CH660
1203	452.4130-902	Main shaft Assembly Incl Mantle	CH660
1204	452.4310-901	Main shaft As.	CH660
1205	442.8792-01	Main shaft Sleeve Pt.	CH660
1206	853.0119-00	Parallel Pin	CH660
1207	855.0026-00	Retaining Ring For Shaft,	CH660
1208	452.4219-901	Mantle Alt.	CH660
1209	831.0016-00	Casting Compound Kg	CH660
1210	442.8800-00	Head Nut With Burning Ring	CH660
1211	442.8791-01	Inner Head Nut	CH660
1212	452.0269-001	Burning Ring Pt.	CH660
1213	442.8802-01	Dust Seal Ring Pt.	CH660
1214	442.8801-01	Retaining Ring Pt.	CH660

1215	442.8804-01	Retainer Pt.	CH660
1216	442.8805-01	Scraper	CH660
1217	840.0069-00	Screw	CH660
1218	840.0071-00	Screw	CH660
1219	847.0016-00	Round Washer	CH660
1220	442.0275-00	Transport Frame	CH660
1221	899.0157-00	Lifting Eye Bolt	CH660
1222	442.8823-01	Filler Ring Mc	CH660
1223	442.8863-01	Filler Ring Mf	CH660
1224	840.1074-00	Screw	CH660
1225	442.7252	Shim	CH660
1226	831-0016-00	Casting Compound	CH660
1227	442.8908-03	Hose	CH660
1228	442.8813-01	Concave Ec	CH660
1229	442.9230-01	Concave Cx	CH660
1230	442.8814-01	Concave C	CH660
1231	442.8815-01	Concave Mc	CH660
1232	442.8816-01	Concave M	CH660
1233	442.8817-01	Concave Mf	CH660
1234	442.8818-01	Concave F	CH660
1235	452.0832-01	Concave Ef	CH660
1236	442.8819-01	Mantle A	CH660
1237	442.8820-01	Mantle B	CH660
1238	442.8821-01	Mantle D	CH660
1239	452.0820-001	Mantle Ef	CH660
1240	452.4131-901	Top Shell Assembly Excl Concave	CH660
1241	452.3760-901	Top shell	CH660
1242	442.8812-01	Arm Shield	CH660
1243	900.0425-00	Compression Fittings	CH660
1244	452.4153-001	Steel Pipe	CH660
1245	914.0093-00	Lubrication Nipple	CH660
1246	900.1030-00	Bushing	CH660
1247	912.0114-00	Air Filter	CH660
1248	900.0169-00	Nipple	CH660
1249	900.0002-00	Elbow	CH660
1250	900.0431-00	Compression Fittings	CH660
1251	191.2376-00	Temperature Sensor	CH660
1252	191.3213-00	Connection Box	CH660

1253	900.2624-00	Jam Nut	CH660
1254	900.0654-00	Adapter	CH660
1255	452.4195-001	Steel Pipe	CH660
1256	452.4131-902	Top Shell Assembly Incl Concave	CH660
1257	840.1073-00	Screws	CH660
1258	845.0322-00	Nut	CH660
1259	847.0171-00	Washer	CH660
1260	442.9530-01	Screw	CH660
1261	899.0278-00	Protective Cap	CH660
1262	452.3760-901	Topshell	CH660
1263	442.8812-01	Arm Shield	CH660
1264	900.0425-00	Compression Fittings	CH660
1265	452.4153-001	Steel Pipe	CH660
1266	914.0093-00	Lubrication Nipple	CH660
1267	900.1030-00	Bushing	CH660
1268	912.0114-00	Air Filter	CH660
1269	900.0169-00	Nipple	CH660
1270	900.0002-00	Elbow	CH660
1271	900.0431-00	Compression Fittings	CH660
1272	452.3841-001	Spider Cap	CH660
1273	873.1401-00	O-Ring	CH660
1274	442.8755-01	Seal Ring	CH660
1275	840.0080-00	Screw	CH660
1276	847.0165-00	Washer	CH660
1277	442.8754-01	Spider Bushing	CH660
1278	191.2376-00	Temperature Sensor Trpf	CH660
1279	191.3213-00	Connection Box Cbt	CH660
1280	900.2624-00	Jam Nut	CH660
1281	900.0654-00	Adapter	CH660
1282	452.4195-001	Steel Pipe	CH660
1283	840.0652-00	Screw	CH660
1284	847.0132-00	Washer	CH660
1285	442.8755-01	Oil Seal Ring	CH660
1286	900.0981-00	Plug Bspt 1" Hexagon	CH660
1287	452.4218-901	Concave Alt	CH660
1288	452.4289-901	Filler Ring Alt	CH660
1289	831.0016-00	Casting Compound	CH660
1290	442.8881-01	Washer	CH660

1291	442.8908-01	Hose	CH660
1292	442.7252-01	Shim	CH660
1293	442.7252-02	Shim	CH660
1294	442.7252-03	Shim	CH660
1295	442.7252-04	Shim	CH660
1296	442.8881-01	Washer	CH660
1297	840.1075-00	Screw	CH660
1298	442.9415-00	Wear Plate	CH660
1299	840.1075-00	Screw	CH660
1300	845.0284-00	Lock Nut	CH660
1301	442.7253-01	Sleeve	CH660
1302	442.7271-01	Washer	CH660
1303	863.0058-00	Disc Spring	CH660
1304	442.8793-01	Support Ring	CH660
1305	442.8290-01	Dowel Pin	CH660
1306	442.8722-01	Hydroset Cylinder	CH660
1307	840.0672-00	Screw	CH660
1308	442.8724-01	Hydroset Cylinder Bushing	CH660
1309	840.0019-00	Screws	CH660
1310	847.0012-00	Washer	CH660
1311	442.8758-00	Piston	CH660
1312	853.0119-00	Pin	CH660
1313	442.8730-01	Piston Wearing Plate	CH660
1314	442.8731-01	Step Washer	CH660
1315	442.8732-01	Main shaft Step	CH660
1316	442.8739-00	Chevron Packing	CH660
1317	442.8725-01	Packing Clamp Plate	CH660
1318	841.0266-00	Screw	CH660
1319	452.4865-01	Hydroset Cylinder Cover	CH660
1320	442.8783-01	Plug	CH660
1321	873.0111-00	O-Ring	CH660
1322	902.0605-00	Air Bleeder	CH660
1323	840.0023-00	Screw	CH660
1324	873.1152-00	O-Ring	CH660
1325	873.0838-00	O-Ring	CH660
1326	873.1277-00	O-Ring	CH660
1327	840.0674-00	Screw	CH660
1328	840.0019-00	Screw	CH660

1329	847.0012-00	Washer	CH660
1330	442.8739-00	Chevron Packing	CH660
1331	841.0266-00	Screw	CH660
1332	873.0838-00	Seals O-Ring	CH660
1333	873.1277-00	Seal O-Ring	CH660
1334	442.8777-00	Check Valve Pt.	CH660
1335	900.0964-00	L-Adapter	CH660
1336	900.2265-00	Plug	CH660
1337	873.0385-00	Seal Ring Tredo	CH660
1338	873.0390-00	Seal Ring Tredo	CH660
1339	900.0659-00	Adapter	CH660
1340	840.0076-00	Screw	CH660
1341	452.0441-001	Clamp	CH660
1342	452.4862-001	Support Accumulator Pt.	CH660
1343	840.0048-00	Screw	CH660
1344	847.0059-00	Washer	CH660
1345	840.0650-00	Screw	CH660
1346	847.0132-00	Washer Round	CH660
1347	452.2899-001	Hose Sae	CH660
1348	452.4933-901	Liner Hydroset Cylinder Cover	CH660
1349	452.5088-901	Accumulator As.	CH660
1350	919.0220-00	Accumulator	CH660
1351	919.0218-00	Accumulator	CH660
1352	840.0065-00	Screw	CH660
1353	847.0016-00	Washer	CH660
1354	900.2041-00	Adapter	CH660
1355	919.0220-00	Accumulator	CH660
1356	919.0218-00	Accumulator	CH660
1357	919.0205-00	Bladder Complete	CH660
1358	919.0125-00	Charging Equipment	CH660
1359	442.8777-00	Check Valve	CH660
1360	442.9776-01	Flange	CH660
1361	442.6407-01	Seat	CH660
1362	442.6403-01	Valve	CH660
1363	127.0004-30	Compression Spring	CH660
1364	442.6406-01	Body	CH660
1365	847.0130-00	O-Ring	CH660
1366	442.6405-01	Valve Guide	CH660

1367	442.6402-01	Flange	CH660
1368	840.0532-00	Screw	CH660
1369	452.4132-901	Feed Hopper Assembly	CH660
1370	452.3877-901	Feed Hopper, Lower	CH660
1371	452.3878-901	Feed Hopper, Upper	CH660
1372	891.1895-901	Feed Hopper Lining, Upper Kit	CH660
1373	452.4197-901	Cones Alt. Lower	CH660
1374	452.4306-901	Feed Distributor As	CH660
1375	840.0070-00	Screw	CH660
1376	847.0016-00	Washer	CH660
1377	845.0215-00	Nut Lock	CH660
1378	840.0067-00	Screw	CH660
1379	840.0069-00	Screw	CH660
1380	891.1895-901	Feed Hopper Lining Kit	CH660
1381	891.1896-901	Feed Hopper Lining	CH660
1382	891.0462-001	Square Washer	CH660
1383	847.0147-00	Round Washer	CH660
1384	845.0030-00	Lock Nut	CH660
1385	843.1323-00	Carriage Bolt	CH660
1386	442.9750-01	Rubber Sheet	CH660
1387	845.0215-00	Nut Lock	CH660
1388	847.0016-00	Washer	CH660
1389	840.0070-00	Screw	CH660
1390	873.1287-00	Rubber Plug	CH660
1391	891.0401-001	Rubber Plug	CH660
1392	891.2128-901	Rubber Lining Kit	CH660
1393	891.1896-901	Feed Hopper Lining	CH660
1394	891.0462-001	Square Washer	CH660
1395	847.0147-00	Washer	CH660
1396	845.0030-00	Lock Nut	CH660
1397	840.0046-00	Screw	CH660
1398	891.0401-001	Rubber Plug	CH660
1399	891.2129-901	Rubber Lining Lit	CH660
1400	442.9750-01	Rubber Sheet	CH660
1401	845.0215-00	Nut Lock	CH660
1402	847.0016-00	Washer	CH660
1403	840.0070-00	Screw	CH660
1404	873.1287-00	Rubber Plug	CH660

1405	452.4213-901	Cones Mc	CH660
1406	452.4216-901	Cone Mc	CH660
1407	891.1908-901	Rubber Lining Mc Kit	CH660
1408	452.4212-901	Cones C	CH660
1409	452.4214-901	Cone C	CH660
1410	891.1902-901	Rubber Lining C Kit	CH660
1411	452.4211-901	Cones Ec	CH660
1412	452.4202-901	Cone Ec	CH660
1413	891.1897-901	Rubber Lining Ec Kit	CH660
1414	891.1908-901	Mc Cone Kit	CH660
1415	891.1909-901	Rubber Lining Cone Mc	CH660
1416	847.0147-00	Washer	CH660
1417	845.0030-00	Lock Nut	CH660
1418	891.0401-001	Rubber Plug	CH660
1419	840.0047-00	Screw	CH660
1420	891.2132-901	Rubber Lining Mc Cone Kit	CH660
1421	891.1909-901	Rubber Lining	CH660
1422	847.0147-00	Washer	CH660
1423	845.0030-00	Lock Nut	CH660
1424	840.0047-00	Screw	CH660
1425	891.0401-005	Rubber Plug	CH660
1426	891.1902-901	C Cone Kit	CH660
1427	891.1903-901	Rubber Lining	CH660
1428	847.0147-00	Washer	CH660
1429	845.0030-00	Lock Nut	CH660
1430	891.0401-001	Rubber Plug	CH660
1431	840.0047-00	Screw	CH660
1432	891.2131-901	Rubber Lining C Cone Kit	CH660
1433	891.1903-901	Rubber Lining	CH660
1434	847.0147-00	Washer	CH660
1435	845.0030-00	Lock Nut	CH660
1436	840.0047-00	Screw	CH660
1437	891.0401-005	Rubber Plug	CH660
1438	891.1897-901	Ec Cone Kit	CH660
1439	847.0147-00	Washer	CH660
1440	845.0030-00	Lock Nut	CH660
1441	891.1898-901	Rubber Lining Cone Ec	CH660
1442	840.0047-00	Screw	CH660

1443	891.0401-001	Rubber Plug	CH660
1444	891.213	Rubber Lining Ec Cone Kit	CH660
1445	891.1898-901	Rubber Lining Ec Cone	CH660
1446	845.0030-00	Lock Nut	CH660
1447	847.0147-00	Washer	CH660
1448	840.0047-00	Screw	CH660
1449	891.0401-005	Rubber Plug	CH660
1450	442.8853-01	Bracket	CH660
1451	442.5621-90	Feed Distributor Left	CH660
1452	442.5621-00	Feed Distributor Right	CH660
1453	840.0065-00	Screw	CH660
1454	847.0016-00	Washer	CH660
1455	845.0009-00	Nut	CH660
1456	442.8642-00	Over Pressure Unit	CH660
1457	442.8642-90	Over Pressure Unit For Compressed Air	CH660
1458	900.1424-00	Hose Coupling	CH660
1459	900.1358-00	Clips	CH660
1460	819.0187-00	Hose	CH660
1461	900.0040-00	Tee	CH660
1462	900.0365-00	Hexagon Nippel	CH660
1463	900.0022-00	Elbow	CH660
1464	900.1139-00	Clip Rsgu	CH660
1465	900.0005-00	Elbow	CH660
1466	442.9325-00	Over Pressure Fan	CH660
1467	912.0138-00	Air Filter Purolator	CH660
1468	900.0108-00	Wrought Iron Pipe Fittings	CH660
1469	900.0209-00	Plug	CH660
1470	900.0022-00	Elbow	CH660
1471	900.1139-00	Clip	CH660
1472	900.0005-00	Elbow	CH660
1473	900.0180-00	Nipple	CH660
1474	912.0113-00	Air Filter	CH660
1475	900.0169-00	Nipple	CH660
1476	902.0645-00	Regulator	CH660
1477	900.0182-00	Nipple	CH660
1478	900.0054-00	Tee	CH660
1479	900.0209-00	Plug	CH660
1480	923.0267-00	Pressure Gauge	CH660

1481	900.0172-00	Nipple	CH660
1482	879.0497-00	V-Belt Pulley	CH660
1483	869.0286-00	Bushing	CH660
1484	452.4718-901	Bushing	CH660
1485	857.0336-00	Key	CH660
1486	442.8788-01	Spacer	CH660
1487	442.8787-01	Washer	CH660
1488	847.0016-00	Washer	CH660
1489	840.0066-00	Screw	CH660
1490	879.0499-00	V-Belt Pulley	CH660
1491	857.0269-00	V-Belt	CH660
1492	869.0235-00	Bushing	CH660
1493	869.0286-00	Bushing	CH660
1494	869.0261-00	Bushing	CH660
1495	869.0278-00	Bushing	CH660
1496	869.0283-00	Bushing	CH660
1497	869.0295-00	Bushing	CH660
1498	879.0510-00	V-Belt Pulley	CH660
1499	869.0286-00	Bushing	CH660
1500	452.4718-901	Bushing	CH660
1501	857.0336-00	Key	CH660
1502	442.8788-01	Spacer	CH660
1503	442.8787-01	Washer	CH660
1504	847.0016-00	Washer	CH660
1505	840.0066-00	Screw	CH660
1506	879.0509-00	V-Belt Pulley	CH660
1507	875.0246-00	V-Belt	CH660
1508	869.0330-00	Bushing	CH660
1509	857.0356-00	Key	CH660
1510	442.8787-01	Washer	CH660
1511	847.0016-00	Washer	CH660
1512	840.0066-00	Screw	CH660
1513	879.0618-00	V-Belt Pulley	CH660
1514	452.4726-901	Bushing	CH660
1515	879.0626-00	V-Belt Pulley	CH660
1516	875.0331-00	V-Belt	CH660
1517	869.0330-00	Bushing	CH660
1518	869.0329-00	Bushing	CH660

1519	869.0339-00	Bushing	CH660
1520	869.0338-00	Bushing	CH660
1521	869.0333-00	Bushing	CH660
1522	442.8877-00	Tool Box Complete	CH660
1523	442.8879-00	Lifting Tool	CH660
1524	442.8880-00	Lifting Tool	CH660
1525	843.1511-00	Lowering Rod	CH660
1526	845.0012-00	Nut	CH660
1527	442.7284-00	Lowering Rod	CH660
1528	442.9996-00	Piston Stop Plate	CH660
1529	840.0542-00	Screw	CH660
1530	442.7282-01	Eye Bolt	CH660
1531	899.0157-00	Eye Bolt	CH660
1532	899.0160-00	Eye Bolt	CH660
1533	899.0147-00	Eye Bolt	CH660
1534	899.0155-00	Eye Bolt	CH660
1535	899.0244-00	Eye Bolt	CH660
1536	920.0110-00	Ring Spanner Striking	CH660
1537	920.0151-00	Ring Spanner Striking	CH660
1538	920.0131-00	U-Ring Spanner	CH660
1539	920.0135-00	U-Ring Spanner	CH660
1540	920.0134-00	U-Ring Spanner	CH660
1541	920.0022-00	U-Ring Spanner	CH660
1542	920.0245-00	U-Ring Spanner	CH660
1543	920.0186-00	U-Ring Spanner	CH660
1544	920.0041-00	Socket Screw Key	CH660
1545	920.0038-00	Socket Screw Key	CH660
1546	920.0037-00	Socket Screw Key	CH660
1547	920.0035-00	Socket Screw Key	CH660
1548	920.0032-00	Socket Screw Key	CH660
1549	442.0800-91	Chunk Of Lead	CH660
1550	923.0422-00	Feeler Gauge	CH660
1551	904.0585-00	Air Bleeder Hose	CH660
1552	126.0383-001	Risk Of Crushing	CH660
1553	126.0384-001	Warning Flying Fragments	CH660
1554	126.0385-001	Warning Sign Read Manual	CH660
1555	126.0445-001	Logotype Silver	CH660
1556	126.0416-001	Sign Product Name	CH660

1557	885.0250-00	Sign To Mark Centre Of Gravity	CH660
1558	126.5007-01	Identification Plate	CH660
1559	885.0267-00	Warning Sign Danger	CH660
1560	442.8762-01	Locating Bar	CH660
1561	442.8809-01	Shim	CH660
1562	442.8809-02	Shim	CH660
1563	442.8809-03	Shim	CH660
1564	442.8809-04	Shim	CH660
1565	841.0019-00	Screw	CH660
1566	442.8803-01	Gasket	CH660
1567	442.8803-02	Gasket	CH660
1568	442.8803-03	Gasket	CH660
1569	868.0799-00	Bearing	CH660
1570	868.0806-00	Bearing	CH660
1571	442.8771-01	Spacer	CH660
1572	873.0128-00	O-Ring	CH660
1573	873.1161-00	Sealing Ring	CH660
1574	442.8775-01	Gasket	CH660
1575	442.8774-01	Gasket	CH660
1576	442.8774-02	Gasket	CH660
1577	873.0385-00	Sealing Ring Tredo	CH660
1578	873.0108-00	O-Ring	CH660
1579	840.1075-00	Screw	CH660
1580	845.0284-00	Nut Lock	CH660
1581	442.7253-01	Sleeve	CH660
1582	442.7271-01	Washer	CH660
1583	863.0058-00	Disc Spring	CH660
1584	452.5227-001	Liner Narrow Arm	CH660
1585	452.5222-001	Liner Pinionshaft Arm	CH660
1586	891.1891-901	Wall Protection	CH660
1587	891.1893-901	Wall Protection	CH660
1588	891.1858-901	Wall Protection	CH660
1589	891.1860-901	Wall Protection	CH660
1590	891.1889-901	Wall Protection	CH660
1591	891.1856-901	Wall Protection	CH660
1592	891.2035-901	Bolt And Plug Set	CH660
1593	891.2035-902	Bolt And Plug Set	CH660
1594	847.0016-00	Washer	CH660

1595	840.0065-00	Screw	CH660
1596	873.0390-00	Seal Ring	CH660
1597	900.0659-00	Adpter	CH660
1598	452.4933-901	Liner Hydroset Cylinder Cover	CH660
1599	452.2899-001	Hose Sae	CH660
1600	452.4865-001	Hydroset Cylinder Cover	CH660
1601	452.4125-901	Bottomshell Assembly	CH660
1602	912.0126-00	Filter	CH660
1603	912.0129-00	Filter Cartridge	CH660
1604	912.0139-00	Filter Cartridge	CH660
1605	912.0155-00	Filter Cartridge	CH660
1606	BG00232521	Feed Hopper	CH550
1607	452.8155-901	Feed Hopper As.	CH550
1608	452.8154-901	Hopper, Feed Welded	CH550
1609	452.7771-901	Inspection Door	CH550
1610	452.7976-901	Locking Device	CH550
1611	452.7970-001	Plate, Angle Stop And Protect	CH550
1612	847.0016-00	Washer	CH550
1613	845.0215-00	Nut, Lock	CH550
1614	840.0068-00	Screw	CH550
1615	840.0070-00	Screw	CH550
1616	891.4227-901	Inspection Door	CH550
1617	891.4226-001	Inspection Door	CH550
1618	847.0147-00	Washer Round	CH550
1619	845.0030-00	Nut, Lock	CH550
1620	843.1517-00	Bolt	CH550
1621	891.0401-004	Plug, Rubber	CH550
1622	452.7771-901	Inspection Door Feed Hopper	CH550
1623	452.7725-001	Door Feed Hopper	CH550
1624	452.7951-001	Flange, Tube Door Feed Hopper	CH550
1625	452.7950-001	Pin, Dowel Door Feed Hopper	CH550
1626	847.0016-00	Washer	CH550
1627	840.0070-00	Screw	CH550
1628	452.7976-901	Locking Device Door Feed Hopper	CH550
1629	452.7950-001	Pin, Dowel Door Feed Hopper	CH550
1630	452.7860-001	Screw	CH550
1631	847.0016-00	Washer	CH550
1632	452.7951-00	Flange, Tube Door Feed Hopper	CH550

1633	853.0561-00	Pin, Spiral	CH550
1634	452.8420-901	Cone Ec Hardox	CH550
1635	452.8415-901	Cone C Hardox	CH550
1636	452.8417-901	Cone Mc Hardox	CH550
1637	452.8422-901	Cone Ec Rubber	CH550
1638	452.8416-901	Cone C Rubber	CH550
1639	452.8418-901	Cone Mc Rubber	CH550
1640	452.8420-901	Cone Ec Hardox Kit	CH550
1641	452.7604-901	Liner Bracket Ec Cone	CH550
1642	452.8308-901	Liner Cone Ec Hardox Kit	CH550
1643	452.8415-901	Cone C Hardox Kit	CH550
1644	452.7890-901	Liner Bracket C Cone	CH550
1645	452.8311-901	Liner Cone C Hardox Kit	CH550
1646	452.8417-901	Cone Mc Hardox Kit	CH550
1647	452.7888-901	Liner Bracket Mc Cone	CH550
1648	452.8312-901	Liner Cone Mc Hardox Kit	CH550
1649	452.8308-901	Liner Cone Ec Hardox As.	CH550
1650	452.7412-001	Liner Cone Ec	CH550
1651	847.0147-00	Washer Round	CH550
1652	845.0030-00	Nut, Lock	CH550
1653	452.8311-901	Liner Cone C Hardox As.	CH550
1654	452.7413-001	Liner Cone	CH550
1655	847.0147-00	Washer Round	CH550
1656	845.0030-00	Nut, Lock	CH550
1657	452.8312-901	Liner Cone Mc Hardox As.	CH550
1658	452.7402-001	Liner Cone Mc	CH550
1659	847.0147-00	Washer Round	CH550
1660	845.0030-00	Nut, Lock	CH550
1661	452.8422-901	Cone Ec Rubber Kit	CH550
1662	452.7604-901	Liner Bracket Ec Cone	CH550
1663	891.4234-901	Liner Cone Ec Kit	CH550
1664	452.8416-901	Cone C Rubber Kit	CH550
1665	452.7890-901	Liner Bracket C Cone	CH550
1666	891.4233-901	Liner Cone C Kit	CH550
1667	452.8418-901	Cone Mc Rubber Kit	CH550
1668	452.7888-901	Liner Bracket Mc Cone	CH550
1669	891.4237-901	Liner Cone Mc Kit	CH550
1670	891.4234-901	Liner Cone Ec Rubber As.	CH550

1671	891.4235-901	Liner Cone Ec	CH550
1672	847.0147-00	Washer Round	CH550
1673	845.0030-00	Lock Nut M	CH550
1674	840.0047-00	Screw	CH550
1675	891.0401-004	Rubber Plug	CH550
1676	891.4233-901	Liner Cone C Rubber As.	CH550
1677	891.4232-901	Liner Cone C	CH550
1678	847.0147-00	Washer Round	CH550
1679	845.0030-00	Lock Nut	CH550
1680	840.0047-00	Screw	CH550
1681	891.0401-004	Rubber Plug	CH550
1682	891.4237-901	Liner Cone Mc Rubber As.	CH550
1683	891.4236-901	Liner Cone Mc	CH550
1684	847.0147-00	Washer Round	CH550
1685	845.0030-00	Lock Nut	CH550
1686	840.0047-00	Screw M	CH550
1687	891.0401-004	Rubber Plug & Oslash;	CH550
1688	452.8412-901	Wear Elements Upper Right	CH550
1689	452.7855-901	Attachment Upper As. Left	CH550
1690	891.4231-901	Hopper Lining As.	CH550
1691	452.8413-901	Wear Elements Upper Left	CH550
1692	452.7859-901	Attachment Upper As. Right	CH550
1693	891.4231-901	Hopper Lining As.	CH550
1694	840.0068-00	Screw	CH550
1695	847.0376-00	Washer	CH550
1696	891.4231-901	Hopper Lining	CH550
1697	891.4231-001	Hopper Lining	CH550
1698	843.1323-00	Bolt	CH550
1699	891.0462-001	Washer, Square	CH550
1700	845.0030-00	Nut, Lock	CH550
1701	847.0147-00	Washer Round	CH550
1702	891.0401-004	Rubber Plug	CH550
1703	BG00212941	Distributor Kit	CH550
1704	452.7958-901	Cover And Splitter Kit	CH550
1705	BG00212941	Distributor Kit	CH550
1706	BG00214755	Plate, Flanged Left	CH550
1707	BG00216301	Plate, Flanged Right	CH550
1708	BG00214791	Bracket	CH550

1709	BG00214868	Bracket, Attachment Left	CH550
1710	BG00215231	Bracket, Attachment Right	CH550
1711	442.7267-00	Distributor, Feed Right	CH550
1712	442.7267-90	Distributor, Feed Left	CH550
1713	840.0071-00	Screw	CH550
1714	840.0069-00	Screw	CH550
1715	847.0060-00	Washer	CH550
1716	845.0215-00	Nut, Lock	CH550
1717	840.0075-00	Screw	CH550
1718	847.0016-00	Washer	CH550
1719	847.0376-00	Washer	CH550
1720	452.7958-901	Cover And Splitter Kit	CH550
1721	452.7959-901	Cover Kit	CH550
1722	452.7983-901	Splitter Kit	CH550
1723	452.7959-901	Cover	CH550
1724	452.7961-901	Cover	CH550
1725	840.0068-00	Screw	CH550
1726	847.0016-00	Washer	CH550
1727	845.0009-00	Nut	CH550
1728	840.0070-00	Screw	CH550
1729	847.0376-00	Washer	CH550
1730	452.7983-901	Splitter	CH550
1731	452.7984-901	Adjusting Unit	CH550
1732	840.0650-00	Screw	CH550
1733	847.0359-00	Washer	CH550
1734	452.7998-001	Plate, Clamping	CH550
1735	452.8361-901	Topshell Assembly Excluding Concave	CH550
1736	290.0058-903	Connection Box	CH550
1737	452.7695-001	Steel Grease Pipe	CH550
1738	452.7696-001	Steel Air Pipe	CH550
1739	452.7697-001	Steel Sensor Pipe	CH550
1740	900.0431-00	Pipe Joint	CH550
1741	900.0654-00	Adapter	CH550
1742	900.0169-00	Hexagon Nipple	CH550
1743	900.3251-00	Bend	CH550
1744	912.0114-00	Filter Element	CH550
1745	912.0155-00	Filter Insert	CH550
1746	900.0425-00	Pipe Joint	CH550

1747	191.2376-00	Temperature Sensor	CH550
1748	900.2624-00	Nut	CH550
1749	914.0233-00	Lubrication Nipple	CH550
1750	BG00204330	Arm Shield	CH550
1751	452.8361-902	Topshell Assembly Including Concave	CH550
1752	290.0058-903	Connection Box	CH550
1753	452.7517-001	Wear Ring	CH550
1754	452.7547-001	Spider Bushing	CH550
1755	452.7519-001	Seal Ring	CH550
1756	452.7695-001	Steel Grease Pipe	CH550
1757	452.7696-001	Steel Air Pipe	CH550
1758	452.7697-001	Steel Sensor Pipe	CH550
1759	900.0431-00	Pipe Joint	CH550
1760	900.0654-00	Adapter	CH550
1761	900.0169-00	Hexagon Nipple	CH550
1762	900.3251-00	Bend	CH550
1763	912.0114-00	Filter Element	CH550
1764	912.0155-00	Filter Insert	CH550
1765	900.0425-00	Pipe Joint	CH550
1766	873.1585-00	O-Ring	CH550
1767	191.2376-00	Temperature Sensor	CH550
1768	900.2624-00	Nut	CH550
1769	914.0233-00	Lubrication Nipple	CH550
1770	BG00204330	Arm Shield	CH550
1771	847.0359-00	Washer	CH550
1772	840.0651-00	Screw	CH550
1773	452.8361-902	Topshell Assembly Including Concave	CH550
1774	452.7698-001	Spacer	CH550
1775	452.7700-001	Sleeve	CH550
1776	841.0641-00	Screw	CH550
1777	847.0016-00	Washer	CH550
1778	863.0058-00	Disc Spring	CH550
1779	845.0284-00	Lock Nut	CH550
1780	840.1297-00	Screw	CH550
1781	847.0251-00	Spherical Washer	CH550
1782	847.0252-00	Spherical Washer	CH550
1783	840.0069-00	Screw	CH550
1784	840.0712-00	Screw	CH550

1785	847.0162-00	Washer	CH550
1786	442.7179-01	Locating Block	CH550
1787	452.7534-901	Spider Cap	CH550
1788	840.0638-00	Screw	CH550
1789	847.0389-00	Spherical Washer	CH550
1790	BG00240402	Washer Plate Arm Shield	CH550
1791	442.9530-01	Screw	CH550
1792	899.0278-00	Protecting Cap	CH550
1793	845.0322-00	Nut	CH550
1794	847.0171-00	Washer	CH550
1795	840.1090-00	Screw	CH550
1796	452.7671-001	Ring	CH550
1797	873.1584-00	O-Ring	CH550
1798	840.0019-00	Screw	CH550
1799	863.0070-00	Spring, Disc	CH550
1800	840.0653-00	Screw	CH550
1801	847.0012-00	Washer	CH550
1802	847.0359-00	Washer	CH550
1803	452.7386-001	Filler Ring, F	CH550
1804	452.7388-001	Filler Ring, Mc	CH550
1805	BG00216572	Concave F	CH550
1806	BG00216573	Concave F	CH550
1807	BG00216574	Concave F	CH550
1808	BG00226991	Concave Mf	CH550
1809	BG00226992	Concave Mf	CH550
1810	BG00226993	Concave Mf	CH550
1811	BG00228529	Concave M	CH550
1812	BG00228530	Concave M	CH550
1813	BG00228531	Concave M	CH550
1814	452.8496-001	Concave Mc	CH550
1815	452.8496-002	Concave Mc	CH550
1816	452.8496-003	Concave Mc	CH550
1817	452.8500-001	Concave C	CH550
1818	452.8500-002	Concave C	CH550
1819	452.8500-003	Concave C	CH550
1820	452.7843-001	Concave Ec	CH550
1821	452.7843-002	Concave Ec	CH550
1822	452.7843-003	Concave Ec	CH550

1823	BG00204330	Arm Shield	CH550
1824	840.0638-00	Screw	CH550
1825	BG00240402	Washer Plate Arm Shield	CH550
1826	847.0389-00	Spherical Washer	CH550
1827	452.7534-901	Spider Cap	CH550
1828	840.1251-00	Screw	CH550
1829	900.1933-00	Plug	CH550
1830	452.8366-901	Mainshaft Assembly Excluding Mantle	CH550
1831	452.7443-001	Inner Head Nut	CH550
1832	853.0119-00	Pin	CH550
1833	452.7542-001	Mainshaft Sleeve	CH550
1834	899.0299-00	Lifting Eyebolt	CH550
1835	452.8265-901	Transport Frame	CH550
1836	452.8366-902	Mainshaft Assembly Including Mantle	CH550
1837	452.7208-901	Head Nut W. Burning Ring As.	CH550
1838	452.7443-001	Inner Head Nut	CH550
1839	452.7329-001	Retaining Ring	CH550
1840	452.7538-001	Retainer	CH550
1841	452.7537-001	Scraper	CH550
1842	452.7685-001	Distance	CH550
1843	452.7531-001	Dust Seal Ring	CH550
1844	840.0068-00	Screw	CH550
1845	847.0016-00	Washer	CH550
1846	853.0119-00	Pin	CH550
1847	840.0045-00	Screw	CH550
1848	840.0052-00	Screw	CH550
1849	847.0147-00	Washer Round	CH550
1850	452.7542-001	Mainshaft Sleeve	CH550
1851	899.0299-00	Lifting Eyebolt	CH550
1852	452.8265-901	Transport Frame	CH550
1853	452.7208-901	Head Nut With Burning Ring	CH550
1854	452.7467-001	Burning Ring	CH550
1855	873.0720-00	Protection Plug	CH550
1856	452.7626-001	Mantle A	CH550
1857	452.7626-002	Mantle A	CH550
1858	452.7626-003	Mantle A	CH550
1859	452.7548-001	Mantle B	CH550
1860	452.7548-002	Mantle B	CH550

1861	452.7548-003	Mantle B	CH550
1862	BG00202524	Mantle Flexifeed B	CH550
1863	BG00134054	Mantle Flexifeed B	CH550
1864	BG00134055	Mantle Flexifeed B	CH550
1865	452.7191-901	Dust Collar Ar. Kit	CH550
1866	452.7313-001	Dust Collar	CH550
1867	452.7295-001	Locating Bar	CH550
1868	452.7612-001	Seal Ring	CH550
1869	847.0012-00	Washer	CH550
1870	840.0025-00	Screw	CH550
1871	840.0070-00	Screw	CH550
1872	847.0016-00	Washer	CH550
1873	873.1583-00	O-Ring	CH550
1874	840.0634-00	Screw	CH550
1875	900.2673-00	Plug	CH550
1876	452.8342-901	Locating Bar Kit	CH550
1877	452.8342-901	Locating Bar Kit	CH550
1878	847.0012-00	Washer	CH550
1879	840.0025-00	Screw	CH550
1880	452.7295-001	Bar, Locating	CH550
1881	452.7712-001	Shim	CH550
1882	452.7712-002	Shim	CH550
1883	452.7712-003	Shim	CH550
1884	452.7712-004	Shim	CH550
1885	452.8348-901	Eccentric After Market Assembly	CH550
1886	452.7268-001	Eccentric	CH550
1887	853.0617-00	Pin, Spiral	CH550
1888	452.7251-001	Eccentric Bushing	CH550
1889	452.7328-001	Key	CH550
1890	452.7273-001	Hub	CH550
1891	452.7271-001	Counterweight	CH550
1892	847.0132-00	Washer Round	CH550
1893	840.0658-00	Screw	CH550
1894	840.0650-00	Screw	CH550
1895	841.0026-00	Screw	CH550
1896	847.0147-00	Washer Round	CH550
1897	452.7203-901	Gear And Pinion Set	CH550
1898	841.0268-00	Screw	CH550

1899	BG00203182	Retainer Eccentric	CH550
1900	847.0012-00	Washer	CH550
1901	840.0025-00	Screw	CH550
1902	452.8348-902	Eccentric After Market Assembly	CH550
1903	452.7268-001	Eccentric	CH550
1904	853.0617-00	Pin, Spiral	CH550
1905	452.7250-001	Eccentric Bushing, Throw	CH550
1906	452.7328-001	Key	CH550
1907	452.7273-001	Hub	CH550
1908	452.7271-001	Counterweight	CH550
1909	847.0132-00	Washer Round	CH550
1910	840.0658-00	Screw	CH550
1911	840.0650-00	Screw	CH550
1912	841.0026-00	Screw	CH550
1913	847.0147-00	Washer Round	CH550
1914	452.7203-901	Gear And Pinion Set	CH550
1915	841.0268-00	Screw	CH550
1916	BG00203182	Retainer Eccentric	CH550
1917	847.0012-00	Washer	CH550
1918	840.0025-00	Screw	CH550
1919	452.8348-903	Eccentric After Market Assembly	CH550
1920	452.7268-001	Eccentric	CH550
1921	853.0617-00	Pin, Spiral	CH550
1922	452.7248-001	Eccentric Bushing, Throw	CH550
1923	452.7328-001	Key	CH550
1924	452.7273-001	Hub	CH550
1925	452.7271-001	Counterweight	CH550
1926	847.0132-00	Washer Round	CH550
1927	840.0658-00	Screw	CH550
1928	840.0650-00	Screw	CH550
1929	841.0026-00	Screw	CH550
1930	847.0147-00	Washer Round	CH550
1931	452.7203-901	Gear And Pinion Set	CH550
1932	841.0268-00	Screw	CH550
1933	BG00203182	Retainer Eccentric	CH550
1934	847.0012-00	Washer	CH550
1935	840.0025-00	Screw	CH550
1936	452.7248-001	Eccentric Bushing	CH550

1937	452.7250-001	Eccentric Bushing Throw	CH550
1938	452.7251-001	Eccentric Bushing Throw	CH550
1939	452.7203-901	Gear And Pinion Set As.	CH550
1940	452.8354-901	Bottomshell Assembly With Hardox	CH550
1941	452.7738-901	Arm Liners	CH550
1942	BG00178625	Overpressure Installation	CH550
1943	452.7406-001	Foot	CH550
1944	847.0124-00	Washer	CH550
1945	840.0671-00	Screw	CH550
1946	842.0288-00	Screw	CH550
1947	853.0617-00	Pin, Spiral	CH550
1948	891.4075-901	Door, Inspection Pu	CH550
1949	452.7746-001	Dolly	CH550
1950	841.0269-00	Screw	CH550
1951	900.2199-00	Flange	CH550
1952	442.9396-00	Bend	CH550
1953	873.0129-00	O-Ring	CH550
1954	840.0070-00	Screw	CH550
1955	847.0016-00	Washer	CH550
1956	452.8163-901	Transport Frame	CH550
1957	873.0615-00	O-Ring	CH550
1958	452.8354-902	Bottomshell Assembly With Rubber	CH550
1959	452.7738-901	Arm Liners	CH550
1960	BG00178625	Overpressure Installation	CH550
1961	452.7406-001	Foot	CH550
1962	847.0124-00	Washer	CH550
1963	840.0671-00	Screw	CH550
1964	842.0288-00	Screw	CH550
1965	853.0617-00	Pin, Spiral	CH550
1966	891.4075-901	Inspection Door Pu	CH550
1967	452.7746-001	Dolly	CH550
1968	841.0269-00	Screw	CH550
1969	900.2199-00	Flange Half	CH550
1970	442.9396-00	Bend	CH550
1971	873.0129-00	O-Ring	CH550
1972	840.0070-00	Screw	CH550
1973	847.0016-00	Washer	CH550
1974	452.8163-901	Transport Frame	CH550

1975	873.0615-00	O-Ring	CH550
1976	452.7738-901	Arm Liners Bottomshell	CH550
1977	452.7076-001	Arm Liner Pinionshaft	CH550
1978	452.7077-001	Arm Liners	CH550
1979	452.7603-001	Plate, Washer	CH550
1980	845.0455-00	Nut	CH550
1981	840.1299-00	Screw	CH550
1982	452.7693-001	Shim Arm Liner Bottom	CH550
1983	891.2879-001	Plate, Washer	CH550
1984	891.2880-001	Washer, Rubber	CH550
1985	BG00174603	Liner Bottomshell Hardox As.	CH550
1986	BG00162786	Liner Bottomshell, First Plain	CH550
1987	BG00167315	Liner Bottomshell, First Hole	CH550
1988	BG00162736	Liner Bottomshell, Second	CH550
1989	843.1616-00	Bolt	CH550
1990	891.2880-001	Washer, Rubber	CH550
1991	891.2879-001	Plate, Washer	CH550
1992	845.0030-00	Nut Lock	CH550
1993	891.2850-901	Liner Bottomshell Rubber As.	CH550
1994	891.2845-901	Rubber Lining	CH550
1995	891.2846-901	Rubber Lining	CH550
1996	891.2847-901	Rubber Lining	CH550
1997	843.1616-00	Bolt	CH550
1998	891.0401-004	Rubber Plug	CH550
1999	891.2879-001	Washer Plate	CH550
2000	845.0030-00	Lock Nut	CH550
2001	891.2880-001	Rubber Washer	CH550
2002	891.4075-901	Inspection Door	CH550
2003	891.2447-901	Inspection Door Pu	CH550
2004	891.4074-001	Screw	CH550
2005	BG00178625	Overpressure Installations	CH550
2006	BG00175086	Over-Pressure Air Line	CH550
2007	BG00213134	Air End Riser	CH550
2008	BG00219282	Air Bracket	CH550
2009	847.0164-00	Washer	CH550
2010	900.3079-00	Clamp	CH550
2011	900.2118-00	Plate	CH550
2012	847.0147-00	Washer Round	CH550

2013	840.0044-00	Screw	CH550
2014	840.0016-00	Screw	CH550
2015	900.3235-00	Stud Elbow	CH550
2016	900.0778-00	Ring, Clamping	CH550
2017	900.3233-00	Stud Elbow	CH550
2018	900.3232-00	Nut Cutting Ring	CH550
2019	900.3236-00	Plug Plastic	CH550
2020	900.3238-00	Stud Elbow	CH550
2021	900.3234-00	Stud	CH550
2022	452.7188-901	Hydroset Cylinder Ar.	CH550
2023	452.7286-001	Hydroset Cylinder	CH550
2024	853.0617-00	Pin, Spiral	CH550
2025	452.7405-901	Piston	CH550
2026	452.7318-001	Hydroset Cylinder Cover	CH550
2027	873.1576-00	O-Ring	CH550
2028	452.6139-001	Flange Measure System	CH550
2029	873.0237-00	O-Ring	CH550
2030	847.0016-00	Washer	CH550
2031	840.0069-00	Screw	CH550
2032	847.0124-00	Washer	CH550
2033	840.0673-00	Screw	CH550
2034	873.1577-00	O-Ring	CH550
2035	900.2292-00	Nipple	CH550
2036	984.0391-00	Position Sensor	CH550
2037	841.0628-00	Screw	CH550
2038	452.7433-001	Cover, Protecting	CH550
2039	847.0147-00	Washer Round	CH550
2040	840.0044-00	Screw	CH550
2041	BG00213705	Protection Kit	CH550
2042	BG00215156	Step Bearing Set	CH550
2043	452.7405-901	Piston	CH550
2044	452.7296-001	Piston	CH550
2045	452.7321-001	Seal, Piston Chevron Packing	CH550
2046	452.7322-001	Packing Clamping Plate	CH550
2047	841.0266-00	Screw	CH550
2048	452.7324-901	Measuring Tube Holder	CH550
2049	853.0119-00	Pin	CH550
2050	452.8371-901	Repair Kit Chevron Packing	CH550

2051	BG00213705	Protection Kit	CH550
2052	BG00213709	Support	CH550
2053	BG00213714	Rubber, Wear	CH550
2054	BG00213712	Rubber, Wear	CH550
2055	BG00213711	Retainer	CH550
2056	840.0047-00	Screw	CH550
2057	847.0147-00	Washer Round	CH550
2058	845.0030-00	Nut, Lock	CH550
2059	840.0045-00	Screw	CH550
2060	452.7324-901	Measuring Tube Holder Kit	CH550
2061	452.7325-001	Measuring Tube Holder	CH550
2062	452.7326-001	Nut, Lock	CH550
2063	873.1575-00	O-Ring	CH550
2064	873.0388-00	Rin	CH550
2065	442.7559-04	Measuring Tube	CH550
2066	452.8371-901	Repair Kit Chevron Packing	CH550
2067	452.7321-001	Seal, Piston Chevron Packing	CH550
2068	841.0266-00	Screw	CH550
2069	452.7322-001	Packing Clamping Plate	CH550
2070	873.0237-00	O-Ring	CH550
2071	873.1577-00	O-Ring	CH550
2072	873.1576-00	O-Ring	CH550
2073	452.7192-901	Hydroset System Ar.	CH550
2074	452.7669-001	Hose	CH550
2075	452.7192-901	Hydroset System Ar.	CH550
2076	452.7533-001	Manifold, Connection	CH550
2077	847.0147-00	Washer Round	CH550
2078	900.2302-00	Plug	CH550
2079	900.2592-00	Flange	CH550
2080	841.0268-00	Screw	CH550
2081	840.1215-00	Screw	CH550
2082	873.0755-00	O-Ring	CH550
2083	452.7192-901	Hydroset System	CH550
2084	452.7351-001	Bracket Pressure Relief Valve	CH550
2085	900.2592-00	Flange	CH550
2086	841.0268-00	Screw	CH550
2087	873.0755-00	O-Ring	CH550
2088	847.0016-00	Washer	CH550

2089	840.0068-00	Screw	CH550
2090	923.0567-00	Sensor, Temperature	CH550
2091	984.1678-00	Transmitter, Pressure	CH550
2092	902.1171-00	Valve, Pressure Relief	CH550
2093	452.7403-901	Valve, Pressure Relief Assembly	CH550
2094	873.1299-00	O-Ring	CH550
2095	900.2385-00	Flange Half	CH550
2096	841.0253-00	Screw	CH550
2097	452.7403-901	Pressure Relief Valve As.	CH550
2098	452.7409-001	Hydraulic Manifold	CH550
2099	452.7416-001	Hydraulic Manifold Control Cover	CH550
2100	900.2279-00	Plug	CH550
2101	847.0132-00	Washer Round	CH550
2102	841.0041-00	Screw	CH550
2103	900.2292-00	Nipple, Measuring	CH550
2104	900.2859-00	Plug	CH550
2105	902.1143-00	Valve, Needle	CH550
2106	452.7403-901	Pressure Relief Valve As.	CH550
2107	900.2279-00	Plug	CH550
2108	900.3230-00	Threaded Orifice	CH550
2109	900.2859-00	Plug	CH550
2110	902.1173-00	Logic Element	CH550
2111	902.1174-00	Spring	CH550
2112	873.1581-00	Square Ring	CH550
2113	873.1582-00	Square Ring	CH550
2114	452.7428-001	Plate, Protecting	CH550
2115	847.0147-00	Washer Round	CH550
2116	841.0266-00	Screw	CH550
2117	452.7535-001	Plate, Protecting	CH550
2118	452.7427-001	Cover, Protecting	CH550
2119	452.7403-901	Pressure Relief Valve As.	CH550
2120	964.3173-00	Bulkhead, Cap Bottom	CH550
2121	964.3256-00	Insert, Pin	CH550
2122	964.3234-00	Cable, Cap, Top	CH550
2123	964.3257-00	Cage Insert	CH550
2124	964.2445-00	Gland	CH550
2125	984.1683-00	Cartridge Heater	CH550
2126	899.0147-00	Eye Bolt	CH550

2127	847.0016-00	Washer	CH550
2128	845.0454-00	Nut, Lock	CH550
2129	843.0873-00	Screw	CH550
2130	452.8372-901	Pinionshaft Housing	CH550
2131	452.7169-001	Pinionshaft Housing Machining	CH550
2132	452.6990-001	Pinionshaft	CH550
2133	900.0022-00	Elbow	CH550
2134	900.0840-00	Plug	CH550
2135	853.0590-00	Pin, Spiral	CH550
2136	840.1289-00	Screw	CH550
2137	845.0009-00	Nut	CH550
2138	452.8372-901	Pinionshaft Housing	CH550
2139	452.6964-001	Bearing Cover Outer	CH550
2140	452.6991-001	Bearing Cover Inner	CH550
2141	452.7005-001	Spacer Outer	CH550
2142	452.7178-001	Spacer Inner	CH550
2143	452.7091-001	Distance	CH550
2144	442.7577-01	Plug, Oil Level	CH550
2145	442.7578-01	Pipe	CH550
2146	868.0282-00	Roller Bearing	CH550
2147	868.0804-00	Roller Bearing	CH550
2148	873.1573-00	Ring, Seal	CH550
2149	873.1574-00	Ring, Seal	CH550
2150	855.0052-00	Retaining Ring	CH550
2151	855.0108-00	Retaining Ring	CH550
2152	857.0059-00	Key	CH550
2153	857.0336-00	Key	CH550
2154	873.1569-00	O-Ring	CH550
2155	873.1570-00	O-Ring	CH550
2156	873.0108-00	O-Ring	CH550
2157	914.0090-00	Nipple, Lubrication	CH550
2158	900.2859-00	Plug	CH550
2159	900.2026-00	Plug	CH550
2160	873.0385-00	Ring, Seal	CH550
2161	840.0045-00	Screw	CH550
2162	840.0068-00	Screw	CH550
2163	847.0147-00	Washer Round	CH550
2164	847.0016-00	Washer	CH550

2165	873.1317-00	O-Ring	CH550
2166	452.8373-901	Pinionshaft Housing Repair Kit	CH550
2167	452.8373-901	Pinionshaft Housing Repair Kit	CH550
2168	855.0108-00	Retaining Ring	CH550
2169	868.0282-00	Roller Bearing	CH550
2170	868.0804-00	Roller Bearing	CH550
2171	873.1573-00	Ring, Seal	CH550
2172	873.1574-00	Ring, Seal	CH550
2173	873.1569-00	O-Ring	CH550
2174	873.1570-00	O-Ring	CH550
2175	452.7115-001	Gasket 0,5Mm	CH550
2176	452.7114-001	Shim 0,2Mm	CH550
2177	452.7178-001	Spacer Inner	CH550
2178	452.7005-001	Spacer Outer	CH550
2179	873.0385-00	Ring, Seal	CH550
2180	BG00174086	Drive, V-Belt, Subframe	CH550
2181	BG00208755	Drive Cover	CH550
2182	452.7732-001	Cover, Sensor	CH550
2183	936.0072-00	Bracket, Motor	CH550
2184	452.4582-901	Damper, Vibration Large	CH550
2185	452.8325-901	Rubber Damper Medium	CH550
2186	984.1684-00	Sensor, Inductive	CH550
2187	960.0794-00	Cable	CH550
2188	873.0718-00	Strip	CH550
2189	847.0066-00	Washer	CH550
2190	845.0284-00	Nut, Lock	CH550
2191	840.0696-00	Screw	CH550
2192	840.0692-00	Screw	CH550
2193	847.0360-00	Washer	CH550
2194	845.0216-00	Nut, Lock	CH550
2195	840.0675-00	Screw	CH550
2196	847.0063-00	Washer	CH550
2197	BG00212356	Dust Shield Subframe Kit	CH550
2198	BG00212360	Dust Shield Subframe Kit	CH550
2199	BG00247857	Distance	CH550
2200	BG00174086	Drive, V-Belt, Subframe	CH550
2201	BG00194719	Plate Engine	CH550
2202	845.0284-00	Nut, Lock	CH550

2203	847.0066-00	Washer	CH550
2204	840.0692-00	Screw	CH550
2205	899.0526-00	Bracket, Lifting	CH550
2206	BG00208755	Drive, Cover	CH550
2207	BG00208737	Protection Hood Drive Cover	CH550
2208	BG00208717	Sump Drive Cover	CH550
2209	BG00208735	Console Drive Cover	CH550
2210	BG00208727	Wall Drive Cover	CH550
2211	BG00208726	Hook Wall	CH550
2212	840.1303-00	Screw	CH550
2213	BG00208723	Cover Plate Shaft Protection	CH550
2214	873.1623-00	Profile, Rubber	CH550
2215	972.1663-00	Motor	CH550
2216	972.1664-00	Motor	CH550
2217	972.1665-00	Motor	CH550
2218	972.1666-00	Motor	CH550
2219	972.1667-00	Motor	CH550
2220	972.1668-00	Motor	CH550
2221	972.1669-00	Motor	CH550
2222	936.0072-00	Bracket, Motor	CH550
2223	936.0073-00	Gemex Cylinder	CH550
2224	936.0074-00	Expander Dowel Complete	CH550
2225	936.0075-00	Hydraulic Hose Set	CH550
2226	936.0076-00	Bearing	CH550
2227	936.0077-00	Axial Bearing	CH550
2228	936.0078-00	Gasket Set	CH550
2229	452.7665-901	Drive, V-Belt	CH550
2230	452.7667-901	Drive, V-Belt	CH550
2231	452.7665-901	Drive, V-Belt	CH550
2232	452.7078-001	Pulley, V Belt	CH550
2233	869.0235-00	Bushing	CH550
2234	442.7238-01	Washer	CH550
2235	847.0016-00	Washer	CH550
2236	840.0068-00	Screw	CH550
2237	875.0245-00	Belt, V	CH550
2238	452.7117-001	Pulley, V Belt	CH550
2239	841.0574-00	Screw	CH550
2240	452.7666-901	Drive, V-Belt	CH550

2241	452.7078-001	Pulley, V Belt	CH550
2242	869.0235-00	Bushing	CH550
2243	442.7238-01	Washer	CH550
2244	847.0016-00	Washer	CH550
2245	840.0068-00	Screw	CH550
2246	875.0245-00	Belt, V Spc	CH550
2247	452.7120-001	Pulley, V Belt	CH550
2248	841.0574-00	Screw	CH550
2249	452.7667-901	Drive, V-Belt	CH550
2250	452.7223-001	Pulley, V Belt	CH550
2251	869.0235-00	Bushing	CH550
2252	442.7238-01	Washer	CH550
2253	847.0016-00	Washer	CH550
2254	840.0068-00	Screw	CH550
2255	875.0175-00	Belt, V	CH550
2256	452.7148-001	Pulley	CH550
2257	841.0574-00	Screw	CH550
2258	452.4582-901	Damper, Vibration, Large	CH550
2259	442.5904-01	Plate	CH550
2260	864.0066-00	Damper, Vibration	CH550
2261	840.1135-00	Screw	CH550
2262	847.0132-00	Washer Round	CH550
2263	840.0078-00	Screw	CH550
2264	845.0203-00	Nut, Lock	CH550
2265	452.8325-901	Damper, Vibration, Medium	CH550
2266	864.0124-00	Damper, Vibration	CH550
2267	452.8324-001	Plate, Mounting	CH550
2268	847.0016-00	Washer	CH550
2269	845.0215-00	Nut, Lock	CH550
2270	840.0066-00	Screw	CH550
2271	840.0069-00	Screw	CH550
2272	452.7896-901	Direct Drive, Subframe	CH550
2273	452.4582-901	Damper, Vibration Large	CH550
2274	452.8325-901	Rubber Damper Medium	CH550
2275	452.8317-901	Drive Cover	CH550
2276	BG00223922	Cover, Sensor Direct Drive	CH550
2277	BG00223866	Plate Sensor	CH550
2278	873.0718-00	Strip	CH550

2279	930.0399-00	Coupling	CH550
2280	984.1684-00	Sensor, Inductive	CH550
2281	960.0794-00	Cable M12 Connector	CH550
2282	BG00212356	Dust Shield Subframe Kit	CH550
2283	BG00212360	Dust Shield Subframe Kit	CH550
2284	847.0164-00	Washer	CH550
2285	840.0010-00	Screw	CH550
2286	847.0360-00	Washer	CH550
2287	845.0216-00	Nut, Lock Low	CH550
2288	840.0674-00	Screw	CH550
2289	847.0066-00	Washer	CH550
2290	845.0284-00	Nut, Lock	CH550
2291	840.0696-00	Screw	CH550
2292	452.7896-901	Drive, V-Belt, Subframe	CH550
2293	899.0526-00	Bracket, Lifting	CH550
2294	840.0671-00	Screw	CH550
2295	847.0360-00	Washer	CH550
2296	845.0012-00	Nut	CH550
2297	452.7819-001	Plate For Engine Placement	CH550
2298	452.8317-901	Drive, Cover	CH550
2299	BG00212174	Cover Bottom Direct Drive	CH550
2300	BG00212176	Cover Top Direct Drive	CH550
2301	845.0213-00	Nut, Lock	CH550
2302	840.0035-00	Screw	CH550
2303	847.0337-00	Washer	CH550
2304	930.0399-00	Coupling	CH550
2305	930.0404-00	Hub	CH550
2306	930.0405-00	Flexibelt Element	CH550
2307	452.8374-901	Rubber Damper	CH550
2308	452.8370-901	Rubber Damper Large Single	CH550
2309	452.8370-901	Rubber Damper Large Single	CH550
2310	452.8368-001	Plate, Top	CH550
2311	442.5904-01	Plate	CH550
2312	864.0066-00	Damper, Vibration	CH550
2313	847.0132-00	Washer Round	CH550
2314	840.1169-00	Screw	CH550
2315	847.0066-00	Washer	CH550
2316	845.0284-00	Nut, Lock	CH550

2317	452.7852-901	Sign Board	CH550
2318	126.0383-001	Sign, Warning Risk Of Crushing	CH550
2319	126.0385-001	Decal Read Manual	CH550
2320	126.5007-01	Plate, Identification	CH550
2321	885.0249-00	Sign Centre Of Gravity	CH550
2322	885.0267-00	Sign, Warning Danger	CH550
2323	126.0384-001	Sign, Warning Flying Fragments	CH550
2324	126.0345-001	Patent Information Sign	CH550
2325	885.0262-00	Plate, Lifting Chain	CH550
2326	126.0447-001	Logotype Sandvik	CH550
2327	126.0817-001	Sign Product Name	CH550
2328	126.0818-001	Sign Rotation Direction	CH550
2329	452.7906-901	Tool Kit	CH550
2330	442.9476-00	Tool Box	CH550
2331	452.7728-901	Piston Retainer	CH550
2332	843.1333-00	Stud	CH550
2333	847.0360-00	Washer	CH550
2334	845.0012-00	Nut	CH550
2335	899.0523-00	Eye Bolt	CH550
2336	899.0509-00	Eye Bolt	CH550
2337	899.0508-00	Eye Bolt	CH550
2338	899.0507-00	Eye Bolt	CH550
2339	899.0512-00	Eye Bolt	CH550
2340	920.0110-00	Tool Slugging Wrench	CH550
2341	920.0109-00	Tool Slugging Wrench	CH550
2342	920.0238-00	Tool Slugging Wrench	CH550
2343	442.0800-90	Cylinder, Lead	CH550
2344	923.0422-00	Feeler Gauge	CH550
2345	904.0585-00	Air Bleeder Hose	CH550
2346	452.7543-001	Mainshaft Sleeve Top	CH550
2347	BG00227711	Lifting Tool, Step Bearing	CH550
2348	BG00227710	Lifting Tool. Bottom Shell Bushing	CH550
2349	BG00227709	Lifting Tool. Eccentric Bushing	CH550
2350	452.7712-001	Shim	CH550
2351	452.7712-002	Shim	CH550
2352	452.7712-003	Shim	CH550
2353	452.7712-004	Shim	CH550
2354	841.0503-00	Screw	CH550

2355	847.0415-00	Washer	CH550
2356	847.0416-00	Washer	CH550
2357	841.0041-00	Screw	CH550
2358	452.0697-901	Bottom Shell Assembly	CH870
2359	452.0998-901	Dust Collar Assembly	CH870
2360	452.0809-901	Eccentric Assembly	CH870
2361	452.0953-901	Hydroset Cylinder Assembly	CH870
2362	452.0656-901	Pinion Shaft Housing Assembly	CH870
2363	452.0917-901	Main Shaft Assembly	CH870
2364	452.0684-901	Top Shell Assembly	CH870
2365	452.0760-00	Feed Hopper	CH870
2366	452.1488-901	Hydroset Security Valve Assembly	CH870
2367	452.1158-901	Hoses And Protections Of Crusher	CH870
2368	452.0675-001	Bottom Shell	CH870
2369	452.1980-901	Foot Alt	CH870
2370	840.0693-00	Screw	CH870
2371	847.0125-00	Washer	CH870
2372	442.7907-01	Boss	CH870
2373	442.7201-00	Cover	CH870
2374	843.1578-00	Stud Weld	CH870
2375	847.0147-00	Washer	CH870
2376	845.0030-00	Lock Nut	CH870
2377	452.1066-901	Liner-Pin Shaft Arm	CH870
2378	452.1065-901	Liner-Narrow Arm	CH870
2379	442.9396-00	Bend	CH870
2380	900.2199-00	Flange	CH870
2381	840.0068-00	Screw	CH870
2382	847.0016-00	Washer	CH870
2383	873.0129-00	O-Ring	CH870
2384	452.0795-001	Bottom Shell Bushing	CH870
2385	853.0464-00	Pin	CH870
2386	900.2127-00	Swivel Run	CH870
2387	900.0655-00	Adapter	CH870
2388	900.0276-00	Cover	CH870
2389	873.0385-00	Seal Ring	CH870
2390	452.1191.901	Wearing Paltes	CH870
2391	853.0464-00	Pin	CH870
2392	452.0808-001	Eccentric Wearing Plate	CH870

2393	853.0646-00	Pin	CH870
2394	452.1064-001	Foot	CH870
2395	452.0977-002	Foot For Subframe, Mirror - Inverted	CH870
2396	452.0977-001	Foot For Subframe	CH870
2397	452.1064-001	Foot	CH870
2398	452.1064-001	Foot	CH870
2399	452.0977-002	Foot For Subframe, Mirror - Inverted	CH870
2400	452.0977-001	Foot For Subframe	CH870
2401	452.1064-001	Foot	CH870
2402	452.0977-002	Foot For Subframe, Mirror - Inverted	CH870
2403	452.0977-001	Foot For Subframe	CH870
2404	452.1066-901	Pin Shaft Arm Liner	CH870
2405	452.1065-901	Narrow Arm Liner	CH870
2406	452.1191-901	Wearing Plates	CH870
2407	442.9650-00	Rubber Compression Mountings For	CH870
2408	864.0079-00	Damper	CH870
2409	840.1135-00	Screw	CH870
2410	847.0132-00	Washer	CH870
2411	442.5904-01	Fixing Plate	CH870
2412	442.9874-91	Rubber Compression Mountings For	CH870
2413	864.0066-00	Damper	CH870
2414	840.1135-00	Screw	CH870
2415	847.0132-00	Washer	CH870
2416	840.0078-00	Screw	CH870
2417	458.0553-00	Fixing Plate	CH870
2418	458.0554-01	Spacer	CH870
2419	847.0142-00	Washer	CH870
2420	845.0274-00	Lock Nut	CH870
2421	452.0540-001	Eccentric	CH870
2422	452.1184-901	Eccentric Bushing Alt	CH870
2423	452.0516-001	Hub	CH870
2424	452.0902-901	Ring	CH870
2425	840.0068-00	Screw	CH870
2426	847.0016-00	Washer	CH870
2427	442.9610-01	Key	CH870
2428	841.0535-00	Screw	CH870
2429	841.0548-00	Screw	CH870
2430	847.0181-00	Washer	CH870

2431	452.1185-901	Gear And Pinion Set	CH870
2432	452.1063-001	Key	CH870
2433	452.0530-901	Gear And Pinion Set	CH870
2434	452.0531-901	Gear And Pinion Set	CH870
2435	452.0970-001	Hydroset Cylinder	CH870
2436	840.1176-00	Screw	CH870
2437	847.0310-00	Washer	CH870
2438	452.0969-001	Hydroset Cylinder Bushing	CH870
2439	840.0032-00	Screw	CH870
2440	847.0144-00	Washer	CH870
2441	873.1247-00	O-Ring	CH870
2442	452.1048-901	Piston Assembly	CH870
2443	853.0119-00	Pin	CH870
2444	452.2630-901	Step Bearing Set	CH870
2445	452.0986-901	Chevron Packing	CH870
2446	452.0990-001	Packing Clamp Plate	CH870
2447	841.0267-00	Screw	CH870
2448	452.0972-001	Hydroset Cylinder Cover	CH870
2449	919.0190-00	Protection Plug	CH870
2450	900.2302-00	Plug	CH870
2451	841.0239-00	Screw	CH870
2452	840.1176-00	Screw	CH870
2453	847.0310-00	Washer	CH870
2454	873.1352-00	O-Ring	CH870
2455	873.1351-00	O-Ring	CH870
2456	984.0421-00	Position Sensor	CH870
2457	873.0111-00	O-Ring	CH870
2458	900.2302-00	Plug	CH870
2459	452.0657-001	Pinion Shaft Housing	CH870
2460	840.0672-00	Screw	CH870
2461	847.0063-00	Washer	CH870
2462	442.9362-01	Gasket	CH870
2463	442.9362-02	Gasket	CH870
2464	442.9362-03	Gasket	CH870
2465	868.0832-00	Bearing	CH870
2466	868.0832-00	Bearing	CH870
2467	845.0154-00	Locking Nut	CH870
2468	847.0299-00	Lock Washer	CH870

2469	442.9809-01	Wear Ring	CH870
2470	442.9808-01	Spacer	CH870
2471	442.9808-01	Spacer	CH870
2472	873.0136-00	O-Ring	CH870
2473	873-0136-00	O-Ring	CH870
2474	873.1219-00	O-Ring	CH870
2475	873.1219-00	O-Ring	CH870
2476	442.9260-01	Bearing Cover, Outer	CH870
2477	840.0046-00	Screw	CH870
2478	847.0147-00	Washer	CH870
2479	840.0078-00	Screw	CH870
2480	847.0132-00	Washer	CH870
2481	442.9365-01	Gasket	CH870
2482	442.9365-02	Gasket	CH870
2483	853.0590-00	Spring Pin	CH870
2484	452.0727-001	Pinion Shaft	CH870
2485	900.2388-00	Plug	CH870
2486	857.0360-00	Key	CH870
2487	857.0354-00	Key	CH870
2488	900.0022-00	Elbow	CH870
2489	842.0020-00	Screw	CH870
2490	900.0655-00	Adapter	CH870
2491	442.9346-01	Oil Level Gauge	CH870
2492	873.0387-00	Seal Ring	CH870
2493	900.0656-00	Straight Adapter	CH870
2494	873.0386-00	Seal	CH870
2495	855.0134-00	Retaining Ring	CH870
2496	840.1063-00	Screw	CH870
2497	845.0009-00	Nut	CH870
2498	452.1930-901	Main Shaft & Head Centre Assy	CH870
2499	452.0505-001	Main Shaft Sleeve	CH870
2500	853.0119-00	Pin	CH870
2501	855.0026-00	Retaining Ring	CH870
2502	452.0930-001	Inner Head Nut	CH870
2503	452.0938-001	Burning Ring	CH870
2504	452.0924-001	Dust Seal Ring	CH870
2505	452.0921-001	Retaining Ring	CH870
2506	442.9367-01	Retainer	CH870

2507	452.1264-001	Scraper	CH870
2508	840.0069-00	Screw	CH870
2509	840.0072-00	Screw	CH870
2510	847.0016-00	Washer	CH870
2511	452.1380-901	Mantle Alt.	CH870
2512	452.0936-901	Head Nut	CH870
2513	452.0872-001	Mantle B Pebbles	CH870
2514	452.0845-001	Mantle Ef	CH870
2515	452.0837-001	Mantle A	CH870
2516	452.2255-001	Concave C	CH870
2517	452.2253-001	Concave Mc	CH870
2518	452.1754-001	Concave M	CH870
2519	452.0842-001	Concave Mf	CH870
2520	452.0841-001	Concave F	CH870
2521	452.0840-001	Concave Ef	CH870
2522	452.0838-001	Concave Ec	CH870
2523	452.0664-001	Top Shell	CH870
2524	840.1124-00	Screw	CH870
2525	845.0322-00	Nut	CH870
2526	847.0171-00	Washer	CH870
2527	442.9979-01	Washer	CH870
2528	899.9278-00	Protective Cap	CH870
2529	442.9530-03	Screw	CH870
2530	899.0278-00	Protective Cap	CH870
2531	452.1060-001	Arm Shield	CH870
2532	914.0093-00	Lubrication Nipple	CH870
2533	900.0142-00	Pipe Bushing	CH870
2534	811.0202-00	Pipe	CH870
2535	900.0437-00	Compression Fittings	CH870
2536	452.0553-001	Spider Cap	CH870
2537	912.0114-00	Air Filter	CH870
2538	900.0169-00	Nipple	CH870
2539	900.0002-00	Elbow	CH870
2540	900.0139-00	Pipe Bushing	CH870
2541	808.0220-00	Steel Pipe	CH870
2542	900.0425-00	Compression Fittings	CH870
2543	808.0220-00	Steel Pipe	CH870
2544	873.1210-00	O-Ring	CH870

2545	840.0653-00	Screw	CH870
2546	847.0132-00	Washer	CH870
2547	452.1619-00	Spider Bushing	CH870
2548	191.2376-00	Temperature Sensor Trpf	CH870
2549	191.2365-00	Connection Box	CH870
2550	900.0139-00	Pipe Bushing	CH870
2551	900.0075-00	Elbow	CH870
2552	808.0220-00	Steel Pipe	CH870
2553	900.0425-00	Compression Fittings	CH870
2554	840.0652-00	Screw	CH870
2555	847.0132-00	Washer	CH870
2556	452.1599-001	Seal Ring	CH870
2557	452.1599-001	Seal Ring	CH870
2558	452.0550-001	Ring	CH870
2559	452.0549-00	Retaining Ring	CH870
2560	841.0225-00	Screw	CH870
2561	900.0981-00	Plug	CH870
2562	452.1373-901	Concave Alt	CH870
2563	873.1112-00	Sealing Compound	CH870
2564	452.1365-901	Filler Ring Alt.	CH870
2565	840.0675-00	Screw	CH870
2566	899.0293-00	Helicioil	CH870
2567	847.0063-00q	Washer	CH870
2568	891.1149-001	Rubber Washer	CH870
2569	452.2201.001	Jack Screw	CH870
2570	452.1369-901	Wearing Plate Assy	CH870
2571	840.1136-00	Screw	CH870
2572	845.0273-00	Lock Nut	CH870
2573	442.9353.01	Sleeve	CH870
2574	442.9354-01	Washer	CH870
2575	863.0015-00	Disc Spring	CH870
2576	452.0687-001	Support Ring	CH870
2577	442.8290-01	Dowel Pin	CH870
2578	452.2269-901	Filler Ring C	CH870
2579	452.0898-901	Filler Ring M	CH870
2580	452.0891-901	Filler Ring Ec	CH870
2581	452.2942-901	Cover	CH870
2582	452.2939-901	Splitter	CH870

2583	452.2938-901	Adjusting Unit	CH870
2584	452.2937-901	Distribution Box	CH870
2585	452.1447-001	Wear Plate	CH870
2586	840.1135-00	Screw	CH870
2587	847.0197-00	Washer	CH870
2588	452.2963-901	Clamping Plate	CH870
2589	845.0203-00	Nut Lock	CH870
2590	452.0802-901	Feed Hopper, Upper	CH870
2591	442.9747-01	Rubber Segment, Plain Section	CH870
2592	442.9751-02	Rubber Segment, R Level Sensor	CH870
2593	442.9751-01	Rubber Segment, L Level Sensor	CH870
2594	442.9750-01	Rubber Segment, Inspection Door	CH870
2595	840.0067-00	Screw	CH870
2596	847.0016-00	Washer	CH870
2597	845.0215-00	Lock Nut	CH870
2598	840.0070-00	Screw	CH870
2599	873.1287-00	Rubber Plug	CH870
2600	452.0799-901	Feed Hopper, Lower	CH870
2601	452.0792-901	Segment Support	CH870
2602	452.2333-901	Segment Support	CH870
2603	452.2348-901	Segment Support	CH870
2604	840.0069-00	Screw	CH870
2605	847.0016-00	Washer	CH870
2606	845.0215-00	Lock Nut	CH870
2607	840.0634-00	Screw	CH870
2608	452.1137-001	Rubber Segment	CH870
2609	452.2340-901	Rubber Segment	CH870
2610	452.2353-001	Rubber Segment	CH870
2611	873.1287-00	Rubber Plug	CH870
2612	840.0069-00	Screw	CH870
2613	847.0016-00	Washer	CH870
2614	845.0215-00	Lock Nut	CH870
2615	902.0850-00	Main Valve	CH870
2616	902.0852-90	Pilot Valve	CH870
2617	452.0978-001	Block	CH870
2618	900.2291-00	Reducing Thread Adapter	CH870
2619	900.2292-00	Measuring Nipple	CH870
2620	900.0647-00	Adapter	CH870

2621	873.0384-00	Seal	CH870
2622	902.0851-90	Pilot Valve Block	CH870
2623	902.0849-00	Seal Kit	CH870
2624	902.0806-00	Seal Kit	CH870
2625	902.0825-00	Gasket Ring	CH870
2626	452.1616-901	Return Oil Hose	CH870
2627	452.1286-001	Hydraulic Hose	CH870
2628	452.1287-001	Hydraulic Hose	CH870
2629	452.1288-001	Hydraulic Hose	CH870
2630	900.2199-00	Flange	CH870
2631	900.2599-00	Adapter	CH870
2632	442.9396-00	Bend	CH870
2633	900.0699-00	Straight Adapter	CH870
2634	452.1538-001	Hose	CH870
2635	452.1414-001	Bracket	CH870
2636	452.1415-001	Rubber Cloth	CH870
2637	452.1419-901	Wearing Liner	CH870
2638	442.9503-01	Bolt	CH870
2639	845.0215-00	Nut Lock	CH870
2640	847.0016-00	Washer	CH870
2641	452.1425-901	Support	CH870
2642	452.1426-001	Bracket	CH870
2643	452.1448-001	Bracket	CH870
2644	452.1449-001	Bracket	CH870
2645	452.1468-901	Bracket	CH870
2646	452.1427-001	Protection	CH870
2647	840.0068-00	Screw	CH870
2648	840.0064-00	Screw	CH870
2649	452.1476-901	Bracket	CH870
2650	840.0051-00	Screw	CH870
2651	845.0030-00	Lock Nut	CH870
2652	840.0049-00	Screw	CH870
2653	452.1579-001	Hose	CH870
2654	873.0390-00	Seal Ring	CH870
2655	900.2592-00	Half Flange	CH870
2656	873.0755-00	O-Ring	CH870
2657	847.0147-00	Washer	CH870
2658	841.0268-00	Screw	CH870

2659	452.1580-001	Hose	CH870
2660	452.1587-001	Hose	CH870
2661	900.0656-00	Straight Adapter	CH870
2662	873.0386-00	Seal Ring	CH870
2663	900.0655-00	Adapter	CH870
2664	452.1511-001	Pilot Valve Protection	CH870
2665	840.0066-00	Screw	CH870
2666	840.0622-00	Screw	CH870
2667	452.1536-901	Straight Hose Coupling	CH870
2668	841.0578-00	Screw	CH870
2669	452.1414-002	Bracket	CH870
2670	819.0061-00	Hose	CH870
2671	873.0615-00	Seal O-Ring	CH870
2672	452.1589-001	Cover	CH870
2673	452.1592-001	Cover	CH870
2674	900.2602-00	Flange	CH870
2675	900.2385-00	Flange	CH870
2676	873.1299-00	O-Ring	CH870
2677	452.1591-001	Cover	CH870
2678	873.0129-00	O-Ring	CH870
2679	452.1590-001	Cover	CH870
2680	847.0144-00	Washer	CH870
2681	841.0253-00	Screw	CH870
2682	845.0213-00	Nut Lock	CH870
2683	452.1602-901	Bracket For Valve	CH870
2684	452.1665-001	Spacer	CH870
2685	847.0132-00	Washer	CH870
2686	840.0078-00	Screw	CH870
2687	452.0926-00	Dust Collar	CH870
2688	840.0064-00	Screw	CH870
2689	452.0999-001	Ring	CH870
2690	840.0072-00	Screw	CH870
2691	847.0327-00	Washer	CH870
2692	452.0834-001	Locating Bar	CH870
2693	452.1279-001	Shim	CH870
2694	452.1279-002	Shim	CH870
2695	452.1279-003	Shim	CH870
2696	452.1279-004	Shim	CH870

2697	841.0254-00	Screw	CH870
2698	452.1267-001	Gasket	CH870
2699	452.1000-001	Inner Dust Seal Ring	CH870
2700	452.0942-901	Subframe	CH870
2701	452.1620-901	Dust Seal Assy	CH870
2702	452.1263-901	Subframe V-Belt Drive	CH870
2703	452.2564-901	Motorframe For V-Elc Drive, Assy.	CH870
2704	458.0406-03	Shims	CH870
2705	458.0406-02	Shims	CH870
2706	442.9650-93	Rubber Damper	CH870
2707	452.1781-901	Motor Alt	CH870
2708	452.1642-901	Dust Seal Alternatives	CH870
2709	458.0773-01	Slide Rail	CH870
2710	458.0156-00	Bracket	CH870
2711	984.0217-00	Sensor	CH870
2712	930.0328-00	Omega Elastomer Coupling	CH870
2713	452.2568-901	Spacer	CH870
2714	458.0348-01	Shaft	CH870
2715	458.0349-01	Bearing Housing	CH870
2716	857.0336-00	Key	CH870
2717	842.0019-00	Screw	CH870
2718	868.0829-00	Roller Bearing	CH870
2719	868.0830-00	Clamping Sleeve	CH870
2720	649.0168-04	Supporting Cleat	CH870
2721	871.0110-00	Guide Ring	CH870
2722	873.1289-00	Felt Seal	CH870
2723	873.0898-00	V-Ring	CH870
2724	871.0404-00	Cover End	CH870
2725	442.9342-01	Washer	CH870
2726	442.9343-01	Spacer	CH870
2727	847.0132-00	Washer	CH870
2728	452.1297-901	V-Belt Guard	CH870
2729	452.2511-901	V-Belt Guard Assy.	CH870
2730	847.0162-00	Washer	CH870
2731	847.0132-00	Washer	CH870
2732	840.0077-00	Screw	CH870
2733	840.1038-00	Screw	CH870
2734	845.0273-00	Nut Lock	CH870

2735	840.0718-00	Screw	CH870
2736	840.0669-00	Screw	CH870
2737	840.0670-00	Screw	CH870
2738	847.0124-00	Washer	CH870
2739	840.0672-00	Screw	CH870
2740	845.0216-00	Nut Lock	CH870
2741	847.0016-00	Washer	CH870
2742	840.0071-00	Screw	CH870
2743	840.0072-00	Screw	CH870
2744	847.0012-00	Washer	CH870
2745	840.0021-00	Screw	CH870
2746	840.0078-00	Screw	CH870
2747	840.0677-00	Screw	CH870
2748	845.0216-00	Nut Lock	CH870
2749	857.0216-00	Key	CH870
2750	845.0012-00	Nut	CH870
2751	847.0122-00	Washer	CH870
2752	845.0010-00	Nut	CH870
2753	840.0675-00	Screw	CH870
2754	853.0617-00	Spiral Pin	CH870
2755	452.2510-901	Subframe Hydraulic Equipment	CH870
2756	452.2595-001	Shims	CH870
2757	840.1197-00	Screw	CH870
2758	841.0587-00	Screw	CH870
2759	841.0584-00	Screw	CH870
2760	452.3770-001	Washer	CH870
2761	452.0905-901	Subframe Direct Drive	CH870
2762	452.1781-901	Motor Alt	CH870
2763	452.1642-901	Dust Seal Alternatives	CH870
2764	452.1014-901	Protective Cap For Shaft	CH870
2765	930.0332-00	Coupling	CH870
2766	930.0333-00	Coupling Omega	CH870
2767	442.9650-92	Rubber Damper	CH870
2768	452.1622-901	Spacer With Flat Bar	CH870
2769	458.0452-01	Support	CH870
2770	442.9342-01	Washer	CH870
2771	984.0217-00	Sensor	CH870
2772	458.0406-01	Shim	CH870

2773	458.0406-02	Shim	CH870
2774	458.0406-03	Shim	CH870
2775	452.1609-001	Threaded Pin	CH870
2776	840.0718-00	Screw	CH870
2777	845.0273-00	Lock Nut	CH870
2778	847.0162-00	Washer	CH870
2779	847.0124-00	Washer	CH870
2780	841.0587-00	Screw	CH870
2781	845.0013-00	Nut	CH870
2782	847.0012-00	Washer	CH870
2783	840.0021-00	Screw	CH870
2784	847.0132-00	Washer	CH870
2785	840.0077-00	Screw	CH870
2786	840.0652-00	Screw	CH870
2787	452.3770-001	Washer	CH870
2788	452.2564-901	Motorframe	CH870
2789	458.0406-03	Shim	CH870
2790	458.0406-02	Shim	CH870
2791	452.1781-901	Motor Alt	CH870
2792	458.0773-01	Slide Rail	CH870
2793	458.0156-00	Bracket	CH870
2794	984.0217-00	Sensor	CH870
2795	930.0328-00	Elastomer Coupling	CH870
2796	930.0314-00	Flex Element	CH870
2797	452.1882-901	Grooved Pulley	CH870
2798	452.1884-901	Bushing	CH870
2799	452.2568-901	Spacer	CH870
2800	458.0348-01	Shaft	CH870
2801	458.0349-01	Bearing Housing	CH870
2802	857.0336-00	Key	CH870
2803	842.0019-00	Screw	CH870
2804	868.0829-00	Roller Bearing C	CH870
2805	868.0830-00	Clamping Sleeve	CH870
2806	649.0168-04	Supporting Cleat	CH870
2807	871.0110-00	Guide Ring	CH870
2808	873.1289-00	Felt Seal F	CH870
2809	873.0898-00	V-Ring V	CH870
2810	871.0404-00	Cover End 34	CH870

2811	442.9342-01	Washer	CH870
2812	442.9343-01	Spacer	CH870
2813	452.1297-901	V-Belt Guard	CH870
2814	847.0162-00	Washer	CH870
2815	847.0132-00	Washer	CH870
2816	840.0077-00	Screw	CH870
2817	845.0273-00	Lock Nut	CH870
2818	840.0718-00	Screw	CH870
2819	840.0670-00	Screw	CH870
2820	847.0016-00	Washer	CH870
2821	847.0124-00	Washer	CH870
2822	845.0215-00	Nut Lock	CH870
2823	840.0072-00	Screw	CH870
2824	847.0012-00	Washer	CH870
2825	840.0021-00	Screw	CH870
2826	840.0079-00	Screw	CH870
2827	840.0672-00	Screw	CH870
2828	840.0677-00	Screw	CH870
2829	845.0216-00	Nut Lock	CH870
2830	452.1848-901	Adapter Fixed	CH870
2831	857.0216-00	Key	CH870
2832	845.0012-00	Nut	CH870
2833	847.0122-00	Washer	CH870
2834	853.0617-00	Spiral Pin	CH870
2835	840.0675-00	Screw	CH870
2836	845.0010-00	Nut	CH870
2837	452.3692-901	Over Pressure Blower Unit With El.	CH870
2838	452.1168-901	Over Pressure Blower	CH870
2839	900.0154-00	Malleable Cast Iron Bussing	CH870
2840	900.1424-00	Hose Coupling	CH870
2841	819.0187-00	Pneumatic Hose	CH870
2842	900.0275-00	Wrought Iron Pipe Fittings Socket	CH870
2843	900.1358-00	Clips	CH870
2844	912.0219-00	Air Filter	CH870
2845	452.3692-902	Over Pressure Blower Unit, Pneumatic	CH870
2846	900.0180-00	Nipple	CH870
2847	912.0113-00	Air Filter	CH870
2848	900.0169-00	Nipple	CH870

2849	902.0645-00	Regulator	CH870
2850	900.0182-00	Nipple	CH870
2851	900.1358-00	Clips	CH870
2852	819.0187-00	Pneumatic Hose	CH870
2853	900.1424-00	Hose Coupling	CH870
2854	900.0275-00	Wrought Iron Pipe Fittings Socket	CH870
2855	452.1169-901	Over Pressure Blower	CH870
2856	906.0494-00	Over Pressure Fan	CH870
2857	972.0838-00	Motor	CH870
2858	840.0021-00	Screw	CH870
2859	452.0642-901	Bottomshell	H8800
2860	452.1064-001	Foot	H8800
2861	840.0693-00	Screw	H8800
2862	847.0125-00	Washer	H8800
2863	442.7201-90	Cover	H8800
2864	843.1267-00	Stud Screw	H8800
2865	847.0147-00	Washer	H8800
2866	845.0030-00	Lock Nut	H8800
2867	452.0317-901	Liner – Pin Shaft Arm	H8800
2868	452.0314-901	Liner- Narrow Arm	H8800
2869	442.9396-00	Bend	H8800
2870	900.2199-00	Flange	H8800
2871	840.0070-00	Screw	H8800
2872	847.0016-00	Washer	H8800
2873	873.0129-00	O-Ring	H8800
2874	442.9248-01	Bottomshell Bushing	H8800
2875	442.9363-01	Gasket	H8800
		Junta	
		Garniture	
2876	442.9357-01	Eccentric Bushing	H8800
2877	442.9358-01	Eccentric Bushing	H8800
2878	442.9359-01	Eccentric Bushing	H8800
2879	442.9360-01	Eccentric Bushing	H8800
2880	442.9249-01	Eccentric Wearing Plate	H8800
2881	442.9256-01	Hydroset Cylinder Bushing	H8800
2882	442.9724-01	Piston Wearing Plate	H8800
2883	442.9722-01	Step Washer	H8800
2884	442.9257-00	Chevron Packing	H8800

2885	873.1233-00	O-Ring	H8800
2886	873.1210-00	O-Ring	H8800
2887	442.9364-01	Gasket	H8800
2888	442.9364-02	Gasket	H8800
2889	442.9364-03	Gasket	H8800
2890		Oil Seal Ring	H8800
	873.1219-00		
2891	873.1219-00	Oil Seal Ring	H8800
2892	442.9365-01	Gasket	H8800
2893	442.9366-01	Gasket	H8800
2894	442.9723-01	Mainshaft Step	H8800
2895	442.9269-01	Inner Head Nut	H8800
2896	442.9271-01	Dust Seal Ring	H8800
2897	912.0155-00	Filter Cartridge	H8800
2898	873.1232-00	O-Ring	H8800
2899	452.0418-001	Oil Seal Ring	H8800
2900	840.1136-00	Screw	H8800
2901	845.0273-00	Lock Nut	H8800
2902	442.9353-01	Sleeve	H8800
2903	442.9354-01	Washer	H8800
2904	863.0015-00	Disc Spring	H8800
2905	442.9694-00	Basic Design	CS420
2906	442.9871-00	Bottom Shell	CS420
2907	442.6564-00	Cover	CS420
2908	843.1267	Stud Screw	CS420
2909	847.0147-00	Washer	CS420
2910	845.0030-00	Lock Nut	CS420
2911	442.6174-01	Liner-Pinion Shaft Arm	CS420
2912	442.6175-01	Liner-Narrow Arm	CS420
2913	900.0026-00	Pipe Angle	CS420
2914	442.6131-01	Bottom Shell Bushing	CS420
2915	853.0464-00	Pin	CS420
2916	900.0921-00	Swivel Branch Tee Adapter	CS420
2917	900.1412-00	Pipes Pipe	CS420
2918	900.0276-00	Cover	CS420
2919	442.6132-01	Dust Collar	CS420
2920	840.0634-00	Screw	CS420
2921	853.0464-00	Pin	CS420

2922	840.0069-00	Screw	CS420
2923	847.0016-00	Washer	CS420
2924	442.6143-01	Backing Lip	CS420
2925	442.6212-01	Shim	CS420
2926	442.6212-02	Shim	CS420
2927	442.6212-03	Shim	CS420
2928	442.6212-05	Shim	CS420
2929	841.0250-00	Screw	CS420
2930	442.6216-01	Gasket	CS420
2931	442.6146-01	Seal Inner	CS420
2932	840.0069-00	Screw	CS420
2933	847.0120-00	Washer	CS420
2934	840.0718-00	Screw	CS420
2935	845.0221-00	Nut	CS420
2936	847.0162-00	Washer	CS420
2937	899.0229-00	Protective Cap	CS420
2938	442.6243-01	Screw	CS420
2939	899.0229-00	Protective Cap	CS420
2940	442.9685-01	Eccentric	CS420
2941	442.9686-01	Eccentric Bushing	CS420
2942	442.6152-01	Hub	CS420
2943	442.6145-01	Ring	CS420
2944	840.0046-00	Screw	CS420
2945	847.0147-00	Washer	CS420
2946	442.9607-01	Key	CS420
2947	841.0026-00	Screw	CS420
2948	841.0518-00	Screw	CS420
2949	847.0180-00	Washer	CS420
2950	442.6127-00	Gear Compl.	CS420
2951	857.0328-00	Key	CS420
2952	442.6130-01	Wearing Plate	CS420
2953	853.0619-00	Dowel	CS420
2954	442.9872-01	Hydroset Cylinder	CS420
2955	840.0542-00	Screws	CS420
2956	847.0124-00	Washer	CS420
2957	442.9873-01	Hydroset Cylinder Bushing	CS420
2958	840.0019-00	Screws	CS420
2959	847.0012-00	Washer	CS420

2960	873.0439-00	O-Ring	CS420
2961	442.9655-00	Piston	CS420
2962	853.0645-00	Spiral-Pins Pin	CS420
2963	442.6139-01	Piston Wearing Plate	CS420
2964	442.6137-01	Step Washer	CS420
2965	442.6153-00	Hydroset Packing	CS420
2966	442.6179-01	Packing Clamp Plate	CS420
2967	841.0267-00	Screw	CS420
2968	442.9660-00	Hydroset Cylinder Cover	CS420
2969	840.0542-00	Screws	CS420
2970	847.0124-00	Washer	CS420
2971	902.0605-00	Air Bleed Valve	CS420
2972	873.0830-00	O-Ring	CS420
2973	873.1274-00	O-Ring	CS420
2974	442.8783-01	Plug	CS420
2975	873.0111-00	O-Ring	CS420
2976	840.0023-00	Screw	CS420
2977	847.0012-00	Washer	CS420
2978	840.0019-00	Screws	CS420
2979	442.6627-00	Pinion Shaft Housing Ass	CS420
2980	442.6134-01	Pinion Shaft Housing	CS420
2981	442.6214-02	Gasket	CS420
2982	442.6214-01	Gasket	CS420
2983	442.6214-03	Gasket	CS420
2984	442.6127-02	Pinion	CS420
2985	868.0801-00	Bearing	CS420
2986	868.0801-00	Bearing	CS420
2987	442.6148-01	Spacer	CS420
2988	442.6148-01	Spacer	CS420
2989	873.0777-00	O-Ring	CS420
2990	873.0777-00	O-Ring	CS420
2991	873.1012-00	Seal	CS420
2992	873.1012-00	Seal	CS420
2993	442.6144-01	Plate	CS420
2994	442.6144-01	Plate	CS420
2995	840.0035-00	Screw	CS420
2996	847.0144-00	Washer	CS420
2997	840.0035-00	Screw	CS420

2998	847.0144-00	Washer	CS420
2999	442.6213-01	Gasket	CS420
3000	442.6213-01	Gasket	CS420
3001	900.0717-00	Filter Plug	CS420
3002	442.6202-01	Plug	CS420
3003	873.0383-00	Sealing Ring	CS420
3004	442.6133-01	Pinion Shaft	CS420
3005	857.0051-00	Key	CS420
3006	442.2018-01	Plug	CS420
3007	900.0269-00	Barrel Nipples	CS420
3008	900.0275-00	Socket	CS420
3009	442.6201-01	Glass Gauge	CS420
3010	873.0385-00	Tredo N	CS420
3011	855.0020-00	Retaining Ring	CS420
3012	840.0956-00	Screw	CS420
3013	845.0009-00	Nut	CS420
3014	442.6816-00	Main Shaft Ass Excl. Mantle	CS420
3015	442.6777-01	Main Shaft	CS420
3016	442.6140-01	Main Shaft Sleeve	CS420
3017	853.0645-00	Spiral-Pins Pin	CS420
3018	442.6138-01	Main Shaft Step	CS420
3019	855.0020-00	Retaining Ring	CS420
3020	442.8882-01	Head Center	CS420
3021	442.9288-01	Mantle A M1	CS420
3022	442.6789-01	Mantle B M1	CS420
3023	442.6194-00	Head Nut With Burn Ring	CS420
3024	442.6193-01	Inner Head Nut	CS420
3025	442.6217-01	Burning Ring	CS420
3026	442.6906-01	Dust Seal Ring	CS420
3027	442.6141-01	Retainer	CS420
3028	442.6931-01	Retainer	CS420
3029	442.6932-01	Scraper	CS420
3030	840.0046-00	Screw	CS420
3031	840.0048-00	Screws	CS420
3032	847.0147-00	Washer	CS420
3033	442.8374-00	Top Shell	CS420
3034	442.8366-01	Top Shell	CS420
3035	442.0191-01	Dowel	CS420

3036	442.6798-00	Arm Shield	CS420
3037	900.1262-00	Elbow Adapte	CS420
3038	650.0086-06	Hose	CS420
3039	914.0093-00	Lubrication Nipple	CS420
3040	442.6813-01	Bracket	CS420
3041	840.0021-00	Screw	CS420
3042	900.0243-00	Wrought Iron Pipe Fittings Socket Rp	CS420
3043	442.8362-01	Spider Cap	CS420
3044	912.0114-00	Air Filter	CS420
3045	900.0652-00	Adapter	CS420
3046	900.0018-00	Elbow	CS420
3047	873.0831-00	O-Ring	CS420
3048	840.0067-00	Screw	CS420
3049	847.0120-00	Washer	CS420
3050	442.8363-01	Spider Bushing	CS420
3051	840.0069-00	Screw	CS420
3052	847.0016-00	Washer	CS420
3053	442.8364-01	Seal	CS420
3054	900.0981-00	Plug Bspt 1" Hexagon	CS420
3055	442.6977-00	Concaves	CS420
3056	442.6978-00	Concaves	CS420
3057	442.8464-001	Lower Concave Ring Ec	CS420
3058	442.8522-00	Lower Concave Ring C	CS420
3059	442.8550-00	Concave-Top Tier	CS420
3060	442.7379-00	Concave-Top Tier	CS420
3061	831.0016-00	Casting Compound	CS420
3062	831.0016-00	Casting Compound	CS420
3063	442.6809-00	Hydroset	CS420
3064	442.6821-00	Wrench And Tool Set	CS420
3065	442.6821-90	Wrench And Tool Set	CS420
3066	442.6174-01	Pin Shaft Arm Liner	CS420
3067	442.6175-01	Narrow Arm Liner	CS420
3068	442.8901-00	Wearing Plates Complete Set	CS420
3069	442.8902-01	Wearing Plates	CS420
3070	442.8903-01	Wearing Plates	CS420
3071	442.8904-01	Wearing Plates	CS420
3072	442.8905-01	Wearing Plates	CS420
3073	442.8906-01	Wearing Plates	CS420

3074	442.8901-06	Rod	CS420
3075	847.0059-00	Washer	CS420
3076	840.0047-00	Screw	CS420
3077	442.6811-00	Feed Hopper	CS420
3078	442.6811-90	Feed Hopper With Insp. Door	CS420
3079	840.0072-00	Screw	CS420
3080	847.0016-00	Washer	CS420
3081	845.0009-00	Nut	CS420
3082	442.6812-00	Feed Hopper Cone	CS420
3083	442.6635-00	Rubber Compression Mounting For	CS420
3084	845.0216-00	Nut	CS420
3085	847.0124-00	Washer	CS420
3086	442.6643-00	Top Plate	CS420
3087	864.0070-00	Rubber Compression Mounting	CS420
3088	840.0044-00	Screw	CS420
3089	847.0147-00	Washer	CS420
3090	442.6644-00	Fixing Plate, Lower	CS420
3091	442.6635-90	Rubber Compression Mountings For	CS420
3092	864.0070-00	Rubber Compression Mounting	CS420
3093	840.0044-00	Screw	CS420
3094	847.0147-00	Washer	CS420
3095	442.6644-00	Fixing Plate, Lower	CS420
3096	840.0047-00	Screw	CS420
3097	845.0030-00	Nut	CS420
3098	442.6908-01	Bushing	CS420
3099	873.0390-00	Sealing Ring	CS420
3100	900.0648-00	Adapter	CS420
3101	873.0386-00	Sealing Ring	CS420
3102	650.0189-01	Hydraulic Hose	CS420
3103	900.0655-00	Adapter	CS420
3104	873.0385-00	Sealing Ring	CS420
3105	442.5969-01	Connection Piece	CS420
3106	900.0810-00	Bushing	CS420
3107	902.0605-00	Bleeder Valve	CS420
3108	442.8398-00	Protection	CS420
3109	442.2100-01	Bracket	CS420
3110	900.0746-00	Clamp	CS420
3111	840.0013-00	Screw	CS420

3112	845.0004-00	Nut	CS420
3113	919.0231-00	Adapter	CS420
3114	442.8642-00	Over Pressure Unit	CS420
3115	442.8642-90	Over Pressure Unit For Compressed Air	CS420
3116	900.1424-00	Hose Coupling	CS420
3117	900.1358-00	Clips	CS420
3118	819.0187-00	Hose 1	CS420
3119	900.0040-00	Tee	CS420
3120	900.0365-00	Hexagon Nippel	CS420
3121	900.0022-00	Elbow	CS420
3122	900.1139-00	Clip Rsgu	CS420
3123	900.0005-00	Elbow	CS420
3124	442.9325-00	Over Pressure Fan	CS420
3125	912.0138-00	Air Filter Purolator	CS420
3126	900.0108-00	Wrought Iron Pipe Fitting	CS420
3127	900.0209-00	Plug	CS420
3128	900.0022-00	Elbow	CS420
3129	900.1139-00	Clip	CS420
3130	900.0005-00	Elbow	CS420
3131	900.0180-00	Nipple	CS420
3132	912.0113-00	Air Filter	CS420
3133	900.0169-00	Nipple	CS420
3134	902.0645-00	Regulator	CS420
3135	900.0182-00	Nipple	CS420
3136	900.0054-00	Tee	CS420
3137	900.0209-00	Plug	CS420
3138	923.0267-00	Pressure Gauge	CS420
3139	900.0172-00	Nipple	CS420
3140	442.9944-00	V-Belt Drive	CS420
3141	879.0322-00	V-Belt Pulley	CS420
3142	869.0221-00	Bushing	CS420
3143	857.0052-00	Key	CS420
3144	442.6162-00	Washer	CS420
3145	847.0016-00	Washer B	CS420
3146	840.0065-00	Screw	CS420
3147	879.0343-00	V-Belt Pulley	CS420
3148	442.9911-00	V-Belt Drive	CS420
3149	869.0328-00	Bushing	CS420

3150	442.6162-00	Washer	CS420
3151	847.0016-00	Washer	CS420
3152	840.0067-00	Screw	CS420
3153	879.0616-00	V-Belt Pulley	CS420
3154	879.0621-00	V-Belt Pulley	CS420
3155	857.0052-00	Key	CS420
3156	126.0421-001	Sign Product Name	CS420
3157	126.0383-001	Risk Of Crushing	CS420
3158	885.0249-00	Signs Centre Of Gravity	CS420
3159	126.0384-001	Warning Flying Fragments	CS420
3160	126.0385-001	Warning Sign Read Manual	CS420
3161	126.5007-01	Identification Plate	CS420
3162	885.0267-00	Warning Sign Danger	CS420
3163	126.0441-001	Logotype Silver	CS420
3164	442.6143-01	Locating Bar	CS420
3165	442.6212-01	Shim	CS420
3166	442.6212-02	Shim	CS420
3167	442.6212-03	Shim	CS420
3168	442.6212-05	Shim	CS420
3169	841.0250-00	Screw	CS420
3170	442.6214-01	Gasket	CS420
3171	442.6214-02	Gasket	CS420
3172	442.6214-03	Gasket	CS420
3173	868.0801-00	Bearing	CS420
3174	442.6148-01	Spacer	CS420
3175	873.0777-00	O-Ring	CS420
3176	873.1012-00	Seal	CS420
3177	442.6213-01	Gasket	CS420
3178	873.0383-00	Sealing Ring	CS420
3179	873.0385-00	Sealing Ring	CS420
3180	442.6174-01	Pin Shaft Arm Liner	CS420
3181	442.6175-01	Narrow Arm Liner	CS420
3182	442.8902-01	Wearing Plates	CS420
3183	442.8903-01	Wearing Plates	CS420
3184	442.8904-01	Wearing Plates	CS420
3185	442.8905-01	Wearing Plates	CS420
3186	442.8906-01	Wearing Plates	CS420
3187	442.8901-06	Rod	CS420

3188	847.0059-00	Washer	CS420
3189	840.0047-00	Screw	CS420
3190	452.5542-901	Filter Kit	CS420
3191	912.0126-00	Filter	CS420
3192	912.0129-00	Filter Cartridge	CS420
3193	912.0139-00	Filter Cartridge	CS420
3194	912.0155-00	Filter Cartridge	CS420
3195	442.7908-00	Bottom Shell	CS430
3196	442.7201-00	Cover	CS430
3197	843.1267	Stud Screw	CS430
3198	847.0147-00	Washer	CS430
3199	845.0030-00	Lock Nut	CS430
3200	442.7915-01	Liner --Pinionshaft Arm	CS430
3201	442.7914-01	Liner – Narrow Arm	CS430
3202	900.0027-00	Elbow	CS430
3203	452.4190-001	Bottom Shell Bushing	CS430
3204	853.0464-00	Pin	CS430
3205	442.7908-00	Bottom Shell	CS430
3206	900.0921-00	Swivel Branch Tee Adapter	CS430
3207	900.1412-00	Pipes Pipe	CS430
3208	900.0276-00	Cover	CS430
3209	442.8870-00	Liners Bottom Shell	CS430
3210	442.7929-01	Dust Collar	CS430
3211	840.0634-00	Screw	CS430
3212	442.7932-01	Ring	CS430
3213	853.0464-00	Pin	CS430
3214	840.1034-00	Screws	CS430
3215	847.0016-00	Washer	CS430
3216	452.4194-001	Locating Bar	CS430
3217	442.7933-01	Shim	CS430
3218	442.7933-02	Shim	CS430
3219	442.7933-03	Shim	CS430
3220	442.7933-04	Shim	CS430
3221	841.0019-00	Screw	CS430
3222	442.7934-01	Gasket	CS430
3223	442.7931-01	Seal Ring – Inner	CS430
3224	840.0070-00	Screw	CS430
3225	847.0060-00	Washer	CS430

3226	840.0720-00	Screws	CS430
3227	845.0221-00	Nut	CS430
3228	847.0162-00	Washer	CS430
3229	899.0229-00	Protective Cap	CS430
3230	442.9529-02	Screw	CS430
3231	899.0229-00	Protective Cap	CS430
3232	442.8449-01	Eccentric	CS430
3233	452.4516-001	Eccentric Bushing	CS430
3234	442.7926-01	Hub	CS430
3235	442.7930-01	Ring	CS430
3236	840.1156-00	Screws	CS430
3237	847.0147-00	Washer	CS430
3238	442.9608-01	Key	CS430
3239	841.0026-00	Screw	CS430
3240	841.0024-00	Screw	CS430
3241	847.0180-00	Washer	CS430
3242	442.7802-00	Gear And Pinion Set	CS430
3243	442.8011-01	Key	CS430
3244	452.4188-001	Ecc. Wearing Plate	CS430
3245	853.0474-00	Spring Pin	CS430
3246	442.7889-01	Hydroset Cylinder	CS430
3247	840.0542-00	Screws	CS430
3248	847.0124-00	Washer	CS430
3249	442.7892-01	Hydroset Cylinder Bushing	CS430
3250	840.0019-00	Screws	CS430
3251	847.0012-00	Washer	CS430
3252	873.0836-00	Seals O-Ring	CS430
3253	442.9668-00	Piston	CS430
3254	853.0118-00	Pins	CS430
3255	442.7893-01	Piston Wearing Plate	CS430
3256	442.7894-01	Step Washer	CS430
3257	442.7897-00	Chevron Packing	CS430
3258	442.7908-00	Bottom Shell	CS430
3259	442.7896-01	Packing Clamp Plate	CS430
3260	841.0266-00	Screw	CS430
3261	442.9667-00	Hydroset Cylinder Cover	CS430
3262	840.0670-00	Screw	CS430
3263	847.0124-00	Washer	CS430

3264	902.0605-00	Air Bleeder Valve	CS430
3265	873.0157-00	Seals O-Ring	CS430
3266	873.1275-00	Seals O-Ring	CS430
3267	442.8783-01	Plug	CS430
3268	873.0111-00	O-Ring	CS430
3269	840.0023-00	Screws	CS430
3270	847.0012-00	Washer	CS430
3271	840.0019-00	Screws	CS430
3272	442.9962-00	Pinion Shaft Housing Assembled	CS430
3273	442.7949-01	Pinion Shaft Housing	CS430
3274	442.7953-01	Gasket	CS430
3275	442.7953-02	Gasket	CS430
3276	442.7953-03	Gasket	CS430
3277	442.7802-02	Pinion	CS430
3278	868.0790-00	Bearing	CS430
3279	868.0805-00	Bearing	CS430
3280	442.7954-01	Spacer	CS430
3281	442.7954-01	Spacer	CS430
3282	873.0778-00	Seals O-Ring	CS430
3283	873.0778-00	Seals O-Ring	CS430
3284	873.1097-00	Oil Seal Ring	CS430
3285	873.1097-00	Oil Seal Ring	CS430
3286	442.7951-01	Bearing Cover	CS430
3287	442.7950-01	Bearing Cover	CS430
3288	840.0021-00	Screw	CS430
3289	840.0046-00	Screw	CS430
3290	847.0147-00	Washer	CS430
3291	442.7957-01	Gasket	CS430
3292	442.7956-01	Gasket	CS430
3293	442.7956-02	Gasket	CS430
3294	900.0717-00	Filter Plug	CS430
3295	853.0590-00	Spring Pin	CS430
3296	442.7959-01	Plug	CS430
3297	873.0383-00	Sealing Ring Tredo	CS430
3298	442.9936-01	Pinion Shaft	CS430
3299	857.0046-00	Key	CS430
3300	442.2018-01	Plug	CS430
3301	900.0269-00	Barrel Nipples	CS430

3302	900.0275-00	Wrought Iron Pipe Fittings Socket 3/4"	CS430
3303	442.7958-01	Nipple Oil Level	CS430
3304	873.0385-00	Tredo	CS430
3305	855.0103-00	3_Retaining Rings Retaining Ring Sga	CS430
3306	840.1063-00	Screw	CS430
3307	845.0009-00	Nut	CS430
3308	452.6149-901	Mainshaft Assembly Excl. Mantle	CS430
3309	452.6117-901	Mainshaft With Headcenter	CS430
3310	442.7913-01	Mainshaft Sleeve	CS430
3311	442.7908-00	Bottom Shell	CS430
3312	853.0118-00	Pins	CS430
3313	442.7895-01	Mainshaft Step	CS430
3314	855.0103-00	3_Retaining Rings Retaining Ring Sga	CS430
3315	442.8471-01	Mantle B M1	CS430
3316	442.8470-01	Mantle A M1	CS430
3317	831.0016-00	Casting Compound	CS430
3318	442.7912-00	Head Nut With Burn Ring	CS430
3319	442.7918-01	Inner Head Nut	CS430
3320	442.7911-01	Burn Ring	CS430
3321	442.8017-01	Dust Seal Ring	CS430
3322	442.8020-01	Retaining Ring	CS430
3323	442.8021-01	Retainer	CS430
3324	442.8022-01	Scraper	CS430
3325	840.0068-00	Screw	CS430
3326	840.0070-00	Screw	CS430
3327	847.0016-00	Washer	CS430
3328	452.6185-901	Topshell Assembly Excl. Crushing	CS430
3329	452.6109-001	Topshell	CS430
3330	442.9035-01	Liner	CS430
3331	452.6197-001	Dowel	CS430
3332	452.6113-001	Arm Shield	CS430
3333	452.6126-001	Dowel	CS430
3334	900.1262-00	Elbow Adapter	CS430
3335	900.1030-00	Bushing	CS430
3336	452.6193-001	Hose	CS430
3337	914.0093-00	Lubrication Nipple	CS430
3338	442.8506-01	Bracket	CS430
3339	840.0021-00	Screw	CS430

3340	900.0243-00	Wrought Iron Pipe Fittings Socket Rp	CS430
3341	900.2519-00	Adapter	CS430
3342	442.8520-00	Spider Cap	CS430
3343	912.0114-00	Air Filter	CS430
3344	900.0134-00	Bushing	CS430
3345	900.2008-00	Pipe Couplings Elbow	CS430
3346	873.0833-00	Seals O-Ring	CS430
3347	840.0069-00	Screw	CS430
3348	847.0120-00	Washer	CS430
3349	442.6473-01	Spider Bushing	CS430
3350	840.0080-00	Screw	CS430
3351	847.0132-00	Washer	CS430
3352	442.6470-01	Oil Seal Ring	CS430
3353	900.0981-00	Plug Bspt 1" Hexagon	CS430
3354	442.8510-00	Crushing Chamber Ec	CS430
3355	442.8511-00	Crushing Chamber C	CS430
3356	452.1526-901	Crushing Chamber Mc	CS430
3357	442.8477-00	Lower Concave Ring Ec	CS430
3358	442.8478-00	Lower Concave Ring C	CS430
3359	452.1464-901	Concave Ring Mc	CS430
3360	442.8484-00	Concave Upper	CS430
3361	442.8485-00	Concave Upper C	CS430
3362	452.1465-901	Concave Mc	CS430
3363	442.7908-00	Bottom Shell	CS430
3364	831.0016-00	Casting Compound	CS430
3365	831.0016-00	Casting Compound	CS430
3366	831.0016-00	Casting Compound	CS430
3367	442.8512-00	Hydroset	CS430
3368	442.8045-91	Wrench Tool Set	CS430
3369	442.8045-90	Wrench Tool Set	CS430
3370	442.8045-92	Wrench Tool Set	CS430
3371	442.7915-01	Liner – Pinionshaft Arm	CS430
3372	442.7914-01	Liner – Narrow Arm	CS430
3373	442.8870-00	Wearing Plates Complete Set	CS430
3374	442.8864-01	Wearing Plates	CS430
3375	442.8865-01	Wearing Plates	CS430
3376	442.8866-01	Wearing Plates	CS430
3377	442.8867-01	Wearing Plates	CS430

3378	442.8868-01	Wearing Plates	CS430
3379	442.8869-01	Wearing Plates	CS430
3380	442.8799-06	Bar	CS430
3381	847.0059-00	Washer	CS430
3382	840.0048-00	Screw	CS430
3383	442.8529-00	Feed Hopper	CS430
3384	442.8517-00	Feed Hopper	CS430
3385	840.0080-00	Screw	CS430
3386	845.0010-00	Nut	CS430
3387	847.0132-00	Washer	CS430
3388	442.97766-00	Rubber Compression Mountings For	CS430
3389	845.0387-00	Nut	CS430
3390	847.0124-00	Washer	CS430
3391	442.9779-00	Top Plate	CS430
3392	864.0080-00	Rubber Compression Mounting	CS430
3393	840.0044-00	Screw	CS430
3394	847.0147-00	Washer	CS430
3395	442.9780-01	Lower Fixing Plate	CS430
3396	442.97766-90	Rubber Compression Mountings For	CS430
3397	864.0080-00	Rubber Compression Mounting	CS430
3398	840.0044-00	Screw	CS430
3399	847.0147-00	Washer	CS430
3400	442.9780-01	Lower Fixing Plate	CS430
3401	840.0048-00	Screws	CS430
3402	845.0030-00	Lock Nut	CS430
3403	902.0605-00	Air Bleeder	CS430
3404	900.0810-00	Reducer	CS430
3405	873.0385-00	Sealing Ring	CS430
3406	900.0655-00	Adapter	CS430
3407	650.0154-01	Hose	CS430
3408	442.5969-01	Connection	CS430
3409	900.0746-00	Tube Clamp	CS430
3410	840.0013-00	Screw	CS430
3411	845.0004-00	Nut	CS430
3412	442.2100-01	Bracket	CS430
3413	442.8694-00	Protection	CS430
3414	900.0648-00	Adapter	CS430
3415	873.0386-00	Sealing Ring	CS430

3416	442.6908-01	Bushing	CS430
3417	873.0390-00	Sealing Ring	CS430
3418	919.0070-00	Protection Plug	CS430
3419	919.0231-00	Adapter	CS430
3420	442.8642-00	Over Pressure Unit	CS430
3421	442.8642-90	Over Pressure Unit For Compressed Air	CS430
3422	900.1424-00	Hose Coupling	CS430
3423	900.1358-00	Clips	CS430
3424	819.0187-00	Hose	CS430
3425	900.0040-00	Tee	CS430
3426	900.0365-00	Hexagon Nipple	CS430
3427	900.0022-00	Elbow	CS430
3428	900.1139-00	Clip	CS430
3429	900.0005-00	Elbow	CS430
3430	442.9325-00	Over Pressure Fan	CS430
3431	912.0138-00	Air Filter Purolator	CS430
3432	900.0108-00	Wrought Iron Pipe Fittings	CS430
3433	900.0209-00	Plug	CS430
3434	900.0022-00	Elbow	CS430
3435	900.1139-00	Clip	CS430
3436	900.0005-00	Elbow	CS430
3437	900.0180-00	Nipple	CS430
3438	912.0113-00	Air Filter	CS430
3439	900.0169-00	Nipple	CS430
3440	902.0645-00	Regulator	CS430
3441	900.0182-00	Nipple	CS430
3442	900.0054-00	Tee	CS430
3443	900.0209-00	Plug	CS430
3444	923.0267-00	Pressure Gauge	CS430
3445	900.0172-00	Nipple	CS430
3446	879.0437-00	V-Belt Pulley	CS430
3447	869.0189-00	Bushing	CS430
3448	857.0346-00	Key	CS430
3449	442.9940-01	Spacer	CS430
3450	442.7955-01	Washer	CS430
3451	847.0016-00	Washer	CS430
3452	840.0066-00	Screw	CS430
3453	879.0261-00	V-Belt Pulleyc	CS430

3454	869.0221-00	Mgt No. 100	CS430
3455	869.0187-00	Mgt No. 100	CS430
3456	869.0188-00	Mgt No. 100	CS430
3457	869.0258-00	Mgt No. 100	CS430
3458	875.0323-00	V-Belt Spc	CS430
3459	875.0244-00	V-Belt Spc	CS430
3460	869.0221-00	Bushing	CS430
3461	869.0187-00	Bushing	CS430
3462	869.0188-00	Bushing	CS430
3463	869.0258-00	Bushing	CS430
3464	879.0495-00	V-Belt Pulley	CS430
3465	442.9940-01	Spacer	CS430
3466	442.7955-01	Washer	CS430
3467	840.0066-00	Screw	CS430
3468	847.0016-00	Washer	CS430
3469	857.0346-00	Key	CS430
3470	869.0189-00	Bushing	CS430
3471	879.0437-00	V-Belt Pulley	CS430
3472	869.0327-00	Bushing	CS430
3473	442.7955-01	Washer	CS430
3474	847.0016-00	Washer	CS430
3475	840.0066-00	Screw	CS430
3476	879.0615-00	V-Belt Pulley	CS430
3477	869.0338-00	Bushing	CS430
3478	869.0339-00	Bushing	CS430
3479	869.0333-00	Bushing	CS430
3480	879.0623-00	V-Belt Pulley	CS430
3481	875.0364-00	V-Belt	CS430
3482	857.0209-00	Key	CS430
3483	126.0422-001	Sign Product Name	CS430
3484	126.0443-001	Logotype Silver	CS430
3485	126.0383-001	Risk Of Crushing	CS430
3486	885.0249-00	Signs Centre Of Gravity	CS430
3487	126.0384-001	Warning Flying Fragments	CS430
3488	126.0385-001	Warning Sign Read Manual	CS430
3489	126.5007-01	Identification Plate	CS430
3490	885.0267-00	Warning Sign Danger	CS430
3491	442.7928-01	Locating Bar	CS430

3492	442.7933-01	Shim	CS430
3493	442.7933-02	Shim	CS430
3494	442.7933-03	Shim	CS430
3495	442.7933-04	Shim	CS430
3496	841.0019-00	Screw	CS430
3497	442.7953-01	Gasket	CS430
3498	442.7953-02	Gasket	CS430
3499	442.7953-03	Gasket	CS430
3500	868.0790-00	Bearing	CS430
3501	868.0805-00	Bearing	CS430
3502	442.7954-01	Spacer	CS430
3503	873.0778-00	O-Ring	CS430
3504	873.1097-00	Seal	CS430
3505	442.7957-01	Gasket	CS430
3506	442.7956-01	Gasket	CS430
3507	442.7956-02	Gasket	CS430
3508	873.0383-00	Sealing Ring	CS430
3509	873.0385-00	Sealing Ring	CS430
3510	442.7915-01	Pin Shaft Arm Liner	CS430
3511	442.7914-01	Narrow Arm Liner	CS430
3512	442.8864-01	Wearing Plates	CS430
3513	442.8865-01	Wearing Plates	CS430
3514	442.8866-01	Wearing Plates	CS430
3515	442.8867-01	Wearing Plates	CS430
3516	442.8868-01	Wearing Plates	CS430
3517	442.8869-01	Wearing Plates	CS430
3518	442.8799-06	Bar	CS430
3519	847.0059-00	Washer	CS430
3520	840.0048-00	Screw	CS430
3521	912.0126-00	Filter	CS430
3522	912.0129-00	Filter Cartridge	CS430
3523	912.0139-00	Filter Cartridge	CS430
3524	912.0155-00	Filter Cartridge	CS430
3525	452.0230-901	Bottom Shell	CS440
3526	442.7201-00	Cover	CS440
3527	843.1267	Stud Screw	CS440
3528	847.0147-00	Washer	CS440
3529	845.0030-00	Lock Nut	CS440

3530	442.7140-00	Liner-Pin Shaft Arm	CS440
3531	442.7141-00	Liner-Norrow Arm	CS440
3532	900.0027-00	Elbow	CS440
3533	442.7146-01	Bottom Shell Bushing	CS440
3534	853.0464-00	Pin	CS440
3535	900.0921-00	Swivel Branch Tee Adapter	CS440
3536	900.1412-00	Pipes	CS440
3537	900.0276-00	Cover	CS440
3538	452.0243-901	Liners In Bottom Shell	CS440
3539	442.7106-01	Dust Collar	CS440
3540	840.0634-00	Screw	CS440
3541	442.7109-01	Ring	CS440
3542	853.0464-00	Pin	CS440
3543	840.1151-00	Screws	CS440
3544	847.0016-00	Washer	CS440
3545	442.7110-01	Locating Bar	CS440
3546	442.7168-01	Shim	CS440
3547	442.7168-02	Shim	CS440
3548	442.7168-03	Shim	CS440
3549	442.7168-04	Shim	CS440
3550	841.0019-00	Screw	CS440
3551	442.7170-01	Gasket	CS440
3552	442.7108-01	Seal Ring Inner	CS440
3553	840.0071-00	Screw	CS440
3554	847.0060-00	Washer	CS440
3555	840.1073-00	Screws	CS440
3556	845.0322-00	Nut	CS440
3557	847.0171-00	Washer Brb	CS440
3558	899.0278-00	Protective Cap	CS440
3559	442.7243-01	Screw	CS440
3560	899.0278-00	Protective Cap	CS440
3561	442.8068-01	Eccentric	CS440
3562	442.8067-01	Eccentric Bushing	CS440
3563	442.7142-01	Hub	CS440
3564	442.7169-00	Ring	CS440
3565	840.1157-00	Screws	CS440
3566	847.0147-00	Washer	CS440
3567	442.9609-01	Key	CS440

3568	841.0027-00	Screw	CS440
3569	841.0025-00	Screw	CS440
3570	847.0180-00	Washer	CS440
3571	442.7093-00	Gear And Pinion Set	CS440
3572	442.7171-01	Key	CS440
3573	442.7107-01	Eccentric Wearing Plate	CS440
3574	853.0646-00	Pin Prym N 16X45	CS440
3575	442.7163-01	Hydroset Cylinder	CS440
3576	840.0671-00	Screw	CS440
3577	847.0124-00	Washer	CS440
3578	442.7166-01	Hydroset Cylinder Bushing	CS440
3579	840.0019-00	Screws	CS440
3580	841.0019-00	Screw	CS440
3581	847.0012-00	Washer	CS440
3582	873.0892-00	Seals O-Ring	CS440
3583	442.9672-00	Piston	CS440
3584	853.0119-00	Pin	CS440
3585	442.7122-01	Piston Wearing Plate	CS440
3586	442.7121-01	Step Washer	CS440
3587	442.7112-00	Chevron Packing	CS440
3588	442.7167-01	Packing Clamp Plate	CS440
3589	841.0266-00	Screw	CS440
3590	442.9663-00	Hydroset Cylinder Cover	CS440
3591	840.0671-00	Screw	CS440
3592	840.0676-00	Screw	CS440
3593	847.0124-00	Washer	CS440
3594	902.0605-00	Air Bleeder Valve	CS440
3595	873.0835-00	Seals O-Ring	CS440
3596	873.1276-00	Seals O-Ring	CS440
3597	442.8783-01	Plug	CS440
3598	873.0111-00	O-Ring	CS440
3599	840.0023-00	Screws	CS440
3600	847.0012-00	Washer	CS440
3601	840.0019-00	Screws	CS440
3602	442.9966-00	Pinion Shaft Housing Assembled	CS440
3603	442.7506-01	Pinion Shaft Housing	CS440
3604	442.7136-01	Gasket	CS440
3605	442.7136-03	Gasket	CS440

3606	442.7136-02	Gasket	CS440
3607	442.7093-02	Pinion	CS440
3608	868.0282-00	Bearings Spherical Roller	CS440
3609	868.0804-00	Tapered Roller Bearing	CS440
3610	442.7130-01	Spacer Inner	CS440
3611	442.7131-01	Spacer Outer	CS440
3612	873.0779-00	Seals O-Ring	CS440
3613	873.0399-00	Seals	CS440
3614	873.1208-00	Oil Seal Ring	CS440
3615	873.1208-00	Oil Seal Ring	CS440
3616	442.9684-01	Bearing Cover Inner	CS440
3617	442.7133-01	Bearing Cover Outer	CS440
3618	840.0045-00	Screw	CS440
3619	847.0147-00	Washer	CS440
3620	840.0066-00	Screw	CS440
3621	847.0016-00	Washer	CS440
3622	442.7134-01	Gasket	CS440
3623	442.7135-01	Gasket	CS440
3624	442.7135-02	Gasket	CS440
3625	853.0590-00	Spring Pin	CS440
3626	442.9937-01	Pinion Shaft	CS440
3627	857.0337-00	Key	CS440
3628	900.0022-00	Elbow	CS440
3629	900.2026-00	Magnetic Plug	CS440
3630	873.0385-00	Tredo	CS440
3631	442.7577-01	Oil Level Plug	CS440
3632	873.0108-00	Seals O-Ring	CS440
3633	442.7578-01	Pipe	CS440
3634	855.0108-00	Retaining Rings	CS440
3635	840.1063-00	Screw	CS440
3636	845.0009-00	Nut	CS440
3637	452.1699-901	Main Shaft Ass Excl Mantle	CS440
3638	452.1635-901	Head Centre - Main Shaft	CS440
3639	442.7117-01	Main Shaft Sleeve	CS440
3640	853.0119-00	Pin	CS440
3641	442.7120-01	Main Shaft Step	CS440
3642	855.0026-00	Retaining Ring	CS440
3643	442.8089-01	Mantle A, M1	CS440

3644	442.8070-01	Mantle B, M1	CS440
3645	831.0016-00	Casting Compound	CS440
3646	831.0016-00	Casting Compound	CS440
3647	442.7105-00	Head Nut With Burn Ring	CS440
3648	442.8333-01	Inner Head Ring	CS440
3649	442.7115-01	Burn Ring	CS440
3650	442.7102-01	Dust Seal Ring	CS440
3651	442.7103-01	Retaining Ring	CS440
3652	442.7523-01	Retainer	CS440
3653	442.7524-01	Scraper	CS440
3654	840.0069-00	Screw	CS440
3655	840.0071-00	Screw	CS440
3656	847.0016-00	Washer	CS440
3657	442.8093-00	Top Shell Ass Excl. Crusher	CS440
3658	442.8059-01	Top Shell	CS440
3659	442.9036-01	Liner	CS440
3660	853.0979-00	Dowel	CS440
3661	442.8075-00	Arm Shield	CS440
3662	442.8077-01	Fixing Pin	CS440
3663	442.8078-01	Bumper	CS440
3664	442.8079-01	Bumper	CS440
3665	900.1262-00	Elbow Adapter	CS440
3666	900.1030-00	Bushing	CS440
3667	650.0086-11	Hose	CS440
3668	914.0093-00	Lubrication Nipple	CS440
3669	442.8090-01	Bracket	CS440
3670	840.0021-00	Screw	CS440
3671	900.0243-00	Wrought Iron Pipe Fittings Socket	CS440
3672	900.0652-00	Adapter	CS440
3673	442.9164-00	Spider Cap	CS440
3674	912.0114-00	Air Filter	CS440
3675	900.0134-00	Bushing	CS440
3676	900.2008-00	Pipe Couplings Elbow	CS440
3677	873.0838-00	Seals O-Ring	CS440
3678	840.0079-00	Screw	CS440
3679	847.0165-00	Washer	CS440
3680	442.9408-01	Spider Bushing	CS440
3681	840.0652-00	Screw	CS440

3682	847.0132-00	Washer	CS440
3683	442.7193-01	Seals O-Ring Oil Seal Ring	CS440
3684	900.0981-00	Plug Bspt 1" Hexagon	CS440
3685	442.8111-00	Crusher Chamber Ec	CS440
3686	442.8112-00	Crusher Chamber C	CS440
3687	452.1202-901	Crushing Chamber Mc	CS440
3688	452.0273-001	Concave Ring Mc	CS440
3689	442.8114-00	Concave Ring Lower M1	CS440
3690	442.8098-00	Concave Ring Lower M1	CS440
3691	452.0274-001	Concave Mc	CS440
3692	442.8115-00	Concave Upper	CS440
3693	442.8099-00	Concave Upper	CS440
3694	831.0016-00	Casting Compound	CS440
3695	831.0016-00	Casting Compound	CS440
3696	831.0016-00	Casting Compound	CS440
3697	442.8082-00	Hydroset System	CS440
3698	442.7255-92	Wrench And Tool Set	CS440
3699	442.7255-91	Wrench And Tool Set	CS440
3700	442.7255-90	Wrench And Tool Set	CS440
3701	442.7140-00	Liner-Pin Shaft Arm	CS440
3702	442.7141-01	Liner-Narrow Arm	CS440
3703	442.8794-01	Wearing Plates	CS440
3704	442.8798-01	Wearing Plates	CS440
3705	442.8797-01	Wearing Plates	CS440
3706	442.8796-01	Wearing Plates	CS440
3707	442.8795-01	Wearing Plates	CS440
3708	452.0239-001	Wearing Plates	CS440
3709	452.0238-001	Wearing Plates	CS440
3710	804.0004-00	Rod	CS440
3711	840.0049-00	Screw	CS440
3712	847.0059-00	Washer	CS440
3713	442.8106-00	Feed Hopper Complete	CS440
3714	442.8105-00	Feed Hopper	CS440
3715	840.0080-00	Screw	CS440
3716	845.0010-00	Nut	CS440
3717	847.0132-00	Washer	CS440
3718	442.6635-00	Rubber Compression Mounting For	CS440
3719	845.0387-00	Nut Lock	CS440

3720	847.0124-00	Washer	CS440
3721	442.9779-00	Top Plate	CS440
3722	864.0046-00	Rubber Compression Mounting	CS440
3723	840.0044-00	Screw	CS440
3724	847.0147-00	Washer	CS440
3725	442.9780-00	Fixing Plate, Lower	CS440
3726	442.6635-90	Rubber Compression Mountings	CS440
3727	864.0070-00	Rubber Compression Mounting	CS440
3728	840.0044-00	Screw	CS440
3729	847.0147-00	Washer	CS440
3730	442.9780-00	Fixing Plate, Lower	CS440
3731	840.0048-00	Screw	CS440
3732	845.0030-00	Nut	CS440
3733	442.6908-01	Bushing	CS440
3734	873.0390-00	Seal Ring	CS440
3735	900.0648-00	Adapter	CS440
3736	873.0386-00	Seal Ring	CS440
3737	442.8080-01	Connection Piece	CS440
3738	900.0655-00	Adapter R 3/4"	CS440
3739	873.0385-00	Seal Ring	CS440
3740	650.0154-00	Hose	CS440
3741	442.2100-01	Bracket	CS440
3742	900.0746-00	Clamp	CS440
3743	840.0013-00	Screw	CS440
3744	845.0004-00	Nut	CS440
3745	442.8645-00	Hose Guard	CS440
3746	900.0810-00	Bushing	CS440
3747	902.0605-00	Bleeder Valve	CS440
3748	847.0060-00	Washer T	CS440
3749	919.0231-00	Adapter	CS440
3750	442.8642-00	Over Pressure Unit	CS440
3751	442.8642-90	Over Pressure Unit For Compressed Air	CS440
3752	900.1424-00	Hose Coupling	CS440
3753	900.1358-00	Clips	CS440
3754	819.0187-00	Hose 1	CS440
3755	900.0040-00	Tee	CS440
3756	900.0365-00	Hexagon Nippel	CS440
3757	900.0022-00	Elbow	CS440

3758	900.1139-00	Clip	CS440
3759	900.0005-00	Elbow	CS440
3760	442.9325-00	Over Pressure Fan	CS440
3761	912.0138-00	Air Filter Purolator	CS440
3762	900.0108-00	Wrought Iron Pipe Fittings	CS440
3763	900.0209-00	Plug	CS440
3764	900.0022-00	Elbow	CS440
3765	900.1139-00	Clip	CS440
3766	900.0005-00	Elbow	CS440
3767	900.0180-00	Nipple	CS440
3768	912.0113-00	Air Filter	CS440
3769	900.0169-00	Nipple	CS440
3770	902.0645-00	Regulator	CS440
3771	900.0182-00	Nipple	CS440
3772	900.0054-00	Tee	CS440
3773	900.0209-00	Plug	CS440
3774	923.0267-00	Pressure Gauge	CS440
3775	900.0172-00	Nipple	CS440
3776	442.9950-00	Belt Driving	CS440
3777	879.0359-00	V-Belt Pulley	CS440
3778	869.0235-00	Bushing	CS440
3779	857.0336-00	Key	CS440
3780	442.9951-00	Distance	CS440
3781	442.7238-01	Washer	CS440
3782	847.0016-00	Washer	CS440
3783	840.0065-00	Screw	CS440
3784	879.0511-00	V-Belt Pulley	CS440
3785	442.9942-00	V-Belt Drive	CS440
3786	869.0329-00	Bushing	CS440
3787	442.7238-00	Washer	CS440
3788	847.0016-00	Washer	CS440
3789	840.0067-00	Screw	CS440
3790	879.0617-00	V-Belt Pulley	CS440
3791	879.0625-00	V-Belt Pulley	CS440
3792	857.0209-00	Key	CS440
3793	442.8735-01	Bottom Shell	CS660
3794	442.8860-00	Foot Assembly	CS660
3795	840.0669-00	Screw	CS660

3796	847.0124-00	Washer	CS660
3797	442.7201-00	Cover	CS660
3798	843.1267	Stud Screw	CS660
3799	847.0147-00	Washer	CS660
3800	845.0030-00	Lock Nut	CS660
3801	442.8760-00	Liner-Pin Shaft Arm	CS660
3802	442.8759-00	Liner-Narrow Arm	CS660
3803	900.2108-00	Elbow	CS660
3804	442.8742-01	Bottom Shell Bushing	CS660
3805	853.0464-00	Pin	CS660
3806	900.0921-00	Swivel Branch Tee Adapter	CS660
3807	900.1412-00	Pipes Pipe	CS660
3808	900.0276-00	Cover	CS660
3809	442.9039-00	Liners In Bottom Shell	CS660
3810	442.8741-01	Dust Collar	CS660
3811	840.0634-00	Screw	CS660
3812	442.8744-01	Ring	CS660
3813	853.0464-00	Pin	CS660
3814	840.0943-00	Screw	CS660
3815	847.0016-00	Washer	CS660
3816	442.8762-01	Locating Bar	CS660
3817	442.8809-01	Shim	CS660
3818	442.8809-02	Shim	CS660
3819	442.8809-03	Shim	CS660
3820	442.8809-04	Shim	CS660
3821	840.0019-00	Screws	CS660
3822	442.8808-01	Gasket	CS660
3823	442.8747-01	Seal Ring Inner	CS660
3824	840.0072-00	Screw	CS660
3825	847.0060-00	Washer	CS660
3826	840.1073-00	Screw	CS660
3827	845.0322-00	Nut	CS660
3828	847.0171-00	Washer	CS660
3829	899.0278-00	Protective Cap	CS660
3830	442.7243-01	Screw	CS660
3831	899.0278-00	Protective Cap	CS660
3832	442.8973-01	Eccentric	CS660
3833	442.9033-01	Eccentric Bushing	CS660

3834	442.8729-01	Hub	CS660
3835	442.8743-00	Ring	CS660
3836	840.0066-00	Screw	CS660
3837	847.0016-00	Washer	CS660
3838	442.9610-01	Key	CS660
3839	841.0028-00	Screw	CS660
3840	841.0025-00	Screw	CS660
3841	847.0180-00	Washer	CS660
3842	442.8723-00	Gear And Pinion Set	CS660
3843	442.8807-01	Key	CS660
3844	442.8761-01	Ecc. Wearing Plate	CS660
3845	853.0646-00	Pin Prym	CS660
3846	442.8722-01	Hydroset Cylinder	CS660
3847	840.0672-00	Screw	CS660
3848	847.0124-00	Washer	CS660
3849	442.8724-01	Hydroset Cyl. Bushing	CS660
3850	840.0019-00	Screws	CS660
3851	847.0012-00	Washer	CS660
3852	873.1152-00	O-Ring	CS660
3853	442.8758-00	Piston	CS660
3854	853.0119-00	Pin	CS660
3855	442.8730-01	Piston Wearing Plate	CS660
3856	442.8731-01	Step Washer	CS660
3857	442.8739-00	Chevron Packing	CS660
3858	442.8725-01	Packing Clamp Plate	CS660
3859	841.0266-00	Screw	CS660
3860	442.8726-01	Hydroset Cyl. Cover	CS660
3861	840.0674-00	Screw	CS660
3862	847.0124-00	Washer	CS660
3863	902.0605-00	Air Bleeder Valve	CS660
3864	873.1153-00	O-Ring	CS660
3865	873.1277-00	O-Ring	CS660
3866	442.8783-01	Plug	CS660
3867	873.0111-00	O-Ring	CS660
3868	840.0023-00	Screws	CS660
3869	847.0012-00	Washer	CS660
3870	840.0019-00	Screws	CS660
3871	442.8847-00	Pinion Shaft Housing Ass	CS660

3872	442.8764-01	Pinion Shaft Housing	CS660
3873	442.8803-01	Gasket	CS660
3874	442.8803-02	Gasket	CS660
3875	442.8803-03	Gasket	CS660
3876	442.8723-02	Pinion	CS660
3877	868.0799-00	Bearing	CS660
3878	868.0806-00	Bearing	CS660
3879	442.8771-01	Spacer	CS660
3880	442.8771-01	Spacer	CS660
3881	873.0128-00	O-Ring	CS660
3882	873.0128-00	O-Ring	CS660
3883	873.1161-00	Oil Seal Ring	CS660
3884	873.1161-00	Oil Seal Ring	CS660
3885	442.8766-01	Plate	CS660
3886	442.8765-01	Plate	CS660
3887	840.0035-00	Screw	CS660
3888	847.0144-00	Washer	CS660
3889	840.0067-00	Screw	CS660
3890	847.0016-00	Washer	CS660
3891	442.8775-01	Gasket	CS660
3892	442.8774-01	Gasket	CS660
3893	442.8774-02	Gasket	CS660
3894	853.0590-00	Spring Pin Prym N 8X28	CS660
3895	442.8772-01	Pinion Shaft	CS660
3896	857.0350-00	Key	CS660
3897	900.0022-00	Elbow	CS660
3898	900.2026-00	Magnetic Plug	CS660
3899	442.8778-01	Oil Level Plug	CS660
3900	873.0108-00	Seals O-Ring	CS660
3901	442.7578-01	Pipe	CS660
3902	855.0132-00	Retaining Ring	CS660
3903	840.1063-00	Screw	CS660
3904	845.0009-00	Nut	CS660
3905	452.1700-901	Huvudaxel Monterad Exkl. Mantel	CS660
3906	452.1640-901	Main Shaft - Head Centre	CS660
3907	442.8792-01	Main Shaft Sleeve	CS660
3908	853.0119-00	Pin	CS660
3909	442.8732-01	Main Shaft Step	CS660

3910	855.0026-00	Retaining Ring	CS660
3911	442.8982-01	Mantle A	CS660
3912	442.8983-01	Mantle B	CS660
3913	831.0016-00	Casting Compound	CS660
3914	442.8800-00	Head Nut With Burn Ring	CS660
3915	442.8791-01	Inner Head Nut	CS660
3916	452.0269-001	Burning Ring	CS660
3917	442.8802-01	Dust Seal Ring	CS660
3918	442.8801-01	Retaining Ring	CS660
3919	442.8804-01	Retainer	CS660
3920	442.8805-01	Scraper	CS660
3921	840.0069-00	Screw	CS660
3922	840.0071-00	Screw	CS660
3923	847.0016-00	Washer	CS660
3924	442.9076-00	Top Shell Asm. Excl. Concave Ring	CS660
3925	442.8970-01	Top Shell	CS660
3926	442.8975-01	Rim Liner	CS660
3927	853.0983-00	Bar	CS660
3928	442.8976-01	Arm Shield	CS660
3929	853.0984-00	Bar	CS660
3930	900.1262-00	Elbow Adapter	CS660
3931	900.1030-00	Bushing	CS660
3932	650.0086-19	Hose	CS660
3933	914.0093-00	Lubrication Nipple	CS660
3934	442.9086-01	Bracket	CS660
3935	840.0021-00	Screw	CS660
3936	840.1124-00	Screw	CS660
3937	845.0322-00	Nut	CS660
3938	847.0171-00	Washer	CS660
3939	442.9172-01	Clamping Bar	CS660
3940	899.0278-00	Protective Cap	CS660
3941	900.0243-00	Wrought Iron Pipe Fittings Socket Rp	CS660
3942	900.0652-00	Adapter	CS660
3943	442.7243-01	Screw	CS660
3944	899.0278-00	Protective Cap	CS660
3945	442.9077-00	Spider Asm. Incl. Liners	CS660
3946	442.8969-00	Spider	CS660
3947	442.8753-01	Spider Cap	CS660

3948	912.0114-00	Air Filter	CS660
3949	900.0243-00	Wrought Iron Pipe Fittings Socket Rp	CS660
3950	873.1160-00	O-Ring	CS660
3951	840.0650-00	Screw	CS660
3952	847.0165-00	Washer	CS660
3953	442.8977-01	Spider Bowl	CS660
3954	853.0985-00	Bar	CS660
3955	877.0350-00	Schackle	CS660
3956	877.0351-00	Chain	CS660
3957	877.0352-00	Chain Joint	CS660
3958	442.8754-01	Spider Bushing	CS660
3959	840.0652-00	Screw	CS660
3960	847.0132-00	Washer	CS660
3961	442.8755-01	Oil Seal Ring	CS660
3962	900.0981-00	Plug Bspt 1" Hexagon	CS660
3963	442.9078-00	Crushing Chamber Ec	CS660
3964	442.9079-00	Crushing Chamber C	CS660
3965	442.8979-00	Concave Ring	CS660
3966	442.9071-00	Concave Ring C, Lower	CS660
3967	442.8981-00	Concave Ring Ec, Upper	CS660
3968	442.9072-00	Concave Ring C, Upper	CS660
3969	831.0016-00	Casting Compound	CS660
3970	831.0016-00	Casting Compound	CS660
3971	442.8985-00	Hydroset	CS660
3972	442.8877-90	Wrench And Tool Set	CS660
3973	442.8760-00	Liner-Pin Shaft Arm	CS660
3974	442.8759-01	Liner-Narrow Arm	CS660
3975	442.9040-01	Wearing Plate	CS660
3976	442.9041-01	Wearing Plate	CS660
3977	442.9042-01	Wearing Plate	CS660
3978	442.9043-01	Wearing Plate	CS660
3979	804.0004-00	Rod	CS660
3980	847.0059-00	Washer	CS660
3981	840.0049-00	Screw	CS660
3982	442.8978-00	Feed Hopper	CS660
3983	840.0532-00	Screw	CS660
3984	845.0203-00	Lock Nut	CS660
3985	847.0132-00	Washer	CS660

3986	847.0197-00	Washer	CS660
3987	840.1135-00	Screw	CS660
3988	847.0132-00	Washer	CS660
3989	442.5904-01	Fixing Plate	CS660
3990	840.0078-00	Screw	CS660
3991	845.0203-00	Nut Lock	CS660
3992	864.0046-00	Vibration Damper	CS660
3993	442.9833-01	Mounting Plate	CS660
3994	840.0049-00	Screw	CS660
3995	840.0044-00	Screw	CS660
3996	847.0147-00	Washer	CS660
3997	845.0030-00	Lock Nut	CS660
3998	864.0079-00	Rubber Compression Mounting Saw	CS660
3999	845.0273-00	Lock Nut	CS660
4000	847.0162-00	Washer	CS660
4001	442.9781-00	Top Plate	CS660
4002	864.0066-00	Rubber Compression Mounting	CS660
4003	840.1135-00	Screw	CS660
4004	847.0132-00	Washer	CS660
4005	442.5904-01	Fixing Plate	CS660
4006	840.1169-00	Screw	CS660
4007	442.6908-01	Bushing	CS660
4008	873.0390-00	Seals Tredo	CS660
4009	900.0648-00	Adapter	CS660
4010	873.0386-00	Seal Tredo	CS660
4011	442.9762-01	Connection Piece	CS660
4012	900.0655-00	Adapter	CS660
4013	873.0385-00	Tredo	CS660
4014	650.0298-01	Hydraulic Hose	CS660
4015	442.2100-01	Bracket	CS660
4016	900.0746-00	Clip	CS660
4017	840.0013-00	Screw	CS660
4018	900.0964-00	Swivel Elbow Adapter 3/4"	CS660
4019	900.0810-00	Reducing	CS660
4020	902.0605-00	Air Bleeder Valve	CS660
4021	900.2041-00	Straight Adapter	CS660
4022	442.9106-01	Support	CS660
4023	442.9109-01	Bracket	CS660

4024	442.9108-01	Wear Rubber	CS660
4025	442.8933-00	Bracket	CS660
4026	840.0048-00	Screws	CS660
4027	847.0147-00	Washer	CS660
4028	845.0030-00	Lock Nut	CS660
4029	442.8934-00	Wearing Liner	CS660
4030	442.8934-90	Wearing Liner	CS660
4031	442.9107-01	Clamp	CS660
4032	840.0065-00	Screw	CS660
4033	847.0016-00	Washer	CS660
4034	900.2163-00	Plug	CS660
4035	442.8642-00	Over Pressure Unit	CS660
4036	442.8642-90	Over Pressure Unit For Compressed Air	CS660
4037	900.1424-00	Hose Coupling	CS660
4038	900.1358-00	Clips	CS660
4039	819.0187-00	Hose	CS660
4040	900.0040-00	Tee	CS660
4041	900.0365-00	Hexagon Nippel	CS660
4042	900.0022-00	Elbow	CS660
4043	900.1139-00	Clip	CS660
4044	900.0005-00	Elbow	CS660
4045	442.9325-00	Over Pressure Fan	CS660
4046	912.0138-00	Air Filter Purolator	CS660
4047	900.0108-00	Wrought Iron Pipe Fittings	CS660
4048	900.0209-00	Plug	CS660
4049	900.0022-00	Elbow	CS660
4050	900.1139-00	Clip	CS660
4051	900.0005-00	Elbow	CS660
4052	900.0180-00	Nipple	CS660
4053	912.0113-00	Air Filter	CS660
4054	900.0169-00	Nipple	CS660
4055	902.0645-00	Regulator	CS660
4056	900.0182-00	Nipple	CS660
4057	900.0054-00	Tee	CS660
4058	900.0209-00	Plug	CS660
4059	923.0267-00	Pressure Gauge	CS660
4060	900.0172-00	Nipple	CS660
4061	879.0521-00	V-Belt Pulley	CS660

4062	869.0286-00	Bushing	CS660
4063	857.0336-00	Key	CS660
4064	442.8788-01	Spacer	CS660
4065	442.8787-01	Washer	CS660
4066	847.0016-00	Washer	CS660
4067	840.0066-00	Screw	CS660
4068	869.0330.00	Bushing	CS660
4069	857.0356-00	Key	CS660
4070	442.8787-00	Washer	CS660
4071	847.0016-00	Washer	CS660
4072	840.0066-00	Screw	CS660
4073	879.0619-00	V-Belt Pulley	CS660
4074	BG00232521	Feed Hopper	CH840
4075	452.8155-901	Feed Hopper	CH840
4076	891.4238-901	Dust Seal Strip	CH840
4077	891.4227-901	Inspection Door	CH840
4078	452.8155-901	Feed Hopper Assembly	CH840
4079	452.7771-901	Inspection Door	CH840
4080	452.7976-901	Locking Device	CH840
4081	452.7970-001	Angle Plate, Stop And Protect	CH840
4082	847.0016-00	Washer	CH840
4083	845.0215-00	Lock Nut	CH840
4084	840.0068-00	Screw	CH840
4085	840.0070-00	Screw	CH840
4086	891.4226-001	Inspection Door	CH840
4087	845.0030-00	Lock Nut	CH840
4088	840.0046-00	Screw	CH840
4089	891.0401-004	Rubber Plug	CH840
4090	452.7771-901	Inspection Door Feed Hopper	CH840
4091	452.7725-001	Door Feed Hopper	CH840
4092	452.7951-001	Flange, Tube Door Feed Hopper	CH840
4093	452.7950-001	Dowel Pin Door Feed Hopper	CH840
4094	847.0016-00	Washer	CH840
4095	840.0070-00	Screw	CH840
4096	452.7976-901	Locking Device, Feed Hopper Door	CH840
4097	452.7950-001	Dowel Pin, Feed Hopper Door	CH840
4098	452.7860-001	Screw	CH840
4099	847.0016-00	Washer	CH840

4100	452.7951-00	Tube Flange, Feed Hopper Door	CH840
4101	853.0561-00	Spiral Pin	CH840
4102	452.8167-901	Cone Ec Steel Plate Liners	CH840
4103	452.7605-901	Cone C Steel Plate Liners	CH840
4104	452.7606-901	Cone Mc Steel Plate Liners	CH840
4105	452.8186-901	Cone Ec Rubber	CH840
4106	452.8184-901	Cone C Rubber	CH840
4107	452.8185-901	Cone Mc Rubber	CH840
4108	452.8167-901	Cone Ec Steel Plate Liners Kit	CH840
4109	452.7604-901	Liner Bracket Ec Cone	CH840
4110	452.8308-901	Liner Cone Ec Steel Plate Liners	CH840
4111	452.7605-901	Cone C Steel Plate Liners Kit	CH840
4112	452.7890-901	Liner Bracket C Cone	CH840
4113	452.8311-901	Liner Cone C Steel Plate Liners	CH840
4114	452.7606-901	Cone Mc Steel Plate Liners Kit	CH840
4115	452.7888-901	Liner Bracket Mc Cone	CH840
4116	452.8312-901	Liner Cone Mc Steel Plate Liners As	CH840
4117	452.8308-901	Liner Cone Ec Steel Plate Liners	CH840
4118	452.7412-001	Liner Cone Ec	CH840
4119	847.0147-00	Washer, Round	CH840
4120	845.0030-00	Lock Nut	CH840
4121	452.8311-901	Liner Cone C Steel Plate Liners	CH840
4122	452.7413-001	Liner Cone C	CH840
4123	847.0147-00	Washer, Round	CH840
4124	845.0030-00	Lock Nut	CH840
4125	452.8312-901	Liner Cone Mc Steel Plate Liners	CH840
4126	452.7402-001	Liner Cone Mc	CH840
4127	847.0147-00	Washer, Round	CH840
4128	845.0030-00	Lock Nut	CH840
4129	452.8186-901	Cone Ec Rubber Kit	CH840
4130	452.7604-901	Liner Bracket Ec Cone	CH840
4131	891.4234-901	Liner Cone Ec Assembly	CH840
4132	452.8184-901	Cone C Rubber Kit	CH840
4133	452.7890-901	Liner Bracket C Cone	CH840
4134	891.4233-901	Liner Cone C Assembly	CH840
4135	452.8185-901	Cone Mc Rubber Kit	CH840
4136	452.7888-901	Liner Bracket Mc Cone	CH840
4137	891.4237-901	Liner Cone Mc Assembly	CH840

4138	891.4234-901	Liner Cone Ec Rubber Assembly	CH840
4139	891.4235-901	Liner Cone Ec	CH840
4140	847.0147-00	Washer, Round	CH840
4141	845.0030-00	Lock Nut	CH840
4142	840.0047-00	Screw	CH840
4143	891.0401-004	Rubber Plug	CH840
4144	891.4233-901	Liner Cone C Rubber Assembly	CH840
4145	891.4232-901	Liner Cone C	CH840
4146	847.0147-00	Washer, Round	CH840
4147	845.0030-00	Lock Nut	CH840
4148	840.0047-00	Screw	CH840
4149	891.0401-004	Rubber Plug	CH840
4150	452.7840-901	Liner Wear Elements	CH840
4151	452.7855-901	Upper Assembly, Left	CH840
4152	452.7859-901	Upper Assembly, Right	CH840
4153	891.4231-901	Hopper Lining Assembly	CH840
4154	840.0068-00	Screw	CH840
4155	847.0376-00	Washer	CH840
4156	891.4231-901	Hopper Lining Assembly	CH840
4157	891.4231-001	Hopper Lining	CH840
4158	843.1323-00	Bolt Mvbf	CH840
4159	891.0462-001	Washer, Square	CH840
4160	845.0030-00	Lock Nut	CH840
4161	847.0147-00	Washer, Round	CH840
4162	891.0401-004	Rubber Plug	CH840
4163	BG00212941	Feed Distributor Kit	CH840
4164	452.7958-901	Cover And Splitter Kit	CH840
4165	BG00212941	Feed Distributor Kit	CH840
4166	BG00214755	Flanged Plate, Left	CH840
4167	BG00216301	Flanged Plate, Right	CH840
4168	BG00214791	Bracket	CH840
4169	BG00214868	Attachment Bracket, Left	CH840
4170	BG00215231	Attachment Bracket, Right	CH840
4171	442.7267-00	Feed Distributor, Right	CH840
4172	442.7267-90	Feed Distributor, Left	CH840
4173	840.0071-00	Screw	CH840
4174	840.0069-00	Screw	CH840
4175	847.0060-00	Washer	CH840

4176	845.0215-00	Lock Nut	CH840
4177	840.0075-00	Screw	CH840
4178	847.0016-00	Washer	CH840
4179	847.0376-00	Washer Nordlock	CH840
4180	452.7958-901	Cover And Splitter Kit	CH840
4181	452.7959-901	Cover Kit	CH840
4182	452.7983-901	Splitter Kit	CH840
4183	452.7959-901	Cover	CH840
4184	452.7961-901	Cover	CH840
4185	840.0068-00	Screw	CH840
4186	847.0016-00	Washer	CH840
4187	845.0009-00	Nut	CH840
4188	840.0070-00	Screw	CH840
4189	847.0376-00	Washer Nordlock	CH840
4190	452.7983-901	Splitter	CH840
4191	452.7984-901	Adjusting Unit	CH840
4192	840.0650-00	Screw	CH840
4193	847.0359-00	Washer	CH840
4194	452.7998-001	Clamping Plate	CH840
4195	452.8361-901	Top Shell Assembly Excluding Concave	CH840
4196	290.0058-901	Connection Box	CH840
4197	452.7695-001	Steel Pipe Grease/Air	CH840
4198	900.3226-00	Adapter	CH840
4199	452.7697-001	Steel Pipe Sensor	CH840
4200	900.0431-00	Pipe Joint	CH840
4201	900.0654-00	Adapter	CH840
4202	900.0169-00	Hexagon Nipple	CH840
4203	900.0002-00	Elbow	CH840
4204	912.0114-00	Air Filter Element	CH840
4205	912.0155-00	Filter Insert	CH840
4206	900.0425-00	Pipe Joint	CH840
4207	873.1585-00	O-Ring	CH840
4208	191.2376-00	Temperature Sensor	CH840
4209	900.2624-00	Nut	CH840
4210	914.0233-00	Lubrication Nipple	CH840
4211	BG00204330	Arm Shield	CH840
4212	452.8361-901	Top Shell Assembly Excluding Concave	CH840
4213	840.0638-00	Screw	CH840

4214	847.0389-00	Spherical Washer	CH840
4215	BG00240402	Washer Plate Arm Shield	CH840
4216	452.8361-902	Top Shell Assembly Including Concave	CH840
4217	290.0058-901	Connection Box	CH840
4218	452.7517-001	Wear Ring	CH840
4219	452.7547-001	Spider Bushing	CH840
4220	452.7519-001	Seal Ring	CH840
4221	452.7695-001	Steel Pipe Grease/Air	CH840
4222	900.3226-00	Adapter	CH840
4223	452.7697-001	Steel Pipe Sensor	CH840
4224	900.0431-00	Pipe Joint	CH840
4225	900.0654-00	Adapter	CH840
4226	900.0169-00	Hexagon Nipple	CH840
4227	900.0002-00	Elbow	CH840
4228	912.0114-00	Air Filter Element	CH840
4229	912.0155-00	Filter Insert	CH840
4230	900.0425-00	Pipe Joint	CH840
4231	873.1585-00	O-Ring	CH840
4232	191.2376-00	Temperature Sensor	CH840
4233	900.2624-00	Nut	CH840
4234	914.0233-00	Lubrication Nipple	CH840
4235	BG00204330	Arm Shield	CH840
4236	847.0359-00	Washer	CH840
4237	840.0651-00	Screw	CH840
4238	452.8361-902	Top Shell Assembly Including Concave	CH840
4239	452.7698-001	Spacer	CH840
4240	452.7700-001	Sleeve	CH840
4241	841.0641-00	Screw	CH840
4242	847.0016-00	Washer	CH840
4243	863.0058-00	Disc Spring	CH840
4244	845.0284-00	Lock Nut	CH840
4245	840.1297-00	Screw	CH840
4246	847.0251-00	Spherical Washer	CH840
4247	847.0420-00	Spherical Washer	CH840
4248	840.0069-00	Screw	CH840
4249	840.0712-00	Screw	CH840
4250	847.0162-00	Washer	CH840
4251	442.7179-01	Locating Block	CH840

4252	452.7534-901	Spider Cap	CH840
4253	840.0638-00	Screw	CH840
4254	847.0389-00	Spherical Washer	CH840
4255	BG00240402	Washer Plate, Arm Shield	CH840
4256	845.0322-00	Nut	CH840
4257	847.0171-00	Washer	CH840
4258	840.1090-00	Screw	CH840
4259	442.9530-01	Screw	CH840
4260	899.0278-00	Protecting Cap	CH840
4261	452.8365-901	Fastener Kit For Concave And Filler	CH840
4262	452.7698-001	Spacer	CH840
4263	452.7700-001	Sleeve	CH840
4264	863.0058-00	Disc Spring	CH840
4265	845.0284-00	Lock Nut	CH840
4266	840.1297-00	Screw	CH840
4267	847.0251-00	Spherical Washer	CH840
4268	847.0420-00	Spherical Washer	CH840
4269	840.0712-00	Screw	CH840
4270	847.0162-00	Washer	CH840
4271	442.7179-01	Locating Block	CH840
4272	452.7671-001	Ring	CH840
4273	873.1584-00	O-Ring	CH840
4274	840.1010-00	Screw	CH840
4275	863.0070-00	Spring	CH840
4276	840.0653-00	Screw	CH840
4277	847.0147-00	Washer, Round	CH840
4278	847.0359-00	Washer	CH840
4279	452.7386-001	Filler Ring, F	CH840
4280	452.7388-001	Filler Ring, Mc	CH840
4281	452.8600-001	Concave	CH840
4282	452.8600-002	Concave	CH840
4283	452.8600-003	Concave	CH840
4284	452.8600-005	Concave	CH840
4285	BG01487095-01	Concave	CH840
4286	BG01487095-02	Concave	CH840
4287	BG01487095-03	Concave	CH840
4288	BG01487095-05	Concave	CH840
4289	BG01487655-01	Concave	CH840

4290	BG01487655-02	Concave	CH840
4291	BG01487655-03	Concave	CH840
4292	BG01487655-05	Concave	CH840
4293	452.8496-001	Concave	CH840
4294	452.8496-002	Concave	CH840
4295	452.8496-003	Concave	CH840
4296	452.8496-005	Concave	CH840
4297	452.8500-001	Concave	CH840
4298	452.8500-002	Concave	CH840
4299	452.8500-003	Concave	CH840
4300	452.8500-005	Concave	CH840
4301	452.7843-001	Concave	CH840
4302	452.7843-002	Concave	CH840
4303	452.7843-003	Concave	CH840
4304	452.7843-005	Concave	CH840
4305	BG00204330	Arm Shield	CH840
4306	840.0638-00	Screw	CH840
4307	BG00240402	Washer Plate Arm Shield	CH840
4308	847.0389-00	Spherical Washer	CH840
4309	452.7534-901	Spider Cap Assembly	CH840
4310	840.0622-00	Screw	CH840
4311	900.1933-00	Plug	CH840
4312	BG01121677	Main Shaft Assembly Excluding Mantle	CH840
4313	452.7443-001	Head Nut, Inner	CH840
4314	855.0026-00	Retaining Ring	CH840
4315	853.0119-00	Pin	CH840
4316	BG00475833	Main Shaft Sleeve	CH840
4317	BG00510051	Main Shaft Cover	CH840
4318	841.0658-00	Screw	CH840
4319	BG01119160	Transportation Rack	CH840
4320	899.0523-00	Eye Bolt	CH840
4321	840.0069-00	Screw	CH840
4322	847.0016-00	Washer	CH840
4323	BG01179908	Main Shaft Assembly Including Mantle	CH840
4324	452.7208-901	Head Nut With Burning Ring	CH840
4325	847.0016-00	Washer	CH840
4326	840.0068-00	Screw	CH840
4327	855.0026-00	Retaining Ring	CH840

4328	452.7531-001	Dust Seal Ring	CH840
4329	452.7685-001	Distance	CH840
4330	452.7537-001	Scraper	CH840
4331	452.7538-001	Retainer	CH840
4332	452.7329-001	Retaining Ring	CH840
4333	452.7443-001	Head Nut, Inner	CH840
4334	841.0658-00	Screw	CH840
4335	BG00510051	Main Shaft Cover	CH840
4336	BG00475833	Main Shaft Sleeve	CH840
4337	847.0147-00	Washer, Round	CH840
4338	840.0052-00	Screw	CH840
4339	840.0045-00	Screw	CH840
4340	853.0119-00	Pin	CH840
4341	BG01119160	Transportation Rack	CH840
4342	899.0523-00	Eye Bolt	CH840
4343	840.0069-00	Screw	CH840
4344	452.7208-901	Head Nut With Burning Ring	CH840
4345	452.7467-001	Burning Ring	CH840
4346	873.0720-00	Protection Plug	CH840
4347	452.7626-001	Mantle A	CH840
4348	452.7626-002	Mantle A	CH840
4349	452.7626-003	Mantle A	CH840
4350	452.7626-005	Mantle A	CH840
4351	452.8602-001	Mantle B	CH840
4352	452.8602-002	Mantle B	CH840
4353	452.8602-003	Mantle B	CH840
4354	452.8602-005	Mantle B	CH840
4355	BG00133846-01	Mantle	CH840
4356	BG00133846-02	Mantle	CH840
4357	BG00133846-03	Mantle	CH840
4358	BG00133846-05	Mantle	CH840
4359	452.7191-901	Dust Collar Assembly	CH840
4360	452.7313-001	Dust Collar	CH840
4361	452.7295-001	Locating Bar	CH840
4362	452.7612-001	Seal Ring	CH840
4363	847.0012-00	Washer	CH840
4364	840.0025-00	Screw	CH840
4365	840.0070-00	Screw	CH840

4366	847.0016-00	Washer	CH840
4367	873.1583-00	O-Ring	CH840
4368	840.0634-00	Screw	CH840
4369	900.2673-00	Plug	CH840
4370	452.7712-001	Shim	CH840
4371	452.7712-002	Shim	CH840
4372	452.7712-003	Shim	CH840
4373	452.7712-004	Shim	CH840
4374	452.7712-005	Shim	CH840
4375	452.8342-901	Locating Bar Kit	CH840
4376	847.0012-00	Washer	CH840
4377	840.0025-00	Screw	CH840
4378	452.7295-001	Locating Bar	CH840
4379	452.7712-001	Shim	CH840
4380	452.7712-002	Shim	CH840
4381	452.7712-003	Shim	CH840
4382	452.7712-004	Shim	CH840
4383	452.7712-005	Shim	CH840
4384	BG01178428	Eccentric After Market Assembly	CH840
4385	BG01082864	Eccentric	CH840
4386	853.0617-00	Spiral Pin	CH840
4387	BG01078588-03	Eccentric Bushing, Throw	CH840
4388	452.7328-001	Key	CH840
4389	BG00906973	Hub	CH840
4390	452.7271-001	Counterweight	CH840
4391	847.0132-00	Washer, Round	CH840
4392	840.0658-00	Screw	CH840
4393	840.0650-00	Screw	CH840
4394	841.0026-00	Screw	CH840
4395	847.0147-00	Washer, Round	CH840
4396	BG00583004	Eccentric Retainer	CH840
4397	847.0012-00	Washer	CH840
4398	840.0025-00	Screw	CH840
4399	452.7203-901	Gear And Pinion Set	CH840
4400	841.0518-00	Screw	CH840
4401	BG01178421	Eccentric After Market Assembly	CH840
4402	BG01082864	Eccentric	CH840
4403	853.0617-00	Spiral Pin	CH840

4404	BG01078588-02	Eccentric Bushing, Throw	CH840
4405	452.7328-001	Key	CH840
4406	BG00906973	Hub	CH840
4407	452.7271-001	Counterweight	CH840
4408	847.0132-00	Washer, Round	CH840
4409	840.0658-00	Screw	CH840
4410	840.0650-00	Screw	CH840
4411	841.0026-00	Screw	CH840
4412	847.0147-00	Washer, Round	CH840
4413	BG00583004	Eccentric Retainer	CH840
4414	847.0012-00	Washer	CH840
4415	840.0025-00	Screw	CH840
4416	452.7203-901	Gear And Pinion Set	CH840
4417	841.0518-00	Screw	CH840
4418	BG01178367	Eccentric After Market Assembly	CH840
4419	BG01082864	Eccentric	CH840
4420	853.0617-00	Spiral Pin	CH840
4421	BG01078588-01	Eccentric Bushing, Throw	CH840
4422	452.7328-001	Key	CH840
4423	BG00906973	Hub	CH840
4424	452.7271-001	Counterweight	CH840
4425	847.0132-00	Washer, Round	CH840
4426	840.0658-00	Screw	CH840
4427	840.0650-00	Screw	CH840
4428	841.0026-00	Screw	CH840
4429	847.0147-00	Washer, Round	CH840
4430	BG00583004	Eccentric Retainer	CH840
4431	847.0012-00	Washer	CH840
4432	840.0025-00	Screw	CH840
4433	452.7203-901	Gear And Pinion Set	CH840
4434	841.0518-00	Screw	CH840
4435	BG01078588-01	Eccentric Bushing Throw	CH840
4436	BG01078588-02	Eccentric Bushing Throw	CH840
4437	BG01078588-03	Eccentric Bushing Throw	CH840
4438	452.7203-901	Gear And Pinion Set Assembly	CH840
4439	452.8354-901	Bottom Shell Assembly With Steel Plate	CH840
4440	452.7738-901	Arm Liner Assembly	CH840
4441	452.7406-001	Foot	CH840

4442	847.0124-00	Washer	CH840
4443	840.0671-00	Screw	CH840
4444	842.0288-00	Screw	CH840
4445	853.0617-00	Spiral Pin	CH840
4446	891.4075-901	Inspection Door Assembly	CH840
4447	452.7746-001	Dolly	CH840
4448	841.0269-00	Screw	CH840
4449	BG01122286	Transportation Rack	CH840
4450	899.0542-00	Double Swivel Shackle With Nut	CH840
4451	BG01282107	Dust Seal Air Pressure Installation	CH840
4452	900.2547-00	Plug	CH840
4453	923.0584-00	Temperature Sensor	CH840
4454	BG00779564	Counter Nut	CH840
4455	BG01208014	Sign	CH840
4456	853.0645-00	Spiral Pin Prym	CH840
4457	BG01074558	Bottom Shell Bushing	CH840
4458	452.7275-001	Eccentric Wearing Plate	CH840
4459	873.0615-00	O-Ring	CH840
4460	452.8354-902	Bottom Shell Assembly With Rubber	CH840
4461	452.7738-901	Arm Liners	CH840
4462	452.7406-001	Foot	CH840
4463	847.0124-00	Washer	CH840
4464	840.0671-00	Screw	CH840
4465	842.0288-00	Screw	CH840
4466	853.0617-00	Spiral Pin Prym	CH840
4467	891.4075-901	Inspection Door Assembly	CH840
4468	452.7746-001	Dolly	CH840
4469	841.0269-00	Screw	CH840
4470	BG01122286	Transportation Rack	CH840
4471	899.0542-00	Double Swivel Shackle	CH840
4472	BG01282107	Dust Seal Air Pressure Installation	CH840
4473	900.2547-00	Plug	CH840
4474	923.0584-00	Temperature Sensor	CH840
4475	BG00779564	Counter Nut	CH840
4476	BG01208014	Sign	CH840
4477	853.0645-00	Spiral Pin	CH840
4478	BG01074558	Bottom Shell Bushing	CH840
4479	452.7275-001	Eccentric Wearing Plate	CH840

4480	873.0615-00	O-Ring	CH840
4481	452.7738-901	Arm Liner Bottom Shell Assembly	CH840
4482	452.7076-001	Arm Liner Pinion Shaft	CH840
4483	452.7077-001	Arm Liners	CH840
4484	452.7603-001	Washer Plate	CH840
4485	845.0455-00	Nut	CH840
4486	840.1299-00	Screw Fine	CH840
4487	452.7693-001	Shim Arm Liner Bottom Shell	CH840
4488	891.2879-001	Washer Plate	CH840
4489	891.2880-001	Rubber Washer	CH840
4490	BG00174603	Steel Plate Lining Bottom Shell	CH840
4491	BG00162786	Steel Plate Liner Bottom Shell, First	CH840
4492	BG00167315	Steel Plate Liner Bottom Shell, First	CH840
4493	BG00162736	Steel Plate Liner Bottom Shell, Second	CH840
4494	843.1616-00	Bolt	CH840
4495	891.2880-001	Rubber Washer	CH840
4496	891.2879-001	Washer Plate	CH840
4497	845.0030-00	Lock Nut	CH840
4498	891.2850-901	Rubber Lining Bottom Shell Assembly	CH840
4499	891.2845-901	Rubber Lining, First Plain	CH840
4500	891.2846-901	Rubber Lining, First Hole	CH840
4501	891.2847-901	Rubber Lining, Second	CH840
4502	843.1616-00	Bolt	CH840
4503	891.0401-004	Rubber Plug	CH840
4504	891.2879-001	Washer Plate	CH840
4505	845.0030-00	Lock Nut	CH840
4506	891.2880-001	Rubber Washer	CH840
4507	891.4075-901	Inspection Door Pu	CH840
4508	891.2447-901	Inspection Door Pu	CH840
4509	891.4074-001	Screw	CH840
4510	BG01282107	Dust Seal Air Pressure Installation	CH840
4511	BG00175086	Over-Pressure Air Line	CH840
4512	BG00213134	Air End	CH840
4513	BG01281750	Air Bracket	CH840
4514	847.0164-00	Washer	CH840
4515	900.3079-00	Clamp	CH840
4516	900.2118-00	Plate, Cover	CH840
4517	847.0147-00	Washer, Round	CH840

4518	840.0044-00	Screw	CH840
4519	840.0016-00	Screw	CH840
4520	900.3235-00	Adapter, Elbow	CH840
4521	900.0778-00	Ring, Clamping	CH840
4522	BG01282190	Adapter	CH840
4523	900.3232-00	Nut Cutting Ring	CH840
4524	900.0042-00	Pipe	CH840
4525	900.3238-00	Adapter, Elbow, Adjustable	CH840
4526	900.3234-00	Adapter	CH840
4527	BG01179355	Hydroset Cylinder Assembly	CH840
4528	BG01073874	Hydroset Cylinder	CH840
4529	853.0617-00	Spiral Pin	CH840
4530	BG01113456	Protection Kit	CH840
4531	452.7318-001	Hydroset Cylinder Cover	CH840
4532	873.1576-00	O-Ring	CH840
4533	847.0124-00	Washer	CH840
4534	840.0673-00	Screw	CH840
4535	873.1577-00	O-Ring	CH840
4536	873.0388-00	Seal Ring, Tredo	CH840
4537	900.2161-00	Adapter	CH840
4538	900.3279-00	Cap	CH840
4539	873.0237-00	O-Ring	CH840
4540	452.6139-001	Flange Measure System	CH840
4541	847.0016-00	Washer	CH840
4542	840.0069-00	Screw	CH840
4543	847.0214-00	Washer	CH840
4544	840.0673-00	Screw	CH840
4545	BG00215156	Step Bearing Set	CH840
4546	452.7296-001	Piston	CH840
4547	452.7321-001	Piston Seal, Chevron Packing	CH840
4548	452.7322-001	Packing Clamping Plate	CH840
4549	841.0266-00	Screw	CH840
4550	452.7324-901	Measuring Tube Holder	CH840
4551	853.0119-00	Pin	CH840
4552	452.8371-901	Repair Kit Chevron Packing	CH840
4553	452.7321-001	Piston Seal, Chevron Packing	CH840
4554	841.0266-00	Screw	CH840
4555	452.7322-001	Packing Clamping Plate	CH840

4556	873.0237-00	O-Ring	CH840
4557	873.1577-00	O-Ring	CH840
4558	873.1576-00	O-Ring	CH840
4559	452.7324-901	Measuring Tube Holder Kit	CH840
4560	452.7325-001	Measuring Tube Holder	CH840
4561	452.7326-001	Lock Nut	CH840
4562	873.1575-00	O-Ring	CH840
4563	873.0388-00	Seal Ring, Tredo	CH840
4564	442.7559-04	Measuring Tube	CH840
4565	BG01113456	Protection Kit	CH840
4566	BG00213709	Support Rubber Cover	CH840
4567	BG01113405	Rubber, Wear	CH840
4568	BG01113388	Rubber, Wear	CH840
4569	840.0047-00	Screw	CH840
4570	847.0118-00	Washer S	CH840
4571	845.0030-00	Lock Nut	CH840
4572	847.0147-00	Washer	CH840
4573	840.0045-00	Screw	CH840
4574	BG00528284	Position Transmitter Assembly	CH840
4575	900.2292-00	Test Point	CH840
4576	BG00514564	Position Transmitter	CH840
4577	841.0628-00	Screw	CH840
4578	452.7433-001	Protecting Cover	CH840
4579	847.0147-00	Washer	CH840
4580	841.0266-00	Screw	CH840
4581	BG00514567	Cable, Pre-Wired Plug Canon	CH840
4582	BG01114132	Hydroset System	CH840
4583	BG01114134	Hose	CH840
4584	BG01114784	Cover Assembly	CH840
4585	819.0061-00	Cable Protection	CH840
4586	452.7533-001	Hydraulic Manifold	CH840
4587	847.0147-00	Washer, Round	CH840
4588	900.2302-00	Plug	CH840
4589	900.2592-00	Split Flange Clamp	CH840
4590	840.1215-00	Screw	CH840
4591	873.0755-00	O-Ring	CH840
4592	841.0268-00	Screw	CH840
4593	452.7351-001	Bracket	CH840

4594	900.2592-00	Split Flange Clamp	CH840
4595	873.0755-00	O-Ring	CH840
4596	841.0268-00	Screw	CH840
4597	847.0016-00	Washer	CH840
4598	840.0068-00	Screw	CH840
4599	873.1299-00	O-Ring	CH840
4600	900.3209-00	Plug	CH840
4601	900.2385-00	Split Flange Clamp	CH840
4602	841.0253-00	Screw	CH840
4603	900.3210-00	Plug	CH840
4604	BG01114784	Cover Assembly	CH840
4605	BG00465390	Bracket	CH840
4606	BG01114785	Rubber Cover	CH840
4607	BG00465392	Clamping Bar	CH840
4608	847.0147-00	Washer, Round	CH840
4609	840.0044-00	Screw	CH840
4610	841.0431-00	Screw	CH840
4611	BG00428222	Hydroset Relief Valve Assembly	CH840
4612	452.7403-901	Hydroset Relief Valve Sub-Assembly	CH840
4613	902.1171-00	Hydroset Relief Valve	CH840
4614	923.0584-00	Temperature Transmitter	CH840
4615	BG00514568	Pressure Transmitter	CH840
4616	BG00428218	Sign	CH840
4617	BG00428223	Sign	CH840
4618	BG00428217	Sign	CH840
4619	BG00267693	Sign	CH840
4620	BG01094613	Sign	CH840
4621	452.7403-901	Hydroset Relief Valve Sub-Assembly	CH840
4622	452.7409-001	Hydraulic Manifold	CH840
4623	452.7416-001	Hydraulic Manifold	CH840
4624	452.7427-001	Protection Cover	CH840
4625	BG01091233	Protection Plate	CH840
4626	452.7535-001	Protection Plate	CH840
4627	BG00656369	Valve	CH840
4628	BG00659033	Spring	CH840
4629	900.3230-00	Orifice	CH840
4630	902.1143-00	Valve, Needle,	CH840
4631	900.2292-00	Test Point	CH840

4632	873.1581-00	O-Ring, Kantseal	CH840
4633	873.1582-00	O-Ring, Kantseal	CH840
4634	984.1683-00	Cartridge Heater	CH840
4635	964.3173-00	Housing, Panel Mounted	CH840
4636	964.3256-00	Contact Insert	CH840
4637	BG01091578	Housing, Straight	CH840
4638	964.3257-00	Contact Insert	CH840
4639	964.2445-00	Cable Gland	CH840
4640	900.2279-00	Plug	CH840
4641	900.2859-00	Plug	CH840
4642	899.0147-00	Eye Bolt	CH840
4643	847.0016-00	Washer	CH840
4644	845.0454-00	Nut, Lock Low	CH840
4645	847.0132-00	Washer	CH840
4646	841.0309-00	Screw	CH840
4647	843.0873-00	Screw	CH840
4648	847.0147-00	Washer	CH840
4649	841.0266-00	Screw	CH840
4650	900.2637-00	Plug, Tapered	CH840
4651	900.2636-00	Plug, Tapered	CH840
4652	919.0288-00	Plug, Tapered	CH840
4653	452.7403-901	Hydroset Relief Valve Sub-Assembly	CH840
4654	452.7409-001	Hydraulic Manifold	CH840
4655	452.7416-001	Hydraulic Manifold	CH840
4656	452.7427-001	Protection Cover	CH840
4657	BG01091233	Protection Plate	CH840
4658	452.7535-001	Protection Plate	CH840
4659	BG00656369	Valve	CH840
4660	BG00659033	Spring	CH840
4661	900.3230-00	Orifice	CH840
4662	902.1143-00	Valve, Needle,	CH840
4663	900.2292-00	Test Point	CH840
4664	873.1581-00	O-Ring	CH840
4665	873.1582-00	O-Ring	CH840
4666	984.1683-00	Cartridge Heater	CH840
4667	964.3173-00	Housing, Panel	CH840
4668	964.3256-00	Contact Insert	CH840
4669	BG01091578	Housing, Straight	CH840

4670	964.3257-00	Contact Insert	CH840
4671	964.2445-00	Cable Gland	CH840
4672	900.2279-00	Plug	CH840
4673	900.2859-00	Plug	CH840
4674	899.0147-00	Eye Bolt	CH840
4675	847.0016-00	Washer	CH840
4676	845.0454-00	Nut, Lock Low	CH840
4677	847.0132-00	Washer	CH840
4678	841.0309-00	Screw	CH840
4679	843.0873-00	Screw	CH840
4680	847.0147-00	Washer	CH840
4681	841.0266-00	Screw	CH840
4682	900.2637-00	Plug, Tapered	CH840
4683	900.2636-00	Plug, Tapered	CH840
4684	919.0288-00	Plug, Tapered	CH840
4685	BG01323272	Pinion Shaft Housing Assembly	CH840
4686	BG00484613	Pinion Shaft Housing, Machined	CH840
4687	452.6990-001	Drive Shaft	CH840
4688	914.0090-00	Lubrication Nipple	CH840
4689	900.2859-00	Plug	CH840
4690	853.0590-00	Spiral Pin Prym	CH840
4691	923.0547-00	Temperature Sensor	CH840
4692	BG01283277	Level Pipe	CH840
4693	900.3180-00	Cap	CH840
4694	900.0654-00	Adapter	CH840
4695	873.0386-00	Seal Ring	CH840
4696	900.3274-00	Cap	CH840
4697	873.0385-00	Seal Ring	CH840
4698	900.0655-00	Adapter	CH840
4699	873.0382-00	Bonded Seal, Self Centering	CH840
4700	BG01323272	Pinion Shaft Housing Assembly	CH840
4701	BG00484670	Bearing Cover, Outer	CH840
4702	452.6991-001	Bearing Cover, Inner	CH840
4703	452.7005-001	Spacer, Outer	CH840
4704	452.7178-001	Spacer, Inner	CH840
4705	452.7091-001	Distance	CH840
4706	BG00484767	Plug	CH840
4707	442.7578-01	Pipe	CH840

4708	868.0282-00	Roller Bearing	CH840
4709	868.0804-00	Roller Bearing	CH840
4710	873.1573-00	Seal Ring	CH840
4711	873.1574-00	Seal Ring	CH840
4712	855.0052-00	Retaining Ring	CH840
4713	855.0108-00	Retaining Ring	CH840
4714	857.0059-00	Key	CH840
4715	857.0336-00	Key	CH840
4716	873.1569-00	O-Ring	CH840
4717	873.1570-00	O-Ring	CH840
4718	873.0108-00	O-Ring	CH840
4719	900.2859-00	Plug	CH840
4720	840.0045-00	Screw	CH840
4721	840.0068-00	Screw	CH840
4722	847.0147-00	Washer	CH840
4723	847.0016-00	Washer	CH840
4724	873.1317-00	O-Ring	CH840
4725	BG00486966	Sign	CH840
4726	873.0386-00	Seal Ring	CH840
4727	840.1155-00	Screw	CH840
4728	847.0060-00	Washer	CH840
4729	840.1289-00	Screw	CH840
4730	845.0009-00	Nut	CH840
4731	452.7114-001	Shim	CH840
4732	BG00300437	Gasket	CH840
4733	BG00579374	Pinion Shaft Housing Repair Kit	CH840
4734	452.7005-001	Spacer Outer	CH840
4735	452.7178-001	Spacer Inner	CH840
4736	452.7114-001	Shim	CH840
4737	BG00300437	Gasket	CH840
4738	868.0282-00	Roller Bearing	CH840
4739	868.0804-00	Roller Bearing	CH840
4740	873.1573-00	Seal Ring	CH840
4741	873.1574-00	Seal Ring	CH840
4742	855.0052-00	Retaining Ring	CH840
4743	855.0108-00	Retaining Ring	CH840
4744	873.1569-00	O-Ring	CH840
4745	873.1570-00	O-Ring	CH840

4746	840.1155-00	Screw	CH840
4747	847.0060-00	Washer	CH840
4748	BG00482690	Elbow	CH840
4749	900.2199-00	Split Flange Clamp	CH840
4750	847.0016-00	Washer	CH840
4751	840.0068-00	Screw	CH840
4752	873.1556-00	O-Ring	CH840
4753	900.3212-00	Plug	CH840
4754	840.0044-00	Screw	CH840
4755	900.2547-00	Plug	CH840
4756	BG00646305	Bracket, Left	CH840
4757	BG00646307	Bracket, Right	CH840
4758	BG01113539	Rubber Cover	CH840
4759	847.0118-00	Washer	CH840
4760	840.0047-00	Screw	CH840
4761	845.0030-00	Lock Nut	CH840
4762	900.2279-00	Plug	CH840
4763	847.0033-00	Spring Washer	CH840
4764	873.1556-00	O-Ring	CH840
4765	BG00498878	Hose Fitting	CH840
4766	650.0326-25	Hose	CH840
4767	BG00501806	Hose	CH840
4768	452.8457-001	Hose	CH840
4769	873.0755-00	O-Ring	CH840
4770	841.0267-00	Screw	CH840
4771	900.2592-00	Split Flange Clamp	CH840
4772	873.1299-00	O-Ring	CH840
4773	452.7930-001	Hose	CH840
4774	650.0089-34	Hose	CH840
4775	900.2090-00	Hose Clip	CH840
4776	BG01283423	Hose	CH840
4777	BG00499286	Adapters	CH840
4778	BG00499283	Adapters	CH840
4779	BG00499286	Adapters	CH840
4780	900.0659-00	Adapter	CH840
4781	900.2161-00	Adapter	CH840
4782	873.0388-00	Seal Ring	CH840
4783	873.0390-00	Seal Ring	CH840

4784	900.0648-00	Adapter	CH840
4785	900.0655-00	Adapter	CH840
4786	873.0385-00	Seal Ring	CH840
4787	442.2549-01	Connection	CH840
4788	BG00499283	Adapters	CH840
4789	442.9831-01	Adapter	CH840
4790	900.2321-00	Adapter	CH840
4791	900.2429-00	Adapter	CH840
4792	873.0388-00	Seal Ring	CH840
4793	873.0390-00	Seal Ring	CH840
4794	900.3197-00	Adapter	CH840
4795	900.2316-00	Adapter	CH840
4796	873.0385-00	Seal Ring	CH840
4797	442.9830-01	Hose Coupling	CH840
4798	BG01289733	Dust Seal Air Pressure Unit	CH840
4799	BG01282189	Dust Seal Air Pressure Connection	CH840
4800	BG01047665	Dust Seal Air Pressure Fan	CH840
4801	819.0345-00	Hose W. Steel Spiral	CH840
4802	900.2283-00	Hose	CH840
4803	452.8006-901	Filter	CH840
4804	BG01036041	Dust Seal Air Pressure Fan	CH840
4805	906.0667-00	Dust Seal Air Pressure Fan	CH840
4806	840.0021-00	Screw	CH840
4807	126.0917-001	Sign	CH840
4808	900.1427-00	Hose Coupling	CH840
4809	900.0155-00	Bushing	CH840
4810	972.2036-00	Motor	CH840
4811	972.2035-00	Motor	CH840
4812	972.1923-00	Motor	CH840
4813	972.1924-00	Motor	CH840
4814	972.1925-00	Motor	CH840
4815	BG01036041-01	Dust Seal Air Pressure Fan With	CH840
4816	BG01036041-02	Dust Seal Air Pressure Fan With 400V50/460V60 Motor	CH840
4817	BG01036041-03	Dust Seal Air Pressure Fan With	CH840
4818	BG01036041-04	Dust Seal Air Pressure Fan With	CH840
4819	BG01036041-05	Dust Seal Air Pressure Fan With	CH840
4820	BG01036041-06	Dust Seal Air Pressure Fan With	CH840

4821	BG01036041-07	Dust Seal Air Pressure Fan Without	CH840
4822	452.8006-901	Filter Assembly	CH840
4823	452.7581-001	Adapter	CH840
4824	912.0373-00	Air Filter	CH840
4825	912.0374-00	Filter Spare Part	CH840
4826	126.0843-001	Sign	CH840
4827	BG01282189	Dust Seal Air Pressure Connection	CH840
4828	900.1425-00	Hose Coupling	CH840
4829	819.0344-00	Hose	CH840
4830	900.1359-00	Hose Clip	CH840
4831	900.1140-00	Clip	CH840
4832	900.0648-00	Adapter	CH840
4833	873.0386-00	Seal Ring, Tredo	CH840
4834	902.1190-00	Flow Valve	CH840
4835	873.0385-00	Seal Ring,	CH840
4836	900.1158-00	Reducing Socket	CH840
4837	900.0655-00	Adapter	CH840
4838	BG01204382	V-Belt Drive	CH840
4839	BG01127482	Subframe, Belt Drive Ch840I/Cs840I	CH840
4840	452.4582-901	Damper, Vibration Large	CH840
4841	452.8325-901	Rubber Damper Medium	CH840
4842	BG01129051	Dust Shield	CH840
4843	BG01165800	Dust Shield	CH840
4844	873.0718-00	Strip	CH840
4845	840.0696-00	Screw	CH840
4846	847.0066-00	Washer Tbrb	CH840
4847	845.0284-00	Lock Nut	CH840
4848	452.7664-901	Drive Alternative, V-Belt	CH840
4849	936.0072-00	Bracket, Motor Iec	CH840
4850	840.0693-00	Screw	CH840
4851	BG00990330	Motor Alternatives	CH840
4852	847.0360-00	Washer	CH840
4853	840.0675-00	Screw	CH840
4854	847.0063-00	Washer	CH840
4855	845.0216-00	Lock Low	CH840
4856	BG00208755	Drive Cover	CH840
4857	BG01283755	Sensor Cover	CH840
4858	BG01464421	Inductive Sensor	CH840

4859	BG00487994	Sign	CH840
4860	906.0645-00	Pump, Hydraulic, Hand	CH840
4861	BG00616109	Potential Equalization Bar	CH840
4862	847.0031-00	Washer, Spring	CH840
4863	840.0021-00	Screw	CH840
4864	BG00695066	Distance	CH840
4865	BG01204382	V-Belt Drive	CH840
4866	BG01127482	Subframe, Belt Drive Ch840I/Cs840I	CH840
4867	452.4582-901	Vibration Damper, Large	CH840
4868	452.8325-901	Rubber Damper, Medium	CH840
4869	BG01129051	Dust Shield	CH840
4870	BG01165800	Dust Shield	CH840
4871	873.0718-00	Strip	CH840
4872	840.0696-00	Screw	CH840
4873	847.0066-00	Washer	CH840
4874	845.0284-00	Lock Nut	CH840
4875	936.0072-00	Bracket, Motor Iec	CH840
4876	840.0693-00	Screw	CH840
4877	BG00990330	Motor Alternatives	CH840
4878	847.0360-00	Washer	CH840
4879	840.0675-00	Screw	CH840
4880	847.0063-00	Washer	CH840
4881	845.0216-00	Lock Low	CH840
4882	BG00208755	Drive Cover	CH840
4883	BG01283755	Sensor Cover	CH840
4884	BG01464421	Inductive Sensor	CH840
4885	BG00487994	Sign	CH840
4886	906.0645-00	Pump, Hydraulic, Hand	CH840
4887	BG00616109	Potential Equalization Bar 6 Electrical	CH840
4888	847.0031-00	Washer, Spring	CH840
4889	840.0021-00	Screw	CH840
4890	BG00695066	Distance	CH840
4891	BG01127482	V-Belt Drive, Subframe	CH840
4892	BG00194719	Engine Plate	CH840
4893	845.0284-00	Lock Nut	CH840
4894	847.0066-00	Washer	CH840
4895	840.0692-00	Screw	CH840
4896	899.0526-00	Lifting Bracket	CH840

4897	BG00208755	Drive Cover	CH840
4898	BG00208737	Protection Hood, Drive Cover	CH840
4899	BG00208717	Sump Drive Cover	CH840
4900	BG00208735	Console, Drive Cover	CH840
4901	BG00208727	Wall, Drive Cover	CH840
4902	BG00208726	Hook Wall	CH840
4903	840.1303-00	Screw	CH840
4904	BG00208723	Cover Plate, Shaft Protection	CH840
4905	873.1623-00	Rubber Profile	CH840
4906	BG00307439	Screw, Modified	CH840
4907	853.0231-00	Split Pin	CH840
4908	BG00300483	Screw, Modified	CH840
4909	BG00990330	Motor Alternative	CH840
4910	972.1914-00	Electric Motor	CH840
4911	972.1954-00	Electric Motor	CH840
4912	972.1955-00	Electric Motor	CH840
4913	972.1956-00	Electric Motor	CH840
4914	972.2067-00	Electric Motor	CH840
4915	972.2068-00	Electric Motor	CH840
4916	936.0072-00	Motor Bracket	CH840
4917	936.0073-00	Gemex Cylinder	CH840
4918	936.0074-00	Expander Dowel Complete	CH840
4919	936.0075-00	Hydraulic Hose Set	CH840
4920	936.0076-00	Sbt Bearing	CH840
4921	936.0077-00	Axial Bearing	CH840
4922	936.0078-00	Gasket Set	CH840
4923	452.7665-901	V-Belt Drive	CH840
4924	452.7666-901	V-Belt Drive	CH840
4925	452.7667-901	V-Belt Drive	CH840
4926	452.7078-001	V-Belt Pulley	CH840
4927	869.0235-00	Bushing	CH840
4928	869.0261-00	Bushing	CH840
4929	869.0278-00	Bushing	CH840
4930	869.0295-00	Bushing	CH840
4931	869.0283-00	Bushing	CH840
4932	869.0286-00	Bushing	CH840
4933	869.0314-00	Bushing	CH840
4934	869.0410-00	Bushing	CH840

4935	869.0411-00	Bushing	CH840
4936	869.0411-00	Bushing	CH840
4937	442.7238-01	Washer	CH840
4938	847.0016-00	Washer	CH840
4939	840.0068-00	Screw	CH840
4940	875.0245-00	V-Belt	CH840
4941	452.7117-001	V-Belt Pulley	CH840
4942	841.0574-00	Screw	CH840
4943	452.7078-001	V-Belt Pulley	CH840
4944	869.0235-00	Bushing	CH840
4945	869.0261-00	Bushing	CH840
4946	869.0278-00	Bushing	CH840
4947	869.0295-00	Bushing	CH840
4948	869.0283-00	Bushing	CH840
4949	869.0286-00	Bushing	CH840
4950	869.0314-00	Bushing	CH840
4951	869.0410-00	Bushing	CH840
4952	869.0411-00	Bushing	CH840
4953	869.0411-00	Bushing	CH840
4954	442.7238-01	Washer	CH840
4955	847.0016-00	Washer	CH840
4956	840.0068-00	Screw	CH840
4957	875.0245-00	V-Belt	CH840
4958	452.7120-001	V-Belt Pulley	CH840
4959	841.0574-00	Screw	CH840
4960	452.7223-001	V-Belt Pulley	CH840
4961	869.0235-00	Bushing	CH840
4962	869.0261-00	Bushing	CH840
4963	869.0278-00	Bushing	CH840
4964	869.0295-00	Bushing	CH840
4965	869.0283-00	Bushing	CH840
4966	869.0286-00	Bushing	CH840
4967	869.0314-00	Bushing	CH840
4968	869.0410-00	Bushing	CH840
4969	869.0411-00	Bushing	CH840
4970	869.0411-00	Bushing	CH840
4971	442.7238-01	Washer	CH840
4972	847.0016-00	Washer	CH840

4973	840.0068-00	Screw	CH840
4974	875.0175-00	V-Belt	CH840
4975	452.7148-001	V-Belt Pulley	CH840
4976	841.0574-00	Screw	CH840
4977	452.4582-901	Vibration Damper, Large	CH840
4978	442.5904-01	Plate	CH840
4979	864.0066-00	Vibration Damper	CH840
4980	840.1135-00	Screw	CH840
4981	847.0132-00	Washer, Round	CH840
4982	840.0078-00	Screw	CH840
4983	845.0203-00	Lock Nut, High	CH840
4984	452.8325-901	Vibration Damper, Medium	CH840
4985	864.0124-00	Vibration Damper	CH840
4986	452.8324-001	Mounting Plate	CH840
4987	847.0016-00	Washer	CH840
4988	845.0215-00	Lock Nut	CH840
4989	840.0066-00	Screw	CH840
4990	840.0069-00	Screw	CH840
4991	BG01165800	Dust Shield	CH840
4992	BG01165660-01	Bracket	CH840
4993	BG01165660-02	Bracket	CH840
4994	BG01165789	Rubber Sheet	CH840
4995	847.0147-00	Washer	CH840
4996	845.0030-00	Nut, Lock	CH840
4997	BG01166275	Bracket	CH840
4998	BG01129051	Dust Shield Subframe Kit	CH840
4999	BG01296098	Sealing Segment, Long	CH840
5000	BG01296099	Sealing Segment, Short	CH840
5001	BG01129074-01	Retaining Plate, Long	CH840
5002	BG01129074-02	Retaining Plate, Short	CH840
5003	BG01203144	Seal Strip, Dust	CH840
5004	BG01139222	Cover	CH840
5005	847.0303-00	Washer	CH840
5006	845.0030-00	Nut, Lock	CH840
5007	847.0147-00	Washer	CH840
5008	840.0048-00	Screw	CH840
5009	BG01237188	Sign Board	CH840
5010	126.0383-001	Warning Sign, Risk Of Crushing	CH840

5011	126.0385-001	Mandatory Sign, Read Manual	CH840
5012	126.5007-01	Identification Plate	CH840
5013	885.0249-00	Sign, Center Of Gravity	CH840
5014	126.0384-001	Warning Sign, Flying Fragments	CH840
5015	126.0345-001	Sign, Patent Information	CH840
5016	885.0262-00	Plate, Lifting Chain	CH840
5017	BG01379287	Logotype Sandvik	CH840
5018	126.0818-001	Sign, Rotation Direction	CH840
5019	126.0920-001	Sign, Product Name	CH840
5020	126.0388-001	Warning Sign, Falling Fragments	CH840
5021	126.0450-001	Warning Sign, Hot Surfaces	CH840
5022	126.0785-001	Sign, Earth Connection	CH840
5023	885.0267-00	English	CH840
5024	885.0273-00	Romanian	CH840
5025	885.0267-01	Bulgarian	CH840
5026	885.0267-02	Czech	CH840
5027	885.0267-03	Danish	CH840
5028	885.0267-04	German	CH840
5029	885.0267-05	Greek	CH840
5030	885.0267-06	Spanish	CH840
5031	885.0267-07	Finnish	CH840
5032	885.0267-08	French	CH840
5033	885.0267-09	Hungarian	CH840
5034	885.0267-10	Italian	CH840
5035	885.0267-11	Lithuanian	CH840
5036	885.0267-12	Dutch	CH840
5037	885.0267-13	Norwegian	CH840
5038	885.0267-14	Polish	CH840
5039	885.0267-15	Brazilian Portuguese	CH840
5040	885.0267-16	Portuguese	CH840
5041	885.0267-17	Russian	CH840
5042	885.0267-18	Swedish	CH840
5043	885.0267-19	Turkish	CH840
5044	885.0267-20	Chinese	CH840
5045	BG01315457	Tool Kit	CH840
5046	442.9476-00	Tool Box	CH840
5047	899.0523-00	Eye Bolt	CH840
5048	899.0509-00	Eye Bolt	CH840

5049	899.0508-00	Eye Bolt	CH840
5050	899.0507-00	Eye Bolt	CH840
5051	899.0512-00	Eye Bolt	CH840
5052	920.0110-00	Tool, Slugging Wrench	CH840
5053	920.0109-00	Tool, Slugging Wrench	CH840
5054	920.0238-00	Tool, Slugging Wrench	CH840
5055	442.0800-90	Lead Cylinder	CH840
5056	923.0422-00	Feeler Gauge	CH840
5057	904.0585-00	Air Bleeder Hose	CH840
5058	BG00462596	Main Shaft Sleeve Cover	CH840
5059	BG00227711	Lifting Tool, Extractor For Step Bearing	CH840
5060	BG01197104	Lifting Tool, Bottom Shell Bushing	CH840
5061	BG00227709	Lifting Tool, Eccentric Bushing	CH840
5062	452.7712-001	Shim	CH840
5063	452.7712-002	Shim	CH840
5064	452.7712-003	Shim	CH840
5065	452.7712-004	Shim	CH840
5066	452.7712-005	Shim	CH840
5067	847.0415-00	Washer	CH840
5068	841.0503-00	Screw	CH840
5069	847.0416-00	Washer	CH840
5070	841.0041-00	Screw	CH840
5071	BG00362732	Hydraulic Pump, Main Shaft, With	CH840
5072	BG00875872	Grease Gauge	CH840
5073	BG00462596	Cover	CH840
5074	847.0415-00	Washer	CH840
5075	847.0416-00	Washer	CH840
5076	841.0041-00	Screw	CH840
5077	841.0503-00	Screw	CH840
5078	BG00362732	Hydraulic Pump Unit	CH840
5079	BG00600996	Quick Coupling	CH840
5080	914.0240-00	Hydraulic Oil, 1 Liter	CH840
5081	452.8420-901	Cone Ec Steel Plate Liners	CH840
5082	452.8415-901	Cone C Steel Plate Liners	CH840
5083	452.8417-901	Cone Mc Steel Plate Liners	CH840
5084	452.8422-901	Cone Ec Rubber	CH840
5085	452.8416-901	Cone C Rubber	CH840
5086	452.8418-901	Cone Mc Rubber	CH840

5087	452.7388-001	Filler Ring Mc/C	CH840
5088	452.7386-001	Filler Ring M/F	CH840
5089	452.7671-001	Ring	CH840
5090	873.1584-00	O-Ring	CH840
5091	840.0019-00	Screw	CH840
5092	863.0070-00	Spring	CH840
5093	840.0653-00	Screw	CH840
5094	847.0012-00	Washer	CH840
5095	847.0359-00	Washer	CH840
5096	452.7843-001	Concave Ec	CH840
5097	452.7843-002	Concave Ec	CH840
5098	452.7843-003	Concave Ec	CH840
5099	452.7843-005	Concave Ec	CH840
5100	452.8500-001	Concave C	CH840
5101	452.8500-002	Concave C	CH840
5102	452.8500-003	Concave C	CH840
5103	452.8500-005	Concave C	CH840
5104	452.8496-001	Concave Mc	CH840
5105	452.8496-002	Concave Mc	CH840
5106	452.8496-003	Concave Mc	CH840
5107	452.8496-005	Concave Mc	CH840
5108	BG01487655-01	Concave M	CH840
5109	BG01487655-02	Concave M	CH840
5110	BG01487655-03	Concave M	CH840
5111	BG01487655-05	Concave M	CH840
5112	BG01487095-01	Concave Mf	CH840
5113	BG01487095-02	Concave Mf	CH840
5114	BG01487095-03	Concave Mf	CH840
5115	BG01487095-05	Concave Mf	CH840
5116	452.8600-001	Concave F	CH840
5117	452.8600-002	Concave F	CH840
5118	452.8600-003	Concave F	CH840
5119	452.8600-005	Concave F	CH840
5120	452.7626-001	Mantle A	CH840
5121	452.7626-002	Mantle A	CH840
5122	452.7626-003	Mantle A	CH840
5123	452.7626-005	Mantle A	CH840
5124	452.8602-001	Mantle B	CH840

5125	452.8602-002	Mantle B	CH840
5126	452.8602-003	Mantle B	CH840
5127	452.8602-005	Mantle B	CH840
5128	BG00133846-01	Mantle Flexifeed B	CH840
5129	BG00133846-02	Mantle Flexifeed B	CH840
5130	BG00133846-03	Mantle Flexifeed B	CH840
5131	BG00133846-05	Mantle Flexifeed B	CH840
5132	452.7843-001	Mantle	CH840
5133	452.7626-001	Mantle	CH840
5134	452.8602-001	Mantle	CH840
5135	BG00133846	Mantle	CH840
5136	452.8500-001	Mantle	CH840
5137	452.8602-001	Mantle	CH840
5138	BG00133846	Mantle	CH840
5139	452.8496-001	Mantle	CH840
5140	452.7388-001	Concave	CH840
5141	452.8420-901	Steel Plate Liners	CH840
5142	452.8422-901	Rubber	CH840
5143	452.8415-901	Steel Plate Liners	CH840
5144	452.8416-901	Rubber	CH840
5145	452.8417-901	Steel Plate Liners	CH840
5146	452.8418-901	Rubber	CH840
5147	452.7386-001	Concave	CH840
5148	452.7738-901	Bottom Shell Arm Liner Kit	CH840
5149	BG00174603	Bottom Shell Liner Kit - Steel Plate	CH840
5150	891.2850-901	Bottom Shell Liner Set - Rubber	CH840
5151	BG00204330	Arm Shield	CH840
5152	452.7626-001	Mantle A M1	CH840
5153	452.7548-001	Mantle B M1	CH840
5154	BG00202524	Mantle Flexifeed B M1	CH840
5155	BG00226991	Concave Mf M1	CH840
5156	BG00216572	Concave F M1	CH840
5157	BG00228529	Concave M M1	CH840
5158	452.8500-001	Concave C M1	CH840
5159	452.8496-001	Concave Mc M1	CH840
5160	452.7843-001	Concave Ec M1	CH840
5161	873.1585-00	O-Ring For Spider Cap	CH840
5162	452.7208-901	Head Nut With Burning Ring	CH840

5163	452.7467-001	Burning Ring	CH840
5164	452.7547-001	Spider Bushing	CH840
5165	452.7519-001	Oil Seal Ring	CH840
5166	825.0182-00	Grease Tribol Tin	CH840
5167	873.1583-00	Gasket	CH840
5168	BG00215156	Step Bearing Set	CH840
5169	BG00475833	Main Shaft Sleeve	CH840
5170	452.7531-001	Dust Seal Ring	CH840
5171	452.7538-001	Retainer	CH840
5172	452.8342-901	Locating Bar Kit	CH840
5173	452.7537-001	Scraper	CH840
5174	452.8365-901	Fastener Kit Concave Support	CH840
5175	912.0155-00	Air Filter Insert	CH840
5176	912.0374-00	Overpressure Filter Insert	CH840
5177	452.7534-901	Spider Cap Assembly	CH840
5178	BG01074558	Bottom Shell Bushing	CH840
5179	BG01078588-03	Eccentric Bushing	CH840
5180	BG01078588-02	Eccentric Bushing	CH840
5181	BG01078588-01	Eccentric Bushing	CH840
5182	452.7275-001	Eccentric Wearing Plate	CH840
5183	BG00579374	Pinion Shaft Repair Kit	CH840
5184	452.8371-901	Chevron Packing Repair Kit	CH840
5185	452.6990-001	Pinion Shaft	CH840
5186	452.7443-001	Head Nut, Inner	CH840
5187	452.7329-001	Dust Seal Retaining Ring	CH840
5188	BG01121677	Main Shaft Assembly Excluding Mantle	CH840
5189	452.8361-901	Top Shell Assembly Excluding Concave	CH840
5190	BG00579275	Pinion Shaft Housing Assembly	CH840
5191	452.5824-901	Bottomshell Ar	CH890
5192	452.5991-901	Wear Plates In Bottomshell	CH890
5193	452.9650-	Rubber Compression Mountings	CH890
5194	452.2045-901	Eccentric Ar	CH890
5195	452.6434-901	Dust Collar Ar	CH890
5196	452.5938-901	Hydroset Cylinder Ar	CH890
5197	452.2007-901	Pinionshaft Housing Ar	CH890
5198	452.6419-901	Mainshaft Ar	CH890
5199	452.6235-901	Topshell Ar	CH890
5200	452.3620-901	Feed Hopper Ar	CH890

5201	452.6738-	Direct Drive On Subframe	CH890
5202	452.6164-	Overpressure Connection Assembly	CH890
5203	452.6271-	Overpressure Unit	CH890
5204	452.6223	Tool List	CH890
5205	452.6745-901	Sign Assembly	CH890
5206	452.5998-901	Hoses And Protection	CH890
5207	452.5972-901	Bottomshell Assembly	CH890
5208	452.3721-901	Foot	CH890
5209	847.0125-00	Washer	CH890
5210	840.0693-00	Screw	CH890
5211	442.9248-01	Bottomshell Bushing	CH890
5212	442.9249-02	Eccentric Wearing Plate	CH890
5213	853.0646-00	Pin	CH890
5214	442.9396-00	Bend	CH890
5215	900.2199-00	Flange	CH890
5216	847.0016-00	Washer	CH890
5217	840.0070-00	Screw	CH890
5218	873.0129-00	O-Ring	CH890
5219	891.2447-901	Inspection Door Pu	CH890
5220	847.0147-00	Washer	CH890
5221	845.0030-00	Lock Nut	CH890
5222	853.0464-00	Pin	CH890
5223	452.5923-901	Liner Pinionshaft Arm Assembly	CH890
5224	452.5925-001	Liner Narrow Arm	CH890
5225	452.5991-901	Wear Plate Complete	CH890
5226	452.5992-001	Wear Plate	CH890
5227	452.5994-001	Wear Plate	CH890
5228	452.5993-001	Wear Plate	CH890
5229	452.6017-001	Wear Plate	CH890
5230	452.6016-001	Wear Plate	CH890
5231	452.6081-001	Bar	CH890
5232	442.9650-91	Rubber Compression Mountings For	CH890
5233	864.0079-00	Damper	CH890
5234	840.1135-00	Screw	CH890
5235	847.0132-00	Washer Round	CH890
5236	442.5904-01	Fixing Plate	CH890
5237	864.0124-00	Damper	CH890
5238	840.0064-00	Screw	CH890

5239	847.0016-00	Washer	CH890
5240	442.9651-01	Mounting Plate	CH890
5241	442.9245-01	Eccentric Pt.	CH890
5242	442.9246-01	Hub	CH890
5243	442.9274-00	Ring	CH890
5244	840.0068-00	Screw	CH890
5245	847.0016-00	Washer	CH890
5246	442.9469-01	Key	CH890
5247	841.0036-00	Screw	CH890
5248	841.0032-00	Screw	CH890
5249	847.0181-00	Washer	CH890
5250	442.9275-01	Key	CH890
5251	442.9357-01	Eccentric Bushing	CH890
5252	442.9358-01	Eccentric Bushing	CH890
5253	442.9359-01	Eccentric Bushing	CH890
5254	442.9360-01	Eccentric Bushing	CH890
5255	442.9639-00	Gear And Pinion Set	CH890
5256	442.9311-00	Gear And Pinion Set	CH890
5257	452.6435-001	Dust Collar	CH890
5258	853.0464-00	Pin	CH890
5259	442.9309-01	Ring	CH890
5260	442.9310-01	Seal Ring Pt.	CH890
5261	442.9362-01	Shim	CH890
5262	442.9362-02	Shim	CH890
5263	442.9362-03	Shim	CH890
5264	442.9362-04	Shim	CH890
5265	442.9308-02	Locating Bar	CH890
5266	841.0256-00	Screw	CH890
5267	847.0016-00	Washer	CH890
5268	840.0943-00	Screw	CH890
5269	840.0064-00	Screw	CH890
5270	873.1545-00	O-Ring	CH890
5271	873.1548-00	O-Ring	CH890
5272	452.5973-001	Hydroset Cylinder	CH890
5273	452.5942-001	Hydroset Cylinder Cover	CH890
5274	847.0310-00	Washer	CH890
5275	840.1176-00	Screw	CH890
5276	442.9256-01	Hydroset Cylinder Bushing Pt.	CH890

5277	840.0032-00	Screw	CH890
5278	847.0144-00	Washer	CH890
5279	873.1233-00	O-Ring	CH890
5280	873.1210-00	O-Ring	CH890
5281	873.1211-00	O-Ring	CH890
5282	919.0190-00	Protection Plug	CH890
5283	873.0237-00	O-Ring	CH890
5284	984.0421-00	Position Sensor	CH890
5285	841.0628-00	Screw	CH890
5286	847.0016-00	Washer	CH890
5287	840.0069-00	Screw	CH890
5288	452.6139-001	Flange Measure System	CH890
5289	900.2292-00	Measuring Nipple	CH890
5290	452.6129-901	Measuring Tube Holder	CH890
5291	853.0988-00	Pin	CH890
5292	452.6075-001	Piston	CH890
5293	442.9304-01	Packing Clamping Plate Pt.	CH890
5294	841.0267-00	Screw	CH890
5295	452.2631-901	Step Bearing Set	CH890
5296	442.9257-00	Chevron Packing Assembly	CH890
5297	442.9806-01	Pinion Shaft Housing	CH890
5298	442.9364-02	Gasket T	CH890
5299	442.9364-03	Gasket T	CH890
5300	868.0832-00	Bearing	CH890
5301	847.0299-00	Lock Washer	CH890
5302	442.9809-01	Wear Ring	CH890
5303	845.0164-00	Locking Nut	CH890
5304	442.9334-01	Spacer	CH890
5305	442.9808-01	Spacer	CH890
5306	873.1219-00	Oil Seal Ring	CH890
5307	873.0136-00	O-Ring	CH890
5308	442.9261-01	Bearing Cover Inner	CH890
5309	442.9260-01	Bearing Cover, Outer	CH890
5310	840.0046-00	Screw	CH890
5311	847.0147-00	Washer	CH890
5312	840.0078-00	Screw	CH890
5313	847.0132-00	Washer	CH890
5314	442.9365-01	Gasket	CH890

5315	442.9364-01	Gasket	CH890
5316	853.0590-00	Spring Pin	CH890
5317	442.9807-01	Pinion Shaft	CH890
5318	900.2388-00	Plug	CH890
5319	857.0360-00	Key	CH890
5320	857.0354-00	Key	CH890
5321	900.0022-00	Elbow	CH890
5322	842.0020-00	Screw	CH890
5323	442.9346-01	Oil Level Gauge	CH890
5324	873.0387-00	Seal Ring	CH890
5325	855.0030-00	Retaining Ring	CH890
5326	840.1063-00	Screw	CH890
5327	845.0009-00	Nut	CH890
5328	847.0063-00	Washer	CH890
5329	840.0672-00	Screw	CH890
5330	442.9366-01	Gasket	CH890
5331	900.0655-00	Adapter	CH890
5332	900.0656-00	Straight Adapter	CH890
5333	873.0386-00	Seal	CH890
5334	452.6421-901	Mainshaft As	CH890
5335	442.9294-01	Main Shaft Sleeve	CH890
5336	853.0988-00	Pin	CH890
5337	855.0026-00	Retaining Ring	CH890
5338	442.9269-01	Head Nut Inner	CH890
5339	442.9270-00	Head Nut As.	CH890
5340	452.6045-001	Dust Seal Retaining Ring	CH890
5341	847.0016-00	Washer	CH890
5342	840.1034-00	Screw	CH890
5343	452.6048-001	Dust Seal Ring	CH890
5344	442.9367-01	Retainer	CH890
5345	840.0067-00	Screw	CH890
5346	452.6114-001	Scraper	CH890
5347	452.6722-001	Distance Pt.	CH890
5348	840.0065-00	Screw	CH890
5349	842.0230-00	Screw	CH890
5350	442.9306-01	Burning Ring	CH890
5351	452.4051-001	Mantle	CH890
5352	442.9314-01	Mantle	CH890

5353	442.9339-01	Mantle	CH890
5354	442.9758-01	Mantle	CH890
5355	452.0264-001	Mantle	CH890
5356	452.6235-901	Topshell	CH890
5357	840.1175-00	Screw	CH890
5358	845.0322-00	Nut	CH890
5359	847.0171-00	Washer	CH890
5360	442.9979-01	Washer	CH890
5361	899.0278-00	Protective Cap	CH890
5362	442.9530-02	Screw	CH890
5363	914.0093-00	Lubrication Nipple	CH890
5364	900.0142-00	Pipe Bushing	CH890
5365	452.4029-001	Pipe	CH890
5366	900.0437-00	Compression Fitting	CH890
5367	452.0266-001	Spider Cap	CH890
5368	912.0114-00	Air Filter	CH890
5369	900.0169-00	Hexagon Nipple	CH890
5370	900.0002-00	Elbow	CH890
5371	452.3952-001	Steel Pipe	CH890
5372	900.0425-00	Compression Fitting	CH890
5373	873.1232-00	O-Ring	CH890
5374	840.0653-00	Screw	CH890
5375	847.0132-00	Washer Round	CH890
5376	442.9266-01	Spider Bushing	CH890
5377	191.3213-00	Connection Box	CH890
5378	900.2624-00	Jam Nut	CH890
5379	900.0654-00	Adapter	CH890
5380	452.3950-001	Steel Pipe	CH890
5381	840.0652-00	Screw	CH890
5382	452.0418-001	Seal Ring / Scraper	CH890
5383	452.0417-001	Ring	CH890
5384	452.0419-001	Support Ring	CH890
5385	841.0225-00	Screw	CH890
5386	842.0316-00	Screw	CH890
5387	840.1115-00	Screw	CH890
5388	452.1068-001	Block	CH890
5389	442.7252-01	Shim	CH890
5390	442.7252-02	Shim	CH890

5391	442.7252-03	Shim	CH890
5392	442.7252-04	Shim	CH890
5393	442.8908-02	Hose	CH890
5394	847.0125-00	Washer	CH890
5395	840.1279-00	Screw	CH890
5396	845.0273-00	Nut	CH890
5397	442.9353-01	Sleeve	CH890
5398	442.9354-01	Washer	CH890
5399	863.0015-00	Disc Spring	CH890
5400	442.9313-01	Support Ring	CH890
5401	442.8290-01	Dowel Pin	CH890
5402	452.5430-001	Spacer	CH890
5403	900.1030-00	Bushing	CH890
5404	900.0981-00	Plug	CH890
5405	191.2376-00	Temperature Sensor	CH890
5406	452.9265-00	Arm Shield	CH890
5407	452.0514-001	Arm Shield	CH890
5408	442.9336-01	Concave Ec	CH890
5409	442.9398-01	Concave C	CH890
5410	442.9471-01	Concave Mc	CH890
5411	442.9337-01	Concave M	CH890
5412	442.9312-01	Concave Mf	CH890
5413	442.9471-01	Concave F	CH890
5414	442.9338-00	Filler Ring M	CH890
5415	442.9332-00	Filler Ring Mf	CH890
5416	442.9520-00	Filler Ring Mc	CH890
5417	452.4035-901	Wearing Plate Assembly, Consists Of:	CH890
5418	452.1069-901	Wearing Plate Alternative	CH890
5419	847.0060-00	Washer	CH890
5420	840.0069-00	Screw	CH890
5421	840.0634-00	Screw	CH890
5422	442.9737-00	Feed Hopper Lower	CH890
5423	452.6128-901	Feed Hopper Upper	CH890
5424	442.9736-00	Feed Hopper, Upper	CH890
5425	840.0078-00	Screw	CH890
5426	847.0132-00	Washer Round	CH890
5427	845.0203-00	Lock Nut	CH890
5428	442.9747-01	Wt6000 50X500X750	CH890

5429	442.9750-01	Wt6000 50X500X550	CH890
5430	840.0068-00	Screw	CH890
5431	845.0215-00	Nut Lock	CH890
5432	847.0016-00	Washer	CH890
5433	840.0071-00	Screw	CH890
5434	873.1287-00	Rubber Plug	CH890
5435	452.3682-901	Cone Ec	CH890
5436	452.3683-901	Cone C	CH890
5437	452.3684-901	Cone Mc	CH890
5438	458.0390-00	Sub-Frame	CH890
5439	442.9650-91	Vibration Damper	CH890
5440	458.0772-00	Rail For Seal Streap	CH890
5441		Drive Shaft With Safety Coupling	CH890
5442	930.0265-00	Pump	CH890
5443	458.0396-001	Guard	CH890
5444	452.3387-001	Motor Template	CH890
5445	458.0406-01	Shims	CH890
5446	458.0406-02	Shims	CH890
5447	458.0406-03	Shims	CH890
5448	840.0718-00	Screw	CH890
5449	847.0162-00	Washer	CH890
5450	845.0273-00	Nut	CH890
5451	845.0274-00	Lock Nut	CH890
5452	847.0142-00	Washer	CH890
5453	840.1117-00	Screw	CH890
5454	845.0010-00	Nut	CH890
5455	840.0967-00	Screw	CH890
5456	873.0718-00	Strip	CH890
5457	930.0273-00	Drive Shaft With Safety Coupling	CH890
5458	930.0276-00	Coupling Safeset	CH890
5459	930.0277-00	Coupling Holset	CH890
5460	930.0278-00	Intermediate Shaft	CH890
5461	930.0274-00	Shear Tube	CH890
5462	458.0451-00	Sensor Without Speed Monitor	CH890
5463	458.0452-01	Support	CH890
5464	840.0021-00	Screw	CH890
5465	847.0012-00	Washer	CH890
5466	984.0217-00	Sensor	CH890

5467	452.6163-001	Air Chamber	CH890
5468	873.0386-00	Seal	CH890
5469	900.0436-00	Compression Fitting	CH890
5470	452.6059-001	Flange Air Inlet Flange	CH890
5471	900.2279-00	Plug	CH890
5472	840.0044-00	Screw	CH890
5473	847.0147-00	Washer	CH890
5474	840.0053-00	Screw	CH890
5475	847.0015-00	Washer	CH890
5476	873.0384-00	Seal Tredo	CH890
5477	984.1632-00	Pressure Transmitter	CH890
5478	452.6152-002	Steel Pipe	CH890
5479	452.6152-003	Steel Pipe	CH890
5480	840.0054-00	Screw	CH890
5481	900.2587-00	Flange Section	CH890
5482	840.0049-00	Screw	CH890
5483	452.6273-001	Cover Lid	CH890
5484	900.3078-00	Adapter	CH890
5485	873.1295-00	O-Ring	CH890
5486	900.3077-00	Compression Fitting	CH890
5487	900.0778-00	Clamping Ring	CH890
5488	873.1547-00	O-Ring	CH890
5489	900.2302-00	Plug	CH890
5490	900.3079-00	Clamp	CH890
5491	900.2118-00	Cover Plate	CH890
5492	840.0588-00	Screw	CH890
5493	847.0164-00	Washer	CH890
5494	452.6099-001	Protective Plate	CH890
5495	452.6271-50/400	Over Pressure Installation	CH890
5496	452.6271-50/660-	Over Pressure Installation	CH890
5497	452.6271-50/525	Over Pressure Installation	CH890
5498	452.6271-50/550	Over Pressure Installation	CH890
5499	452.6271-60/575	Over Pressure Installation	CH890
5500	452.6271-60/460	Over Pressure Installation	CH890
5501	900.0193-00	Hexagon Nipple	CH890
5502	900.2846-00	Socket	CH890
5503	900.2809-00	Hose Coupling Hose	CH890
5504	452.6272-001	Hose	CH890

5505	452.3811-901	Air Cleaner	CH890
5506	900.3080-00	Nipple	CH890
5507	900.1722-00	Hose Clip	CH890
5508	906.0538-00	Over pressure Fan Becker	CH890
5509	840.0021-00	Screw	CH890
5510	972.1328-00	W22 71-2B5-0,55 4 525V50	CH890
5511	972.1314-00	W22 71-2B5-0,55 4 575V60	CH890
5512	972.1297-00	W22 71-2B5-0,55 4 460V60	CH890
5513	972.1283-00	W22 71-2B5-0,55 4 400Vd50	CH890
5514	442.9476-00	Tool Box	CH890
5515	452.6267-001	Tool List	CH890
5516	442.9443-00	Lifting Tool Eccentric Bushing	CH890
5517	442.9444-00	Lifting Tool Bottom Shell Bushing	CH890
5518	442.9446-00	Lifting Tool	CH890
5519	452.6180-901	Piston Retainer As.	CH890
5520	442.7284-90	Lowering Rod	CH890
5521	843.1529-00	Lowering Rod	CH890
5522	845.0013-00	Nut	CH890
5523	899.0515-00	Lifting Eye Bolt	CH890
5524	899.0511-00	Lifting Eye Bolt	CH890
5525	899.0510-00	Lifting Eye Bolt	CH890
5526	899.0509-00	Lifting Eye Bolt	CH890
5527	899.0508-00	Lifting Eye Bolt	CH890
5528	899.0507-00	Lifting Eye Bolt	CH890
5529	899.0512	Lifting Eye Bolt	CH890
5530	920.0110-00	Slugging Wrench 65	CH890
5531	920.0109-00	Slugging Wrench 55	CH890
5532	920.0238-00	Slugging Wrench 46	CH890
5533	920.0243-00	Tool Combination Wrench	CH890
5534	920.0131-00	Combination Wrench	CH890
5535	920.0135-00	Combination Wrench	CH890
5536	920.0134-00	Combination Wrench	CH890
5537	920.0022-00	Combination Wrench	CH890
5538	920.0044-00	Combination Wrench	CH890
5539	920.0245-00	Tool Combination Wrench	CH890
5540	920.0042-00	Socket Screw Key	CH890
5541	920.0040-00	Socket Screw Key	CH890
5542	920.0038-00	Socket Screw Key	CH890

5543	920.0037-00	Socket Screw Key	CH890
5544	920.0035-00	Socket Screw Key	CH890
5545	920.0032-00	Socket Screw Key	CH890
5546	442.0800-91	Chunk Of Lead As.	CH890
5547	923.0422-00	Feeler Gauge	CH890
5548	452.0452-001	Lifting Tool	CH890
5549	904.0585-00	Air Bleeder Hose	CH890
5550	126.0447-001	Logotype Silver 180	CH890
5551	126.0772-001	Sign Product Name	CH890
5552	126.0384-001	Warning Flying Fragments	CH890
5553	126.5007-01	Identification Plate	CH890
5554	126.0345-001	Patent Information Sign	CH890
5555	885.0267-00	Warning Sign Danger	CH890
5556	126.0383-001	Risk Of Crushing	CH890
5557	126.0385-001	Warning Sign Read Manual	CH890
5558	452.1488-902	Hydroset Security Valve As.	CH890
5559	452.6079-001	Hydraulic Hose	CH890
5560	452.6077-001	Hydraulic Hose	CH890
5561	452.6078-001	Hydraulic Hose	CH890
5562	900.2592-00	Flange	CH890
5563	452.1580-001	Hose	CH890
5564	442.9396-00	Bend As.	CH890
5565	452.1616-901	Return Oil Hose	CH890
5566	873.0390-00	Seal Ring	CH890
5567	900.2599-00	Adapter	CH890
5568	452.1579-001	Hose	CH890
5569	873.1299-00	O-Ring	CH890
5570	873.0129-00	O-Ring	CH890
5571	452.1536-901	Straight Hose Coupling	CH890
5572	873.0755-00	O-Ring	CH890
5573	873.0615-00	O-Ring	CH890
5574	900.2199-00	Flange	CH890
5575	900.2602-00	Flange	CH890
5576	900.2385-00	Flange	CH890
5577	452.1591-001	Cover	CH890
5578	452.1590-001	Cover	CH890
5579	452.1592-001	Cover	CH890
5580	841.0268-00	Screw	CH890

5581	847.0147-00	Washer Round	CH890
5582	840.0068-00	Screw	CH890
5583	847.0016-00	Washer	CH890
5584	845.0215-00	Lock Nut	CH890
5585	841.0253-00	Screw	CH890
5586	847.0144-00	Washer	CH890
5587	845.0213-00	Lock Nut	CH890
5588	840.0066-00	Screw	CH890
5589	452.6153-001	Connection Manifold	CH890
5590	847.0338-00	Washer	CH890
5591	840.0934-00	Screw	CH890
5592	840.0076-00	Screw	CH890
5593	900.2302-00	Plug	CH890
5594	452.6000-902	Bracket For Hydroset Security Valve	CH890
5595	900.1140-00	Clip	CH890
5596	841.0219-00	Screw	CH890
5597	452.1511-001	Protection	CH890
5598	840.0622-00	Screw	CH890
5599	452.6090-901	Bracket	CH890
5600	452.6093-901	Bracket Fzb	CH890
5601	452.6096-001	Bar	CH890
5602	452.6127-001	Bracket Fzb	CH890
5603	452.6088-901	Wear Liner	CH890
5604	452.1425-901	Support	CH890
5605	452.1426-001	Bracket	CH890
5606	847.0016-00	Washer	CH890
5607	845.0215-00	Lock Nut	CH890
5608	452.6103-001	Rubber Protection	CH890
5609	452.6134-001	Bar	CH890
5610	840.1097-00	Screw	CH890
5611	452.6169-001	Support Fzb	CH890
5612	840.0070-00	Screw	CH890
5613	452.6175-001	Fixing Bar Fzb	CH890
5614	452.6166-001	Rubber Protection	CH890
5615	840.0065-00	Screw	CH890
5616	840.0072-00	Screw	CH890
5617	840.0067-00	Screw	CH890
5618	452.6170-001	Protective Cover Fzb	CH890

5619	847.0147-00	Washer Round	CH890
5620	840.0044-00	Screw	CH890
5621	873.0390-00	Seal Ring	CH890
5622	900.0659-00	Adapter	CH890
5623	452.1587-001	Hose	CH890
5624	452.1580-001	Hose	CH890
5625	452.1538-001	Hose	CH890
5626	452.1616-901	Return Oil Hose	CH890
5627	452.1591-001	Cover	CH890
5628	841.0253-00	Screw	CH890
5629	845.0213-00	Lock Nut	CH890
5630	847.0144-00	Washer	CH890
5631	900.2385-00	Flange Half	CH890
5632	873.1299-00	O-Ring	CH890
5633	452.1592-001	Cover	CH890
5634	900.2602-00	Flange Half	CH890
5635	873.0615-00	O-Ring	CH890
5636	452.1589-001	Cover	CH890
5637	900.2592-00	Flange Half	CH890
5638	845.0030-00	Lock Nut	CH890
5639	847.0147-00	Washer Round	CH890
5640	841.0268-00	Screw	CH890
5641	873.0755-00	O-Ring	CH890
5642	452.1536-901	Straight Hose Coupling	CH890
5643	900.2199-00	Flange	CH890
5644	840.0068-00	Screw	CH890
5645	847.0016-00	Washer	CH890
5646	845.0215-00	Lock Nut	CH890
5647	873.0129-00	O-Ring	CH890
5648	452.1590-001	Cover	CH890
5649	442.9308-02	Locating Bar	CH890
5650	442.9362-01	Shim	CH890
5651	442.9362-02	Shim	CH890
5652	442.9362-03	Shim	CH890
5653	442.9362-04	Shim	CH890
5654	841.0256-00	Screw	CH890
5655	442.9364-01	Gasket	CH890
5656	442.9364-02	Gasket	CH890

5657	442.9364-03	Gasket	CH890
5658	868.0832-00	Bearing	CH890
5659	845.0164-00	Lock Nut	CH890
5660	847.0299-00	Lock Washer	CH890
5661	442.9809-01	Wear Ring	CH890
5662	442.9334-01	Spacer	CH890
5663	442.9808-01	Spacer	CH890
5664	873.0136-00	O-Ring	CH890
5665	873.1219-00	Oil Seal Ring	CH890
5666	442.9365-01	Gasket	CH890
5667	442.9366-01	Gasket	CH890
5668	873.0387-00	Seal Ring	CH890
5669	873.0386-00	Seal Ring	CH890
5670	840.1279-00	Screw	CH890
5671	845.0273-00	Lock Nut	CH890
5672	442.9353-01	Cage Pt.	CH890
5673	442.9354-01	Washer Pt.	CH890
5674	863.0015-00	Disc Spring	CH890
5675	452.5430-001	Spacer	CH890
5676	452.5923-901	Liner Pinionshaft Arm	CH890
5677	452.5925-001	Liner Narrow Arm	CH890
5678	912.0126-00	Filter	CH890
5679	912.0129-00	Filter Cartridge	CH890
5680	912.0139-00	Filter Cartridge	CH890
5681	912.0219-00	Filter Cartridge	CH890
5682	912.0155-00	Filter Cartridge	CH890
5683	452.5824-901	Bottom shell Ar	CH895
5684	452.5991-901	Wear Plates In Bottom shell	CH895
5685	452.9650-	Rubber Compression Mountings	CH895
5686	452.2045-901	Eccentric Ar	CH895
5687	452.6133-901	Dust Collar Ar	CH895
5688	452.5938-901	Hydroset Cylinder Ar	CH895
5689	452.2007-901	Pinion shaft Housing	CH895
5690	452.6419-901	Main shaft Ar	CH895
5691	452.5944-901	Top shell Ar	CH895
5692	452.6066-901	Feed Hopper Ar	CH895
5693	452.6738-	Direct Drive On Sub frame	CH895
5694	452.6164-	Over pressure Connection Assembly	CH895

5695	452.6271-	Over pressure Unit	CH895
5696	452.6223	Tool List	CH895
5697	452.6745-901	Sign Assembly	CH895
5698	452.5998-901	Hoses And Protection	CH895
5699	452.5824-901	Bottom shell Arrangement	CH895
5700	452.5972-901	Bottom shell Assembly	CH895
5701	452.3721-901	Foot Assembly	CH895
5702	847.0125-00	Washer	CH895
5703	840.0693-00	Screw	CH895
5704	891.2447-901	Inspection Door Pu	CH895
5705	847.0147-00	Washer	CH895
5706	845.0030-00	Lock Nut	CH895
5707	853.0464-00	Pin	CH895
5708	442.9248-01	Bottom shell Bushing	CH895
5709	442.9396-00	Bend Assembly	CH895
5710	900.2199-00	Flange Halfe	CH895
5711	847.0016-00	Washer	CH895
5712	840.0070-00	Screw	CH895
5713	873.0129-00	O-Ring	CH895
5714	853.0646-00	Pin Prym N 16X45	CH895
5715	442.9249-02	Eccentric Wearing Plate	CH895
5716	452.5988-901	Bottom Shell Liner Kit	CH895
5717	452.5923-901	Liner Narrow Arm	CH895
5718	452.5991-901	Wear Plate Kit	CH895
5719	452.5992-001	Wear Plate	CH895
5720	452.5994-001	Wear Plate	CH895
5721	452.5993-001	Wear Plate	CH895
5722	452.6017-001	Wear Plate	CH895
5723	452.6016-001	Wear Plate	CH895
5724	452.6081-001	Bar	CH895
5725	442.9650-91	Rubber Compression Mountings For Crusher On	CH895
5726	864.0079-00	Damper	CH895
5727	840.1135-00	Screw	CH895
5728	847.0132-00	Washer Round	CH895
5729	442.5904-01	Fixing Plate	CH895
5730	864.0124-00	Damper	CH895
5731	840.0064-00	Screw	CH895
5732	847.0016-00	Washer	CH895

5733	442.9651-01	Mounting Plate	CH895
5734	442.9245-01	Eccentric Pt.	CH895
5735	442.9246-01	Hub	CH895
5736	442.9274-00	Ring	CH895
5737	840.0068-00	Screw	CH895
5738	847.0016-00	Washer	CH895
5739	442.9469-01	Key	CH895
5740	841.0036-00	Screw	CH895
5741	841.0032-00	Screw	CH895
5742	847.0181-00	Washer	CH895
5743	442.9275-01	Key	CH895
5744	442.9357-01	Eccentric Bushing	CH895
5745	442.9358-01	Eccentric Bushing	CH895
5746	442.9359-01	Eccentric Bushing	CH895
5747	442.9360-01	Eccentric Bushing	CH895
5748	442.9639-00	Gear And Pinion Set	CH895
5749	442.9311-00	Gear And Pinion Set	CH895
5750	452.6435-001	Dust Collar	CH895
5751	853.0464-00	Pin	CH895
5752	442.9309-01	Ring	CH895
5753	442.9310-01	Seal Ring Pt.	CH895
5754	442.9362-01	Shim	CH895
5755	442.9362-02	Shim	CH895
5756	442.9362-03	Shim	CH895
5757	442.9362-04	Shim	CH895
5758	442.9308-02	Locating Bar	CH895
5759	841.0256-00	Screw	CH895
5760	847.0016-00	Washer	CH895
5761	840.0943-00	Screw	CH895
5762	840.0064-00	Screw	CH895
5763	873.1545-00	O-Ring	CH895
5764	873.1548-00	O-Ring	CH895
5765	452.5973-001	Hydroset Cylinder	CH895
5766	452.5942-001	Hydroset Cylinder Cover	CH895
5767	847.0310-00	Washer	CH895
5768	840.1176-00	Screw	CH895
5769	442.9256-01	Hydroset Cylinder Bushing	CH895
5770	840.0032-00	Screw	CH895

5771	847.0144-00	Washer	CH895
5772	873.1233-00	O-Ring	CH895
5773	873.1210-00	O-Ring	CH895
5774	873.1211-00	O-Ring	CH895
5775	919.0190-00	Protection Plug	CH895
5776	873.0237-00	O-Ring	CH895
5777	984.0421-00	Position Sensor	CH895
5778	841.0628-00	Screw	CH895
5779	847.0016-00	Washer	CH895
5780	840.0069-00	Screw	CH895
5781	452.6139-001	Flange Measure System	CH895
5782	900.2292-00	Measuring Nipple G 1/4"	CH895
5783	452.6129-901	Measuring Tube Holder As.	CH895
5784	853.0988-00	Pin	CH895
5785	452.6075-001	Piston	CH895
5786	442.9304-01	Packing Clamping Plate Pt.	CH895
5787	841.0267-00	Screw	CH895
5788	452.2631-901	Step Bearing Set	CH895
5789	442.9257-00	Chevron Packing Assembly	CH895
5790	442.2007-901	Pinion Shaft Housing Assembly	CH895
5791	442.9806-01	Pinion Shaft Housing	CH895
5792	442.9364-02	Gasket T	CH895
5793	442.9364-03	Gasket T	CH895
5794	868.0832-00	Bearing	CH895
5795	847.0299-00	Lock Washer	CH895
5796	442.9809-01	Wear Ring	CH895
5797	845.0164-00	Locking Nut	CH895
5798	442.9334-01	Spacer	CH895
5799	442.9808-01	Spacer	CH895
5800	873.1219-00	Oil Seal Ring	CH895
5801	873.0136-00	O-Ring	CH895
5802	442.9261-01	Bearing Cover Inner	CH895
5803	442.9260-01	Bearing Cover, Outer	CH895
5804	840.0046-00	Screw	CH895
5805	847.0147-00	Washer	CH895
5806	840.0078-00	Screw	CH895
5807	847.0132-00	Washer	CH895
5808	442.9365-01	Gasket T	CH895

5809	442.9364-01	Gasket T	CH895
5810	853.0590-00	Spring Pin	CH895
5811	442.9807-01	Pinion Shaft	CH895
5812	900.2388-00	Plug	CH895
5813	857.0360-00	Key	CH895
5814	857.0354-00	Key	CH895
5815	900.0022-00	Elbow	CH895
5816	842.0020-00	Screw	CH895
5817	442.9346-01	Oil Level Gauge	CH895
5818	873.0387-00	Seal Ring	CH895
5819	855.0030-00	Retaining Ring	CH895
5820	840.1063-00	Screw	CH895
5821	845.0009-00	Nut	CH895
5822	847.0063-00	Washer	CH895
5823	840.0672-00	Screw	CH895
5824	442.9366-01	Gasket	CH895
5825	900.0655-00	Adapter	CH895
5826	900.0656-00	Straight Adapter	CH895
5827	873.0386-00	Seal	CH895
5828	452.6419-901	Mainshaft Assembly Excluding Mantle	CH895
5829	452.6421-901	Mainshaft As	CH895
5830	442.9294-01	Main Shaft Sleeve	CH895
5831	853.0988-00	Pin	CH895
5832	855.0026-00	Retaining Ring	CH895
5833	442.9269-01	Head Nut Inner	CH895
5834	899.0336-00	Lifting Eye Bolt	CH895
5835	442.9620-00	Transport Frame	CH895
5836	452.6419-902	Mainshaft Assembly Incl Mantle	CH895
5837	452.6421-902	Mainshaft As	CH895
5838	442.9294-01	Main Shaft Sleeve	CH895
5839	853.0988-00	Pin	CH895
5840	855.0026-00	Retaining Ring	CH895
5841	442.9269-01	Head Nut Inner	CH895
5842	442.9270-00	Head Nut As.	CH895
5843	442.9306-01	Burning Ring	CH895
5844	452.6048-001	Dust Seal Ring	CH895
5845	452.6045-001	Dust Seal Retaining Ring	CH895
5846	442.9367-01	Retainer	CH895

5847	452.6114-001	Scraper	CH895
5848	840.0067-00	Screw	CH895
5849	840.1034-00	Screw	CH895
5850	840.0065-00	Screw	CH895
5851	842.0230-00	Screw	CH895
5852	847.0016-00	Washer	CH895
5853	452.6722-001	Distance Pt.	CH895
5854	899.0336-00	Lifting Eye Bolt	CH895
5855	442.9620-00	Transport Frame	CH895
5856	452.1067-001	Concave	CH895
5857	452.0263-001	Concave	CH895
5858	452.0579-001	Concave	CH895
5859	452.2061-901	Mantle Assembly	CH895
5860	452.0264-001	Mantle	CH895
5861	452.4051-001	Mantle	CH895
5862	452.1067-001	Concave	CH895
5863	452.0263-001	Concave	CH895
5864	452.0579-001	Concave	CH895
5865	452.4051-001	Mantle	CH895
5866	452.0264-001	Mantle	CH895
5867	452.5514	Cover And Splitter	CH895
5868	452.5944-901	Topshell Tertiary Arrangement, Excl	CH895
		Concave	
5869	452.5944-902	Topshell Tertiary Arrangement , Incl	CH895
		Concave	
5870	912.0114-00	Air Filter	CH895
5871	900.1030-00	Bushing	CH895
5872	900.0425-00	Compression Fittings	CH895
5873	452.5971-001	Steel Pipe	CH895
5874	452.5984-001	Steel Pipe	CH895
5875	191.2376-00	Temperature Sensor	CH895
5876	191.3213-00	Connection Box	CH895
5877	900.0654-00	Adapter	CH895
5878	900.2624-00	Jam Nut	CH895
5879	900.0431-00	Compression Fitting	CH895
5880	452.5983-001	Pipe	CH895
5881	914.0093-00	Lubrication Nipple	CH895
5882	452.6068-901	Rim Liner Tertiary As.	CH895

5883	452.6071-901	Arm Shield As.	CH895
5884	442.9266-01	Spider Bushing	CH895
5885	847.0132-00	Washer Round	CH895
5886	840.0652-00	Screw	CH895
5887	452.0418-001	Seal Ring / Scraper	CH895
5888	452.0417-001	Ring	CH895
5889	452.0419-001	Support Ring	CH895
5890	841.0225-00	Screw	CH895
5891	452.0266-001	Spider Cap	CH895
5892	900.0981-00	Plug	CH895
5893	873.1232-00	O-Ring	CH895
5894	840.0653-00	Screw	CH895
5895	442.8290-01	Dowel Pin	CH895
5896	442.9313-01	Support Ring Pt.	CH895
5897	452.5985-901	Concave Tertiary Alt.	CH895
5898	831.0016-00	Casting Compound	CH895
5899	452.5430-001	Spacer Fzb Pt.	CH895
5900	442.9354-01	Washer Pt.	CH895
5901	442.9353-01	Sleeve Pt.	CH895
5902	863.0015-00	Disc Spring	CH895
5903	845.0273-00	Lock Nut Low	CH895
5904	840.1279-00	Screw	CH895
5905	442.9530-02	Screw	CH895
5906	899.0278-00	Protective Cap	CH895
5907	840.1175-00	Screw	CH895
5908	442.9979-01	Washer Pt.	CH895
5909	845.0322-00	Nut	CH895
5910	847.0171-00	Washer	CH895
5911	452.5835-001	Rim Liner	CH895
5912	452.6069-001	Bar	CH895
5913	452.6071	Arm Shield Assembly	CH895
5914	452.5841-001	Arm Shield	CH895
5915	452.6072-001	Bar	CH895
5916	452.1067-001	Concave Efx	CH895
5917	452.0579-001	Concave Eef	CH895
5918	452.0263-001	Concave Ef	CH895
5919	452.5921-901	Feed Hopper Lower	CH895
5920	452.5922-00	Feed Hopper	CH895

5921	847.0016-00	Washer	CH895
5922	840.0075-00	Screw	CH895
5923	845.0215-00	Nut Lock	CH895
5924	840.0068-00	Screw	CH895
5925	452.6028-001	Rubber Sheet	CH895
5926	840.0068-00	Screw	CH895
5927	847.0016-00	Washer	CH895
5928	845.0215-00	Nut Lock M16	CH895
5929	873.1287-00	Rubber Plug	CH895
5930	452.6128-901	Feed Hopper Upper	CH895
5931	442.9736-00	Feed Hopper, Upper	CH895
5932	840.0078-00	Screw	CH895
5933	847.0132-00	Washer Round	CH895
5934	845.0203-00	Lock Nut	CH895
5935	442.9747-01	Wt6000 50X500X750	CH895
5936	442.9750-01	Wt6000 50X500X550	CH895
5937	840.0068-00	Screw	CH895
5938	845.0215-00	Nut Lock	CH895
5939	847.0016-00	Washer	CH895
5940	840.0071-00	Screw	CH895
5941	873.1287-00	Rubber Plug	CH895
5942	452.3984-901	Cover	CH895
5943	452.2939-901	Splitter	CH895
5944	452.3984-901	Cover Assembly	CH895
5945	452.3985-901	Cover	CH895
5946	840.0068-00	Screw	CH895
5947	847.0016-00	Washer	CH895
5948	845.0215-00	Nut Lock	CH895
5949	840.0066-00	Screw	CH895
5950	452.2939-901	Splitter Assembly	CH895
5951	452.2938-901	Adjusting Unit	CH895
5952	452.2937-901	Distribution Box	CH895
5953	452.1447-001	Wearing Plate	CH895
5954	840.1135-00	Screw	CH895
5955	847.0197-00	Washer	CH895
5956	452.2963-901	Clamping Plate	CH895
5957	845.0203-00	Nut Lock	CH895
5958	458.0390-00	Sub-Frame	CH895

5959	442.9650-91	Vibration Damper	CH895
5960	458.0772-00	Rail For Seal Streap	CH895
5961	930.0265-00	Pump	CH895
5962	458.0396-001	Guard	CH895
5963	452.3387-001	Motor Template	CH895
5964	458.0406-01	Shims	CH895
5965	458.0406-02	Shims	CH895
5966	458.0406-03	Shims	CH895
5967	840.0718-00	Screw	CH895
5968	847.0162-00	Washer	CH895
5969	845.0273-00	Nut	CH895
5970	845.0274-00	Lock Nut	CH895
5971	847.0142-00	Washer	CH895
5972	840.1117-00	Screw	CH895
5973	845.0010-00	Nut	CH895
5974	840.0967-00	Screw	CH895
5975	873.0718-00	Strip	CH895
5976	930.0273-00	Drive Shaft With Safety Coupling, Con-	CH895
		Sists Of:	
5977	930.0276-00	Coupling Safeset	CH895
5978	930.0277-00	Coupling	CH895
5979	930.0278-00	Intermediate Shaft	CH895
5980	930.0274-00	Shear Tube	CH895
5981	458.0451-00	Sensor Without Speed Monitor	CH895
5982	458.0452-01	Support	CH895
5983	840.0021-00	Screw	CH895
5984	847.0012-00	Washer	CH895
5985	984.0217-00	Sensor	CH895
5986	452.6163-001	Air Chamber	CH895
5987	873.0386-00	Seal Tredo	CH895
5988	900.0436-00	Compression Fitting	CH895
5989	452.6059-001	Flange Air Inlet Flange	CH895
5990	900.2279-00	Plug	CH895
5991	840.0044-00	Screw	CH895
5992	847.0147-00	Washer	CH895
5993	840.0053-00	Screw	CH895
5994	847.0015-00	Washer	CH895
5995	873.0384-00	Seal Tredo	CH895

5996	984.1632-00	Pressure Transmitter	CH895
5997	452.6152-002	Steel Pipe	CH895
5998	452.6152-003	Steel Pipe	CH895
5999	840.0054-00	Screw	CH895
6000	900.2587-00	Flange Section	CH895
6001	840.0049-00	Screw	CH895
6002	452.6273-001	Cover Lid	CH895
6003	900.3078-00	Adapter	CH895
6004	873.1295-00	O-Ring	CH895
6005	900.3077-00	Compression Fitting	CH895
6006	900.0778-00	Clamping Ring	CH895
6007	873.1547-00	O-Ring	CH895
6008	900.2302-00	Plug	CH895
6009	900.3079-00	Clamp	CH895
6010	900.2118-00	Cover Plate	CH895
6011	840.0588-00	Screw	CH895
6012	847.0164-00	Washer	CH895
6013	452.6099-001	Protective Plate	CH895
6014	900.0193-00	Hexagon Nipple	CH895
6015	900.2846-00	Socket	CH895
6016	900.2809-00	Hose Coupling Hose	CH895
6017	452.6272-001	Hose	CH895
6018	452.3811-901	Air Cleaner	CH895
6019	900.3080-00	Nipple	CH895
6020	900.1722-00	Hose Clip	CH895
6021	906.0538-00	Overpressure Fan Becker	CH895
6022	840.0021-00	Screw	CH895
6023	972.1328-00	W22 71-2B5-0,55 4 525V50	CH895
6024	972.1314-00	W22 71-2B5-0,55 4 575V60	CH895
6025	972.1297-00	W22 71-2B5-0,55 4 460V60	CH895
6026	972.1283-00	W22 71-2B5-0,55 4 400Vd50	CH895
6027	899.0483-00	Mounting Band	CH895
6028	912.0262-00	Air Cleaner	CH895
6029	900.2806-00	Reducer	CH895
6030	452.3800-901	Reducing Pipe	CH895
6031	921.0261-00	Topspin	CH895
6032	900.2804-00	Clamp 133 To 156 Mm	CH895
6033	900.2807-00	Clamp 184 To 206 Mm	CH895

6034	912.0263-00	Air Filter Element	CH895
6035	900.2084-00	Clamping Ring	CH895
6036	452.6223-901	Tool List Complete	CH895
6037	442.9476-00	Tool Box	CH895
6038	452.6267-001	Tool List	CH895
6039	442.9443-00	Lifting Tool Eccentric Bushing	CH895
6040	442.9444-00	Lifting Tool Bottomshell Bushing	CH895
6041	442.9446-00	Lifting Tool	CH895
6042	452.6180-901	Piston Retainer As.	CH895
6043	442.7284-90	Lowering Rod	CH895
6044	843.1529-00	Lowering Rod	CH895
6045	845.0013-00	Nut	CH895
6046	899.0515-00	Lifting Eye Bolt	CH895
6047	899.0511-00	Lifting Eye Bolt	CH895
6048	899.0510-00	Lifting Eye Bolt	CH895
6049	899.0509-00	Lifting Eye Bolt	CH895
6050	899.0508-00	Lifting Eye Bolt	CH895
6051	899.0507-00	Lifting Eye Bolt	CH895
6052	899.0512	Lifting Eye Bolt	CH895
6053	920.0110-00	Slugging Wrench	CH895
6054	920.0109-00	Slugging Wrench	CH895
6055	920.0238-00	Slugging Wrench	CH895
6056	920.0243-00	Combination Wrench	CH895
6057	920.0131-00	Combination Wrench	CH895
6058	920.0135-00	Combination Wrench	CH895
6059	920.0134-00	Combination Wrench	CH895
6060	920.0022-00	Combination Wrench	CH895
6061	920.0044-00	Combination Wrench	CH895
6062	920.0245-00	Tool Combination Wrench	CH895
6063	920.0042-00	Socket Screw Key	CH895
6064	920.0040-00	Socket Screw Key	CH895
6065	920.0038-00	Socket Screw Key	CH895
6066	920.0037-00	Socket Screw Key	CH895
6067	920.0035-00	Socket Screw Key	CH895
6068	920.0032-00	Socket Screw Key	CH895
6069	442.0800-91	Chunk Of Lead As.	CH895
6070	923.0422-00	Feeler Gauge	CH895
6071	452.0452-001	Lifting Tool	CH895

6072	904.0585-00	Air Bleeder Hose	CH895
6073	126.0447-001	Logotype Silver	CH895
6074	126.0753-001	Sign Product Name	CH895
6075	126.0384-001	Warning Flying Fragments	CH895
6076	126.5007-01	Identification Plate	CH895
6077	126.0345-001	Patent Information Sign	CH895
6078	885.0267-00	Warning Sign Danger	CH895
6079	126.0383-001	Risk Of Crushing	CH895
6080	126.0385-001	Warning Sign Read Manual	CH895
6081	452.6079-001	Hydraulic Hose	CH895
6082	452.6077-001	Hydraulic Hose	CH895
6083	452.6078-001	Hydraulic Hose	CH895
6084	900.2592-00	Flange Half	CH895
6085	442.9396-00	Bend As.	CH895
6086	452.1616-901	Return Oil Hose	CH895
6087	873.0390-00	Seal Ring Tredo 30	CH895
6088	900.2599-00	Adapter	CH895
6089	452.1579-001	Hose	CH895
6090	873.1299-00	O-Ring	CH895
6091	873.0129-00	O-Ring	CH895
6092	452.1536-901	Straight Hose Coupling	CH895
6093	873.0755-00	O-Ring	CH895
6094	900.2199-00	Flange	CH895
6095	900.2385-00	Flange	CH895
6096	452.1591-001	Flange	CH895
6097	452.1590-001	Flange	CH895
6098	841.0268-00	Screw	CH895
6099	847.0147-00	Washer Round	CH895
6100	840.0068-00	Screw	CH895
6101	847.0016-00	Washer	CH895
6102	845.0215-00	Lock Nut High	CH895
6103	841.0253-00	Screw	CH895
6104	847.0144-00	Washer	CH895
6105	845.0213-00	Lock Nut	CH895
6106	840.1222-00	Screw	CH895
6107	452.6153-001	Connection Manifold	CH895
6108	847.0359-00	Washer	CH895
6109	840.0934-00	Screw	CH895

6110	840.1300-00	Screw	CH895
6111	900.2302-00	Plug	CH895
6112	452.7646-901	Bracket For Hydroset Security Valve Alt	CH895
6113	900.1140-00	Clip	CH895
6114	841.0219-00	Screw	CH895
6115	452.6179-00	Hose	CH895
6116	452.7650-901	Hydroset Security Valve Alt.	CH895
6117	452.7445-001	Spacer	CH895
6118	452.7446-001	Spacer	CH895
6119	452.6001-002	Plate Left	CH895
6120	452.6001--001	Plate Right	CH895
6121	452.1488-902	Hydroset Safety Valve	CH895
6122	452.7171-903	Electric Dump Valve	CH895
6123	452.1488-901	Hydroset Safety Valve Assembly	CH895
6124	902.0850-00	Main Valve	CH895
6125	902.0806-00	Seal Kit	CH895
6126	902.1123-00	Valve Block	CH895
6127	452.0978-001	Block	CH895
6128	900.2291-00	Adapter	CH895
6129	900.2292-00	Measuring Nipple	CH895
6130	900.0647-00	Adapter	CH895
6131	873.0384-00	Seal Ring Tredo	CH895
6132	902.0852-91	Pressure Relief Valve	CH895
6133	847.0147-00	Washer Round	CH895
6134	452.1511-00	Pilot Valve Protection	CH895
6135	840.0044-00	Screw	CH895
6136	900.2602-00	Flange	CH895
6137	452.1580-001	Hose	CH895
6138	452.1592-001	Cover	CH895
6139	847.0144-00	Washer	CH895
6140	841.0253-00	Screw	CH895
6141	845.0213-00	Lock Nut High	CH895
6142	452.7171	Electric Dump Valve Assembly	CH895
6143	452.7730-901	Electric Dump Valve Without Pressure	CH895
6144	902.0852-91	Pressure Relief Valve	CH895
6145	452.7730-901	Electric Dump Valve Without Pressure	CH895
6146	452.7099-001	Hydraulic Manifold	CH895
6147	900.2292-00	Measuring Nipple	CH895

6148	900.2279-00	Plug	CH895
6149	900.2673-0	Plug	CH895
6150	902-1175-00	Needle Valve	CH895
6151	452.7172-001	Protective Cover	CH895
6152	452.7175-001	Protective Cover	CH895
6153	902.1152-00	Logic Component	CH895
6154	902.1153-00	Spacer	CH895
6155	902.1154-00	Cover	CH895
6156	902.1155-00	Directional Valve	CH895
6157	847.0016-00	Washer	CH895
6158	840.0066-00	Screw	CH895
6159	873.0384-00	Seal Ring	CH895
6160	900.1030-00	Adapter	CH895
6161	847.0012-00	Washer	CH895
6162	841.0236-00	Screw	CH895
6163	964.3173-00	Cap Bottom Bulkhead	CH895
6164	964.3174-00	Cage Insert	CH895
6165	843.0873-00	Screw	CH895
6166	984.1677-00	Heater	CH895
6167	923.0566-00	Temperature Sensor	CH895
6168	984.1678-00	Pressure Transmitter	CH895
6169	841.0224-00	Screw	CH895
6170	902.1166-00	Sealing	CH895
6171	902.1167-00	Compression Spring	CH895
6172	902.1158-00	R-Ring	CH895
6173	902.1159-00	O-Ring	CH895
6174	902.1157-00	Sealing	CH895
6175	902.1154-00	Cover	CH895
6176	902.1161-00	Solenoid Coil	CH895
6177	902.1160-00	O-Ring	CH895
6178	290.0105-903	Electrical Cabinet, Siemens	CH895
6179	966.3822-00	Main Switch	CH895
6180	960.0782-00	Cable	CH895
6181	960.0783-00	Cable	CH895
6182	290.0104-903	Electrical Cabinet, Siemens	CH895
6183	290.0113-901	Spec Plc System	CH895
6184	978.0554-00	Power Supply Unit	CH895
6185	978.0555-00	Analog In Card	CH895

6186	978.0557-00	Digital In Card	CH895
6187	978.0558-00	Digital Out Card	CH895
6188	978.0559-00	Digital Out Card	CH895
6189	978.0561-00	Connecting Terminal Plate	CH895
6190	978.0560-00	Connecting Terminal Plate	CH895
6191	966.3422-00	Relay	CH895
6192	290.0115-901	Display	CH895
6193	962.0575-00	Mini Circuit Breaker	CH895
6194	962.0565-00	Mini Circuit Breaker	CH895
6195	962.0522-00	Mini Circuit Breaker	CH895
6196	975.0321-00	Power Supply Unit	CH895
6197	975.0318-00	Power Supply Unit	CH895
6198	966.3192-00	Earth Fault Breaker	CH895
6199	962.0498-00	Mini Circuit Breaker	CH895
6200	978.0537-00	Connector	CH895
6201	962.0534-00	Auxiliary Contact	CH895
6202	290.0113-901	Spec Plc System	CH895
6203	293.0088-001	Plc Program	CH895
6204	978.0552-00	Cpu Unit	CH895
6205	978.0553-00	Cpu Card	CH895
6206	293.0098-001	Instruction	CH895
6207	290.0115-901	Display	CH895
6208	293.0088-001	Program	CH895
6209	978.0562-00	Display	CH895
6210	293.0098-001	Instruction	CH895
6211	290.0105-903	Electrical Cabinet, Beckhoff	CH895
6212	966.3822-00	Main Switch	CH895
6213	960.0782-00	Cable	CH895
6214	960.0783-00	Cable	CH895
6215	290.0105-903	Electrical Cabinet, Beckhoff	CH895
6216	978.0564-00	Cpu Unit	CH895
6217	978.0571-00	Analog In Card	CH895
6218	978.0565-00	Digital In Card	CH895
6219	978.0566-00	Digital Out Card	CH895
6220	978.0567-00	Power Supply Unit	CH895
6221	978.0568-00	Digital Out Card	CH895
6222	966.3422-00	Relay	CH895
6223	290.0114-901	Spec Plc System	CH895

6224	962.0575-00	Mini Circuit Breaker	CH895
6225	962.0565-00	Mini Circuit Breaker	CH895
6226	962.0522-00	Mini Circuit Breaker	CH895
6227	975.0321-00	Power Supply Unit	CH895
6228	975.0318-00	Power Supply Unit	CH895
6229	966.3192-00	Earth Fault Breaker	CH895
6230	962.0498-00	Mini Circuit Breaker	CH895
6231	978.0537-00	Connector	CH895
6232	962.0534-00	Auxiliary Contact	CH895
6233	290.0114-901	Spec Plc System	CH895
6234	293.0089-001	Plc Program	CH895
6235	978.0563-00	Display	CH895
6236	293.0099-001	Instruction	CH895
6237	452.6090-901	Bracket	CH895
6238	452.6093-901	Bracket Fzb	CH895
6239	452.6096-001	Bar	CH895
6240	452.6127-001	Bracket Fzb	CH895
6241	452.6088-901	Wear Liner	CH895
6242	452.1425-901	Support	CH895
6243	452.1426-001	Bracket	CH895
6244	847.0016-00	Washer	CH895
6245	845.0215-00	Lock Nut	CH895
6246	452.6103-001	Rubber Protection	CH895
6247	452.6134-001	Bar	CH895
6248	840.1097-00	Screw	CH895
6249	452.6169-001	Support Fzb	CH895
6250	840.0070-00	Screw	CH895
6251	452.6175-001	Fixing Bar Fzb	CH895
6252	452.6166-001	Rubber Protection	CH895
6253	840.0065-00	Screw	CH895
6254	840.0072-00	Screw	CH895
6255	840.0067-00	Screw	CH895
6256	452.6170-001	Protective Cover	CH895
6257	847.0147-00	Washer Round	CH895
6258	840.0044-00	Screw	CH895
6259	873.0390-00	Seal Ring	CH895
6260	900.0659-00	Adapter	CH895
6261	452.1587-001	Hose	CH895

6262	452.1580-001	Hose	CH895
6263	452.1538-001	Hose	CH895
6264	452.1616-901	Return Oil Hose	CH895
6265	452.1591-001	Cover	CH895
6266	841.0253-00	Screw	CH895
6267	845.0213-00	Lock Nut	CH895
6268	847.0144-00	Washer	CH895
6269	900.2385-00	Flange Half	CH895
6270	873.1299-00	O-Ring	CH895
6271	452.1592-001	Cover	CH895
6272	900.2602-00	Flange Half	CH895
6273	873.0615-00	O-Ring	CH895
6274	452.1589-001	Cover	CH895
6275	900.2592-00	Flange Half	CH895
6276	845.0030-00	Lock Nut	CH895
6277	847.0147-00	Washer Round	CH895
6278	841.0268-00	Screw	CH895
6279	873.0755-00	O-Ring	CH895
6280	452.1536-901	Straight Hose Coupling	CH895
6281	900.2199-00	Flange	CH895
6282	840.0068-00	Screw	CH895
6283	847.0016-00	Washer	CH895
6284	845.0215-00	Lock Nut High	CH895
6285	873.0129-00	O-Ring	CH895
6286	452.1590-001	Cover	CH895
6287	442.9308-02	Locating Bar	CH895
6288	442.9362-01	Shim	CH895
6289	442.9362-02	Shim T	CH895
6290	442.9362-03	Shim T	CH895
6291	442.9362-04	Shim T	CH895
6292	841.0256-00	Screw	CH895
6293	442.9364-01	Gasket	CH895
6294	442.9364-02	Gasket	CH895
6295	442.9364-03	Gasket	CH895
6296	868.0832-00	Bearing	CH895
6297	845.0164-00	Lock Nut	CH895
6298	847.0299-00	Lock Washer	CH895
6299	442.9809-01	Wear Ring	CH895

6300	442.9334-01	Spacer Pt.	CH895
6301	442.9808-01	Spacer Pt.	CH895
6302	873.0136-00	O-Ring	CH895
6303	873.1219-00	Oil Seal Ring Type	CH895
6304	442.9365-01	Gasket	CH895
6305	442.9366-01	Gasket	CH895
6306	873.0387-00	Seal Ring	CH895
6307	873.0386-00	Seal Ring	CH895
6308	840.1279-00	Screw	CH895
6309	845.0273-00	Lock Nut Low	CH895
6310	442.9353-01	Cage	CH895
6311	442.9354-01	Washer	CH895
6312	863.0015-00	Disc Spring	CH895
6313	452.5430-001	Spacer	CH895
6314	452.5923-901	Liner Pinionshaft Arm	CH895
6315	452.5925-001	Liner Narrow Arm	CH895
6316	912.0126-00	Filter	CH895
6317	912.0129-00	Filter Cartridge	CH895
6318	912.0139-00	Filter Cartridge	CH895
6319	912.0219-00	Filter Cartridge	CH895
6320	912.0155-00	Filter Cartridge	CH895
6321	452.5921-901	Feed Hopper, Lower	CH895
6322	452.5922-001	Feed Hopper	CH895
6323	847.0016-00	Washer	CH895
6324	840.0075-00	Screw	CH895
6325	845.0215-00	Lock Nut High	CH895
6326	452.6029-901	Rubber Lining Lower Assembly	CH895
6327	840.0068-00	Screw	CH895
6328	452.6028-001	Rubber Sheet	CH895
6329	847.0016-00	Washer	CH895
6330	845.0215-00	Lock Nut	CH895
6331	873.1287-00	Rubber Plug	CH895
6332	452.6128-901	Feed Hopper, Upper	CH895
6333	442.9736-00	Feed Hopper Upper	CH895
6334	452.3688-901	Rubber Sheet	CH895
6335	840.0078-00	Screw	CH895
6336	847.0132-00	Washer Round	CH895
6337	845.0203-00	Lock Nut High	CH895

6338	840.0068-00	Screw	CH895
6339	847.0016-00	Washer	CH895
6340	845.0215-00	Nut Lock	CH895
6341	650.0327-00	Inspection Door	CH895
6342	452.3688-901	Rubber Sheet	CH895
6343	442.9747-01	Wt6000 50X500X750	CH895
6344	442.9750-01	Wt6000 50X500X550	CH895
6345	840.0068-00	Screw	CH895
6346	845.0215-00	Nut Lock	CH895
6347	847.0016-00	Washer	CH895
6348	840.0071-00	Screw	CH895
6349	873.1287-00	Rubber Plug	CH895
6350	452.5514-901	Cover And Splitter	CH895
6351	452.3984-901	Cover	CH895
6352	452.2939-901	Splitter	CH895
6353	452.3984-901	Cover	CH895
6354	452.3985-901	Cover	CH895
6355	840.0068-00	Screw	CH895
6356	847.0016-00	Washer	CH895
6357	845.0215-00	Nut Lock	CH895
6358	840.0066-00	Screw	CH895
6359	452.2939-901	Splitter	CH895
6360	452.2938-901	Adjusting Unit	CH895
6361	452.2937-901	Distribution Box	CH895
6362	452.1447-001	Wearing Plate	CH895
6363	840.1135-00	Screw	CH895
6364	847.0197-00	Washer	CH895
6365	452.2963-901	Clamping Plate	CH895
6366	845.0203-00	Nut Lock	CH895
6367	BG00509994	Top Shell After Market Assembly	CH895
6368	912.0114-00	Air Filter Element	CH895
6369	912.0155-00	Filter Insert	CH895
6370	900.1030-00	Adapter	CH895
6371	900.0425-00	Pipe Joint	CH895
6372	452.5971-001	Steel Pipe	CH895
6373	452.5984-001	Steel Pipe	CH895
6374	191.2376-00	Temperature Sensor	CH895
6375	290.0058-901	Connection Box	CH895

6376	900.0654-00	Adapter	CH895
6377	900.2624-00	Nut	CH895
6378	900.0431-00	Pipe Joint	CH895
6379	452.5983-001	Pipe	CH895
6380	914.0093-00	Lubrication Nipple	CH895
6381	452.6068-901	Rim Liner / Liner	CH895
6382	452.6071-901	Arm Shield	CH895
6383	873.1232-00	O-Ring	CH895
6384	452.6215-901	Transportation Rack	CH895
6385	885.0260-00	Sign, Lifting Point Truck	CH895
6386	885.0250-00	Sign, Center Of Gravity	CH895
6387	885.0262-00	Lifting Chain Plate	CH895
6388	873.0384-00	Bonded Seal, Self Centering	CH895
6389	BG00509335	Top Shell After Market Assembly	CH895
6390	912.0114-00	Air Filter Element	CH895
6391	912.0155-00	Filter Insert	CH895
6392	900.1030-00	Adapter	CH895
6393	900.0425-00	Pipe Joint	CH895
6394	452.5971-001	Steel Pipe	CH895
6395	452.5984-001	Steel Pipe	CH895
6396	191.2376-00	Temperature Sensor	CH895
6397	290.0058-901	Connection Box	CH895
6398	900.0654-00	Adapter	CH895
6399	900.2624-00	Nut	CH895
6400	900.0431-00	Pipe Joint	CH895
6401	452.5983-001	Pipe	CH895
6402	914.0093-00	Lubrication Nipple	CH895
6403	452.6068-901	Rim Liner / Liner Tertiary	CH895
6404	452.6071-901	Arm Shield	CH895
6405	442.9266-01	Spider Bushing	CH895
6406	847.0132-00	Washer Round	CH895
6407	840.0652-00	Screw	CH895
6408	BG01122636	Spider Cap Kit	CH895
6409	873.1232-00	O-Ring	CH895
6410	840.0653-00	Screw	CH895
6411	442.9313-01	Support Ring	CH895
6412	452.5430-001	Spacer Fzb	CH895
6413	BG00733121	Washer	CH895

6414	BG00733104	Sleeve Disc Spring	CH895
6415	863.0015-00	Disc Spring	CH895
6416	845.0273-00	Lock Nut Low	CH895
6417	840.1279-00	Screw	CH895
6418	452.6215-901	Transportation Rack	CH895
6419	885.0260-00	Sign, Lifting Point Truck	CH895
6420	885.0250-00	Sign, Center Of Gravity	CH895
6421	885.0262-00	Lifting Chain Plate	CH895
6422	831.0016-00	Casting Compound	CH895
6423	BG00880139	Scraper Package	CH895
6424	BG00206187	Dowel Pin	CH895
6425	873.0384-00	Bonded Seal, Self Centering	CH895
6426	840.1175-00	Screw	CH895
6427	442.9979-01	Washer	CH895
6428	847.0171-00	Washer	CH895
6429	845.0322-00	Nut	CH895
6430	442.9530-02	Screw	CH895
6431	899.0278-00	Protecting Cap	CH895
6432	BG00733156	Concave Bolt Set	CH895
6433	452.5430-001	Spacer Fzb	CH895
6434	BG00733121	Washer	CH895
6435	863.0015-00	Disc Spring	CH895
6436	BG00733104	Disc Spring Sleeve	CH895
6437	845.0273-00	Lock Nut	CH895
6438	840.1279-00	Screw	CH895
6439	452.6068-901	Rim Liner Tertiary Assembly	CH895
6440	452.5835-001	Rim Liner	CH895
6441	452.6069-001	Bar	CH895
6442	452.6071-901	Arm Shield	CH895
6443	452.5841-001	Arm Shield	CH895
6444	452.6072-001	Bar	CH895
6445	BG01122636	Spider Cap Kit	CH895
6446	900.2970-00	Plug R 1"	CH895
6447	BG00284338-01	Concave Hr	CH895
6448	BG00284338-05	Concave Hr	CH895
6449	452.1067-001	Concave Efx	CH895
6450	452.1067-005	Concave Efx	CH895
6451	452.0263-001	Concave Ef	CH895

6452	452.0263-005	Concave Ef	CH895
6453	452.0579-001	Concave Eef	CH895
6454	452.0579-005	Concave Eef	CH895
6455	BG00880139	Scraper Package	CH895
6456	BG00842934	Support Ring	CH895
6457	BG00842937	Ring	CH895
6458	452.0418-001	Seal Ring	CH895
6459	841.0672-00	Shoulder Screw	CH895
6460	BG00505358	Main Shaft Assembly Excluding Mantle	CH895
6461	442.9294-01	Main Shaft Sleeve	CH895
6462	853.0988-00	Pin	CH895
6463	855.0026-00	Retaining Ring	CH895
6464	442.9269-01	Head Nut Inner	CH895
6465	899.0515-00	Eye Bolt	CH895
6466	442.9620-00	Transport Rack	CH895
6467	885.0250-00	Sign, Center Of Gravity	CH895
6468	BG00504841	Main Shaft Assembly Including Mantle	CH895
6469	442.9294-01	Main Shaft Sleeve	CH895
6470	853.0988-00	Pin	CH895
6471	855.0026-00	Retaining Ring	CH895
6472	442.9269-01	Head Nut Inner	CH895
6473	442.9270-00	Head Nut With Burning Ring	CH895
6474	831.0016-00	Casting Compound	CH895
6475	452.6045-001	Retaining Ring, Dust Seal Ring	CH895
6476	847.0016-00	Washer	CH895
6477	840.0070-00	Screw	CH895
6478	BG00663893	Dust Seal Ring	CH895
6479	442.9367-01	Retainer	CH895
6480	840.0067-00	Screw	CH895
6481	452.6114-001	Scraper	CH895
6482	452.6722-001	Distance	CH895
6483	840.0065-00	Screw	CH895
6484	842.0230-00	Screw	CH895
6485	899.0515-00	Eye Bolt	CH895
6486	442.9620-00	Transport Rack	CH895
6487	885.0250.00	Sign, Center Of Gravity	CH895
6488	452.4051-001	Mantle Ob	CH895
6489	452.4051-005	Mantle Ob	CH895

6490	442.9339-01	Mantle B	CH895
6491	442.9339-005	Mantle B	CH895
6492	442.9758-01	Mantle Hc	CH895
6493	442.9758-005	Mantle Hc	CH895
6494	452.0264-001	Mantle Ef	CH895
6495	452.0264-005	Mantle Ef	CH895
6496	442.9314-01	Mantle A	CH895
6497	442.9314-005	Mantle A	CH895
6498	BG00282784-01	Mantle Flexifeed A	CH895
6499	BG00282784-05	Mantle Flexifeed A	CH895
6500	442.9270-00	Head Nut With Burning Ring	CH895
6501	442.9306-01	Burning Ring	CH895
6502	873.0720-00	Protection Plug	CH895
6503	452.6434-901	Dust Collar Assembly	CH895
6504	452.6435-001	Dust Collar	CH895
6505	853.0464-00	Pin	CH895
6506	442.9309-01	Ring	CH895
6507	442.9310-01	Seal Ring	CH895
6508	442.9362-01	Shim	CH895
6509	442.9362-02	Shim	CH895
6510	442.9362-03	Shim	CH895
6511	442.9362-04	Shim	CH895
6512	442.9308-02	Locating Bar	CH895
6513	841.0256-00	Screw	CH895
6514	847.0016-00	Washer	CH895
6515	840.0943-00	Screw	CH895
6516	840.0064-00	Screw	CH895
6517	873.1545-00	O-Ring	CH895
6518	873.1548-00	O-Ring	CH895
6519	452.5801-901	Locating Bar Kit	CH895
6520	442.9308-02	Locating Bar	CH895
6521	442.9362-01	Shim	CH895
6522	442.9362-02	Shim	CH895
6523	442.9362-03	Shim	CH895
6524	442.9362-04	Shim	CH895
6525	841.0256-00	Screw	CH895
6526	BG00998271	Eccentric After Market Assembly	CH895
6527	BG01006849	Eccentric	CH895

6528	442.9357-01	Eccentric Bushing, Throw	CH895
6529	442.9246-01	Hub	CH895
6530	442.9274-00	Ring	CH895
6531	840.0068-00	Screw	CH895
6532	847.0016-00	Washer	CH895
6533	442.9469-01	Key	CH895
6534	442.9275-01	Key	CH895
6535	841.0036-00	Screw	CH895
6536	841.0032-00	Screw	CH895
6537	847.0181-00	Washer	CH895
6538	BG00998422	Eccentric After Market Assembly	CH895
6539	BG01006849	Eccentric	CH895
6540	442.9358-01	Eccentric Bushing, Throw	CH895
6541	442.9246-01	Hub	CH895
6542	442.9274-00	Ring	CH895
6543	840.0068-00	Screw	CH895
6544	847.0016-00	Washer	CH895
6545	442.9469-01	Key	CH895
6546	442.9275-01	Key	CH895
6547	841.0036-00	Screw	CH895
6548	841.0032-00	Screw	CH895
6549	847.0181-00	Washer	CH895
6550	BG00998430	Eccentric After Market Assembly	CH895
6551	BG01006849	Eccentric	CH895
6552	442.9359-01	Eccentric Bushing, Throw	CH895
6553	442.9246-01	Hub	CH895
6554	442.9274-00	Ring	CH895
6555	840.0068-00	Screw	CH895
6556	847.0016-00	Washer	CH895
6557	442.9469-01	Key	CH895
6558	442.9275-01	Key	CH895
6559	841.0036-00	Screw	CH895
6560	841.0032-00	Screw	CH895
6561	847.0181-00	Washer	CH895
6562	BG00998432	Eccentric After Market Assembly	CH895
6563	BG01006849	Eccentric	CH895
6564	442.9360-01	Eccentric Bushing, Throw	CH895
6565	442.9246-01	Hub	CH895

6566	442.9274-00	Ring	CH895
6567	840.0068-00	Screw	CH895
6568	847.0016-00	Washer	CH895
6569	442.9469-01	Key	CH895
6570	442.9275-01	Key	CH895
6571	841.0036-00	Screw	CH895
6572	841.0032-00	Screw	CH895
6573	847.0181-00	Washer	CH895
6574	442.9357-01	Eccentric Bushing, Throw	CH895
6575	442.9358-01	Eccentric Bushing, Throw	CH895
6576	442.9359-01	Eccentric Bushing, Throw	CH895
6577	442.9360-01	Eccentric Bushing, Throw	CH895
6578	442.9639-00	Gear And Pinion Set	CH895
6579	442.9311-00	Gear And Pinion Set	CH895
6580	BG00617331	Bottom Shell After Market Assembly	CH895
6581	BG00477827	Transport Protection	CH895
6582	BG00928257	Transport Rack, Bottom Shell	CH895
6583	840.1117-00	Screw	CH895
6584	845.0427-00	Hexagon Nut	CH895
6585	847.0026-00	Washer	CH895
6586	452.6507-901	Lifting Tool	CH895
6587	452.6946-001	Secure Plate	CH895
6588	840.1073-00	Screw	CH895
6589	845.0322-00	Nut	CH895
6590	885.0261-00	Information Sign - Lift Here/ Secure	CH895
6591	885.0260-00	Sign - Lifting Point Truck	CH895
6592	126.0384-001	Warning Sign - Flying Fragments	CH895
6593	126.0385-001	Mandatory Sign - Read Manual	CH895
6594	126.0383-001	Warning Sign - Risk Of Crushing	CH895
6595	840.1300-00	Screw	CH895
6596	847.0359-00	Washer	CH895
6597	452.7446-001	Spacer	CH895
6598	452.6001-002	Plate Left	CH895
6599	841.0271-00	Screw	CH895
6600	BG00465619	Pinion Adjustment Boss	CH895
6601	840.0066-00	Screw	CH895
6602	847.0016-00	Washer Brb	CH895
6603	BG00603087	Plate, Hoses	CH895

6604	840.0068-00	Screw	CH895
6605	BG00603086	Plate, Rubber Protection	CH895
6606	BG00841851	Hatch	CH895
6607	BG00601852	Arm Liner Assembly	CH895
6608	BG00598672	Wear Plate Assembly	CH895
6609	BG00578266	Dust Seal Air Pressure Connection	CH895
6610	BG00603915	Foot Assembly	CH895
6611	BG00601743	Bottom Shell Machined	CH895
6612	S 223.1412-xx	Modification Guide, Bottom Shell	CH895
6613	BG00392209	Corrlam Alu	CH895
6614	885.0250-00	Information Sign - Center Of Gravity	CH895
6615	BG00617331	Bottom Shell After Market Assembly	CH895
6616	845.0215-00	Lock Nut	CH895
6617	853.0464-00	Pin	CH895
6618	923.0584-00	Temperature Sensor	CH895
6619	BG00779564	Counter Nut	CH895
6620	BG01208014	Sign	CH895
6621	442.9248-01	Bottom Shell Bushing	CH895
6622	442.9396-00	Bend	CH895
6623	900.2199-00	Split Flange Clamp	CH895
6624	847.0016-00	Washer	CH895
6625	840.0070-00	Screw	CH895
6626	873.1556-00	O-Ring	CH895
6627	853.0109-00	Pin	CH895
6628	442.9249-02	Eccentric Wearing Plate	CH895
6629	847.0359-00	Washer	CH895
6630	840.1180-00	Screw	CH895
6631	BG00601852	Arm Liner Assembly	CH895
6632	BG00873434	Liner Narrow Arm	CH895
6633	BG00872668	Liner Pinion Shaft Arm	CH895
6634	BG00234474	Washer Plate, Protection For The Bolt	CH895
6635	845.0462-00	Spherical Collar Nut	CH895
6636	840.1345-00	Screw	CH895
6637	BG00865034	Angle Washer	CH895
6638	BG00865035	Rubber Washer	CH895
6639	BG00874339	Arm Liner Distance	CH895
6640	842.0317-00	Screw	CH895
6641	BG00598672	Wear Plate Assembly	CH895

6642	BG00864214	Wear Plate, Small	CH895
6643	BG00864259	Wear Plate, Large	CH895
6644	BG00864279	Wear Plate Assembly, Large With	CH895
6645	845.0215-00	Lock Nut	CH895
6646	843.1658-00	Bolt	CH895
6647	BG00865035	Washer, Rubber	CH895
6648	BG00865034	Angle Washer	CH895
6649	BG01142308	Washer	CH895
6650	BG00864279	Wear Plate Assembly	CH895
6651	BG00551149	Rubber Spacer	CH895
6652	853.0231-00	Split Pin	CH895
6653	BG01241953	Sealing	CH895
6654	BG00578266	Dust Seal Air Pressure Connection	CH895
6655	452.6163-001	Air Chamber	CH895
6656	873.0386-00	Seal Ring Tredo	CH895
6657	900.0436-00	Pipe Joint	CH895
6658	452.6059-001	Air Inlet Flange	CH895
6659	900.2279-00	Plug	CH895
6660	840.0044-00	Screw	CH895
6661	847.0147-00	Washer	CH895
6662	840.0053-00	Screw	CH895
6663	840.0054-00	Screw	CH895
6664	900.2587-00	Split Flange Clamp	CH895
6665	840.0049-00	Screw	CH895
6666	900.3206-00	Plug Sae	CH895
6667	900.3078-00	Adapter	CH895
6668	900.3077-00	Pipe Joint	CH895
6669	900.0778-00	Clamping Ring	CH895
6670	900.2302-00	Plug	CH895
6671	873.1295-00	O-Ring	CH895
6672	BG01184463	Protecting Plate	CH895
6673	BG00578266	Dust Seal Air Pressure Connection	CH895
6674	873.0384-00	Self Centering Bonded Seal	CH895
6675	BG00578264	Steel Pipe, Right	CH895
6676	BG00578261	Steel Pipe, Left	CH895
6677	873.1547-00	O-Ring	CH895
6678	984.1700-00	Pressure Transmitter	CH895
6679	900.3079-00	Clamp	CH895

6680	847.0164-00	Washer	CH895
6681	841.0433-00	Screw	CH895
6682	841.0225-00	Screw	CH895
6683	BG00261638	Clamping Plate	CH895
6684	900.2118-00	Cover Plate	CH895
6685	BG00603915	Foot Assembly	CH895
6686	452.1064-001	Foot	CH895
6687	847.0125-00	Washer	CH895
6688	840.0693-00	Screw	CH895
6689	BG00998256	Hydroset Cylinder Assembly	CH895
6690	452.5973-001	Hydroset Cylinder	CH895
6691	452.5942-001	Hydroset Cylinder Cover	CH895
6692	847.0310-00	Washer	CH895
6693	840.1176-00	Screw	CH895
6694	442.9256-01	Hydroset Cylinder Bushing	CH895
6695	840.0032-00	Screw	CH895
6696	847.0144-00	Washer	CH895
6697	873.1233-00	O-Ring	CH895
6698	873.1210-00	O-Ring	CH895
6699	873.1211-00	O-Ring	CH895
6700	919.0190-00	Protection Plug	CH895
6701	873.0237-00	O-Ring	CH895
6702	984.0421-00	Position Sensor	CH895
6703	841.0628-00	Screw	CH895
6704	847.0016-00	Washer	CH895
6705	840.0069-00	Screw	CH895
6706	452.6139-001	Flange Measure System	CH895
6707	900.2292-00	Measuring Nipple G 1/4"	CH895
6708	452.6129-901	Measuring Tube Holder As.	CH895
6709	853.0988-00	Pin	CH895
6710	452.6075-001	Piston	CH895
6711	442.9257-00	Chevron Packing As.	CH895
6712	442.9304-01	Packing Clamping Plate	CH895
6713	841.0267-00	Screw	CH895
6714	452.2631-901	Step Bearing Set	CH895
6715	847.0310-00	Washer	CH895
6716	840.1176-00	Screw	CH895
6717	452.6129-901	Measuring Tube Holder Assembly	CH895

6718	452.6130-001	Tube Measure Tube Holder	CH895
6719	452.6131-001	Lock Nut	CH895
6720	442.7568-04	Measuring Tube	CH895
6721	873.0102-00	O-Ring	CH895
6722	873.0391-00	Seal Ring Tredo	CH895
6723	442.9257-00	Chevron	CH895
6724	452.2631-901	Step Bearing Set	CH895
6725	452.6079-001	Hydraulic Hose	CH895
6726	452.6077-001	Hydraulic Hose	CH895
6727	452.6078-001	Hydraulic Hose	CH895
6728	442.9396-00	Bend	CH895
6729	452.1616-901	Return Oil Hose	CH895
6730	873.0390-00	Seal Ring	CH895
6731	900.2599-00	Adapter	CH895
6732	452.1579-001	Hose	CH895
6733	452.1536-901	Coupling, Hose	CH895
6734	900.2199-00	Split Flange Clamp	CH895
6735	452.1590-001	Cover	CH895
6736	840.0068-00	Screw	CH895
6737	847.0016-00	Washer	CH895
6738	845.0215-00	Lock Nut	CH895
6739	840.0934-00	Screw	CH895
6740	452.6179-001	Hose Cable Protection	CH895
6741	840.1222-00	Screw	CH895
6742	847.0359-00	Washer	CH895
6743	452.7445-001	Spacer	CH895
6744	873.1556-00	O-Ring	CH895
6745	900.2592-00	Split Flange Clamp	CH895
6746	873.1299-00	O-Ring	CH895
6747	873.0755-00	O-Ring	CH895
6748	900.2385-00	Split Flange Clamp	CH895
6749	452.1591-001	Cover	CH895
6750	841.0268-00	Screw	CH895
6751	847.0147-00	Washer	CH895
6752	841.0253-00	Screw	CH895
6753	847.0144-00	Washer Brb	CH895
6754	845.0213-00	Lock Nut	CH895
6755	452.6153-001	Connection Manifold	CH895

6756	900.2302-00	Plug	CH895
6757	900.1140-00	Clip	CH895
6758	841.0219-00	Screw	CH895
6759	452.6179-001	Hose Cable Protection	CH895
6760	452.1616-901	Return Oil Hose	CH895
6761	650.0326-15	Hose	CH895
6762	900.2548-00	Clip, Hose	CH895
6763	BG01265593-04	Mechanical Dump Valve Assembly	CH895
6764	BG01265593-02	Mechanical Dump Valve Assembly	CH895
6765	452.7171-903	Electric Dump Valve	CH895
6766	452.7171-906	Electric Dump Valve	CH895
6767	BG01265593	Mechanical Dump Valve Assembly	CH895
6768	BG01258702-02	Mechanical Dump Valve	CH895
6769	BG01258702-04	Mechanical Dump Valve	CH895
6770	873.0384-00	Self Centering Bonded Seal	CH895
6771	900.0647-00	Union Adapter	CH895
6772	452.1580-001	Hydraulic Hose	CH895
6773	900.2602-00	Split Flange Clamp	CH895
6774	452.1592-001	Flange Cover	CH895
6775	847.0144-00	Washer	CH895
6776	841.0253-00	Screw	CH895
6777	845.0213-00	Lock Nut	CH895
6778	BG01258702-02	Mechanical Dump Valve	CH895
6779	BG01258702-04	Mechanical Dump Valve	CH895
6780	BG01170915	Mechanical Dump Valve Subassembly	CH895
6781	BG01272612	Sign	CH895
6782	BG01272615	Sign K	CH895
6783	BG01094613	Sign	CH895
6784	BG01114414	Temperature Switch	CH895
6785	900.2279-00	Plug	CH895
6786	BG00487975	Sign	CH895
6787	902.0852-91	Pressure Relief Valve Cartridge	CH895
6788	984.1678-00	Pressure Transmitter	CH895
6789	923.0584-00	Temperature Sensor	CH895
6790	BG00428217	Sign K1-Tt1	CH895
6791	BG00267693	Sign K1-Pt1	CH895
6792	BG01170915	Mechanical Dump Valve Sub-Assembly	CH895
6793	BG01260846	Hydraulic Manifold	CH895

6794	902.0850-00	Logic Element Valve	CH895
6795	902.1123-00	Control Cover Assembly	CH895
6796	902.1175-00	Needle Valve Cartridge	CH895
6797	984.1677-00	Heater Cartridge	CH895
6798	964.3173-00	Panel Mounted Housing	CH895
6799	964.3256-00	Contact Insert	CH895
6800	BG00810640	Thread Reducer Adapter	CH895
6801	900.2292-00	Test Point	CH895
6802	900.2673-00	Plug	CH895
6803	900.2279-00	Plug	CH895
6804	BG01264599	Top Cover	CH895
6805	452.7175-001	Side Cover	CH895
6806	843.0873-00	Screw	CH895
6807	847.0016-00	Washer	CH895
6808	840.0066-00	Screw	CH895
6809	847.0012-00	Washer	CH895
6810	841.0236-00	Screw	CH895
6811	452.7171-903	Electric Dump Valve	CH895
6812	452.7171-906	Electric Dump Valve	CH895
6813	BG01014170	Electric Dump Valve Sub-Assembly	CH895
6814	902.0852-91	Pressure Relief Valve Cartridge	CH895
6815	BG00779431	Sign	CH895
6816	BG00428217	Sign	CH895
6817	BG01274289	Sign	CH895
6818	BG01094613	Sign	CH895
6819	BG01272612	Sign	CH895
6820	BG01272615	Sign	CH895
6821	900.2279-00	Plug	CH895
6822	984.1678-00	Pressure Transmitter	CH895
6823	BG00267693	Sign	CH895
6824	BG01014170	Electric Dump Valve Sub-Assembly	CH895
6825	BG01260846	Hydraulic Manifold	CH895
6826	BG00978424	Control Cover	CH895
6827	902.1152-00	Logic Element Valve	CH895
6828	902.1189-00	Directional Solenoid Valve	CH895
6829	902.1175-00	Needle Valve, Cartridge	CH895
6830	984.1678-00	Pressure Transmitter	CH895
6831	923.0566-00	Temperature Transmitter	CH895

6832	984.1677-00	Cartridge Heater	CH895
6833	964.3173-00	Contact Insert Housing	CH895
6834	964.3256-00	Male Contact Insert	CH895
6835	853.0302-00	Parallel Pin	CH895
6836	873.1245-00	O-Ring	CH895
6837	BG00981940	Orifice	CH895
6838	842.0210-00	Socket Set Screw	CH895
6839	900.2292-00	Test Point	CH895
6840	900.2673-00	Plug	CH895
6841	900.2279-00	Plug	CH895
6842	452.7172-001	Top Cover	CH895
6843	452.7175-00	Side Cover	CH895
6844	843.0873-00	Screw	CH895
6845	847.0016-00	Washer	CH895
6846	840.0066-00	Screw	CH895
6847	841.0224-00	Screw	CH895
6848	841.0651-00	Screw	CH895
6849	847.0012-00	Washer	CH895
6850	841.0236-00	Screw	CH895
6851	902.1189-00	Directional Solenoid Valve	CH895
6852	902.1200-00	Coil	CH895
6853	902.1201-00	Seal Kit	CH895
6854	902.1189-00	Directional Valve	CH895
6855	902.1200-00	Coil	CH895
6856	902.1201-00	Sealing Kit	CH895
6857	290.0117-901	Electrical Cabinet, Siemens	CH895
6858	966.3822-00	Main Switch	CH895
6859	290.0106-901	Cable Set	CH895
6860	290.0117-901	Electrical Cabinet, Siemens	CH895
6861	290.0113-901	Spec Plc System	CH895
6862	978.0554-00	Power Supply Unit	CH895
6863	978.0555-00	Analog In Card	CH895
6864	978.0557-00	Digital In Card	CH895
6865	978.0558-00	Digital Out Card	CH895
6866	978.0559-00	Digital Out Card	CH895
6867	978.0561-00	Connecting Terminal Plate	CH895
6868	978.0560-00	Connecting Terminal Plate	CH895
6869	966.3422-00	Relay	CH895

6870	290.0115-901	Display	CH895
6871	962.0575-00	Mini Circuit Breaker	CH895
6872	962.0565-00	Mini Circuit Breaker	CH895
6873	962.0522-00	Mini Circuit Breaker	CH895
6874	975.0321-00	Power Supply Unit	CH895
6875	975.0318-00	Power Supply Unit	CH895
6876	966.3192-00	Earth Fault Breaker	CH895
6877	962.0497-00	Mini Circuit Breaker	CH895
6878	978.0537-00	Connector	CH895
6879	962.0534-00	Auxiliary Contact	CH895
6880	BG01283963	Pinion Shaft Housing After Market	CH895
6881	BG01236441	Pinion Shaft Housing	CH895
6882	868.0832-00	Bearing	CH895
6883	847.0299-00	Lock Washer	CH895
6884	442.9809-01	Wear Ring	CH895
6885	845.0164-00	Lock Nut	CH895
6886	BG01237965	Pinion Shaft Spacer, Inner	CH895
6887	BG01178805	Pinion Shaft Spacer, Outer	CH895
6888	873.1709-00	Radial Oil Seal	CH895
6889	873.0136-00	O-Ring	CH895
6890	BG01241652	Bearing Cover, Inner	CH895
6891	840.0046-00	Screw	CH895
6892	847.0147-00	Washer	CH895
6893	840.0078-00	Screw	CH895
6894	847.0132-00	Washer	CH895
6895	442.9365-01	Gasket	CH895
6896	442.9807-01	Pinion Shaft	CH895
6897	900.2388-00	Plug	CH895
6898	857.0360-00	Key	CH895
6899	857.0354-00	Key	CH895
6900	900.0022-00	Elbow	CH895
6901	842.0020-00	Screw	CH895
6902	BG01178936	Oil Level Gauge	CH895
6903	873.0387-00	Self Centering Bonded Seal	CH895
		G	
6904	855.0030-00	Retaining Ring	CH895
6905	900.0655-00	Adapter	CH895
6906	900.0656-00	Adapter	CH895

6907	873.0386-00	Seal Ring Tredo 23	CH895
6908	BG01247642	Bearing Cover, Outer	CH895
6909	BG01222383	Temperature Sensor	CH895
6910	873.1492-00	O-Ring	CH895
6911	900.2673-00	Plug	CH895
6912	873.1546-00	O-Ring	CH895
6913	900.3274-00	Cap	CH895
6914	900.3180-00	Cap	CH895
6915	BG00486966	Sign	CH895
6916	S 223.1648.xx	Modification Guide, Pinion Shaft	CH895
6917	BG00392209	Corrlamalu-Vpci	CH895
6918	BG01226187	Shim	CH895
6919	BG01226198	Shim	CH895
6920	BG01226200	Shim	CH895
6921	840.1063-00	Screw	CH895
6922	845.0009-00	Nut	CH895
6923	847.0063-00	Washer	CH895
6924	840.0672-00	Screw	CH895
6925	BG01309093	Pinion Shaft Housing Repair Kit	CH895
6926	868.0832-00	Bearing	CH895
6927	847.0299-00	Lock Washer	CH895
6928	442.9809-01	Wear Ring	CH895
6929	845.0164-00	Lock Nut	CH895
6930	BG01237965	Spacer Pinion Shaft Spacer, Inner	CH895
6931	BG01178805	Spacer Pinion Shaft Spacer, Outer	CH895
6932	873.1709-00	Radial Oil Seal	CH895
6933	873.0136-00	O-Ring	CH895
6934	442.9365-01	Gasket	CH895
6935	873.0387-00	Self Centering	CH895
6936	873.0386-00	Seal Ring	CH895
6937	873.1492-00	O-Ring	CH895
6938	BG01226187	Shim	CH895
6939	BG01226198	Shim	CH895
6940	BG01226200	Shim	CH895
6941	BG00608554	Hydroset System	CH895
6942	BG00605797	Protection	CH895
6943	452.6089-901	Lubrication System	CH895
6944	BG00605797	Protection Assembly	CH895

6945	452.6088-901	Wear Liner	CH895
6946	452.1425-901	Support	CH895
6947	452.1426-001	Bracket	CH895
6948	847.0016-00	Washer Brb	CH895
6949	845.0215-00	Lock Nut	CH895
6950	452.6127-001	Bracket Fzb	CH895
6951	840.1097-00	Screw	CH895
6952	452.6169-001	Support Fzb	CH895
6953	840.0070-00	Screw	CH895
6954	452.6175-001	Mounting Bar Fzb	CH895
6955	840.0065-00	Screw	CH895
6956	840.0072-00	Screw	CH895
6957	840.0067-00	Screw	CH895
6958	843.1363-00	Bolt	CH895
6959	845.0016-00	Nut	CH895
6960	845.0030-00	Lock Nut	CH895
6961	BG00605797	Protection Assembly	CH895
6962	452.6103-001	Rubber Protection	CH895
6963	452.6134-001	Bar	CH895
6964	452.6166-001	Rubber Protection	CH895
6965	452.6170-001	Protecting Cover Fzb	CH895
6966	847.0147-00	Washer	CH895
6967	840.0044-00	Screw	CH895
6968	452.6089-901	Lubrication System	CH895
6969	873.0390-00	Seal Ring Tredo	CH895
6970	900.0659-00	Straight Adapter	CH895
6971	452.1587-001	Hose Sae	CH895
6972	452.1580-001	Hose Sae	CH895
6973	452.1538-001	Hose Sae	CH895
6974	452.1591-001	Cover	CH895
6975	845.0213-00	Lock Nut High	CH895
6976	841.0253-00	Screw	CH895
6977	847.0144-00	Washer	CH895
6978	900.2385-00	Flange Half Sae	CH895
6979	873.1299-00	O-Ring	CH895
6980	452.1592-001	Cover	CH895
6981	900.2602-00	Flange Half	CH895
6982	873.0615-00	O-Ring	CH895

6983	452.1589-001	Cover	CH895
6984	900.2592-00	Split Flange Clamp	CH895
6985	845.0030-00	Lock Nut	CH895
6986	847.0147-00	Washer Round	CH895
6987	841.0268-00	Screw	CH895
6988	873.0755-00	O-Ring	CH895
6989	452.1616-901	Return Oil Hose	CH895
6990	452.1536-901	Hose Coupling	CH895
6991	900.2199-00	Split Flange Clamp	CH895
6992	840.0068-00	Screw	CH895
6993	847.0016-00	Washer	CH895
6994	845.0215-00	Lock Nut High	CH895
6995	873.1556-00	O-Ring	CH895
6996	452.1590-001	Cover	CH895
6997	900.0193-00	Hexagon Nipple	CH895
6998	900.2846-00	Socket	CH895
6999	900.2809-00	Hose Coupling	CH895
7000	BG01319144	Hose	CH895
7001	452.3811-901	Air Cleaner	CH895
7002	900.3080-00	Nipple	CH895
7003	900.1722-00	Hose Clip	CH895
7004	BG01018800-01	Overpressure Fan	CH895
7005	BG01018800-02	Overpressure Fan	CH895
7006	BG01018800-03	Overpressure Fan	CH895
7007	BG01018800-04	Overpressure Fan	CH895
7008	BG01018800-05	Overpressure Fan	CH895
7009	BG01018800-06	Overpressure Fan	CH895
7010	BG01018800-07	Overpressure Fan	CH895
7011	452.3811-901	Air Cleaner	CH895
7012	899.0483-00	Mounting Band	CH895
7013	912.0262-00	Air Cleaner Housing, Including Main And Safety	CH895
		Element D178	
7014	912.0363-00	Safety Element And Main Element Kit	CH895
7015	912.0404-00	Main Element	CH895
7016	900.2806-00	Rubber Hump Reducer	CH895
7017	452.3800-901	Reducing Pipe	CH895
7018	912.0261-00	Air Pre-Cleaner	CH895
7019	900.2804-00	Hose Clamp	CH895

7020	900.2807-00	Hose Clamp	CH895
7021	900.2084-00	Hose Clamp	CH895
7022	458.0390-00	Subframe Direct Drive	CH895
7023	873.0718-00	Strip	CH895
7024	847.0142-00	Washer	CH895
7025	845.0274-00	Lock Nut Low	CH895
7026	840.1117-00	Screw	CH895
7027	930.0273-00	Drive Shaft With Safety Coupling	CH895
7028	930.0265-00	Pump	CH895
7029	458.0406-01	Shim	CH895
7030	458.0406-02	Shim	CH895
7031	458.0406-03	Shim	CH895
7032	847.0162-00	Washer	CH895
7033	845.0273-00	Lock Nut Low	CH895
7034	840.0718-00	Screw	CH895
7035	442.9650-92	Vibration Damper	CH895
7036	458.0396-00	Guard	CH895
7037	840.0967-00	Screw	CH895
7038	845.0010-00	Nut	CH895
7039	458.0772-00	Rail For Seal Strip	CH895
7040	BG00616109	Potential Equalization Bar 6 Electrical	CH895
7041	847.0012-00	Washer	CH895
7042	845.0205-00	Lock Nut High	CH895
7043	840.0026-00	Screw	CH895
7044	BG01202081	Speed Sensor Assembly	CH895
7045	847.0136-00	Washer, Lock	CH895
7046	930.0273-00	Drive Shaft With Safety Coupling	CH895
7047	930.0276-00	Coupling Safeset	CH895
7048	930.0277-00	Coupling Holset	CH895
7049	930.0274-00	Shear Tube Safeset	CH895
7050	840.1166-00	Stud Screw	CH895
7051	845.0203-00	Lock Nut	CH895
7052	930.0278-00	Intermediate Shaft	CH895
7053	840.1165-00	Stud Screw	CH895
7054	845.0215-00	Lock Nut	CH895
7055	930.0279-00	Rubber Block Renold	CH895
7056	930.0265-00	Pump	CH895
7057	825.0133-00	Oil Safeset	CH895

7058	452.9650-92	Vibration Damper	CH895
7059	864.0079-00	Damper	CH895
7060	840.1135-00	Screw	CH895
7061	847.0132-00	Washer Round	CH895
7062	442.5904-01	Fixing Plate	CH895
7063	864.0124-00	Damper	CH895
7064	840.0064-00	Screw	CH895
7065	847.0016-00	Washer	CH895
7066	442.9651-01	Mounting Plate	CH895
7067	458.0553-00	Fixing Plate	CH895
7068	458.0554-01	Spacer	CH895
7069	847.0142-00	Washer	CH895
7070	845.0274-00	Lock Nut	CH895
7071	458.0396-00	Guard	CH895
7072	458.0891-001	Plate	CH895
7073	847.0147-00	Washer Round	CH895
7074	840.0044-00	Screw	CH895
7075	845.0030-00	Lock Nut	CH895
7076	458.0396-90	Guard	CH895
7077	BG01202081	Speed Sensor Assembly	CH895
7078	BG01202054	Speed Sensor Support	CH895
7079	847.0012-00	Washer	CH895
7080	840.0021-00	Screw	CH895
7081	BG01198383	Inductive Sensor, Without Counter	CH895
7082	BG01198954	Counter Nut	CH895
7083	BG00487994	Sign	CH895
7084	972.0851-00	Motor	CH895
7085	972.0920-00	Motor	CH895
7086	972.0918-00	Motor	CH895
7087	972.0922-00	Motor	CH895
7088	972.0947-00	Motor	CH895
7089	972.0949-00	Motor	CH895
7090	972.0950-00	Motor	CH895
7091	972.0785-00	Motor	CH895
7092	972.0923-00	Motor	CH895
7093	972.0772-00	Motor	CH895
7094	972.0916-00	Motor	CH895
7095	972.0921-00	Motor	CH895

7096	972.1478-00	Motor	CH895
7097	972.1479-00	Motor	CH895
7098	972.1487-00	Motor	CH895
7099	972.1488-00	Motor	CH895
7100	972.1489-00	Motor	CH895
7101	972.1490-00	Motor	CH895
7102	972.1498-00	Motor Hgf450C 750 Kw 6-Pole 6600 V	CH895
7103	452.6223-901	Tool Kit	CH895
7104	442.9476-00	Tool Box	CH895
7105	BG00227695	Lifting Tool	CH895
7106	BG00227703	Lifting Tool	CH895
7107	BG00235167	Lifting Tool	CH895
7108	452.6180-901	Piston Retainer	CH895
7109	442.7284-90	Lowering Rod	CH895
7110	BG00271537	Lowering Rod	CH895
7111	899.0515-00	Eye Bolt	CH895
7112	920.0110-00	Slugging Wrench	CH895
7113	920.0109-00	Slugging Wrench	CH895
7114	920.0238-00	Slugging Wrench	CH895
7115	920.0243-00	Combination Wrench	CH895
7116	920.0131-00	Combination Wrench	CH895
7117	920.0135-00	Combination Wrench	CH895
7118	920.0134-00	Combination Wrench	CH895
7119	920.0022-00	Combination Wrench	CH895
7120	920.0244-00	Combination Wrench	CH895
7121	920.0245-00	Combination Wrench	CH895
7122	920.0042-00	Allen Key	CH895
7123	920.0040-00	Allen Key	CH895
7124	920.0038-00	Allen Key	CH895
7125	920.0037-00	Allen Key	CH895
7126	920.0035-00	Allen Key	CH895
7127	920.0032-00	Allen Key	CH895
7128	923.0422-00	Feeler Gauge	CH895
7129	452.0452-001	Lifting Tool	CH895
7130	904.0585-00	Microbore Hose	CH895
7131	442.0800-90	Lead Cylinder	CH895
7132	899.0539-00	Eye Bolt	CH895
7133	899.0538-00	Eye Bolt	CH895

7134	899.0536-00	Eye Bolt	CH895
7135	899.0535-00	Eye Bolt	CH895
7136	899.0534-00	Eye Bolt	CH895
7137	899.0533-00	Eye Bolt	CH895
7138	BG00704661	Grease Gauge	CH895
7139	452.4033-901	Wearing Plate As. Kit	CH895
7140	452.1069-901	Wearing Plate	CH895
7141	840.0069-00	Screw	CH895
7142	847.0060-00	Washer	CH895
7143	BG00284338-01	Concave	CH895
7144	BG00284338-05	Concave	CH895
7145	452.1067-001	Concave	CH895
7146	452.1067-005	Concave	CH895
7147	452.0263-001	Concave	CH895
7148	452.0263-005	Concave	CH895
7149	452.0579-001	Concave	CH895
7150	452.0579-005	Concave	CH895
7151	442.9314-01	Mantle	CH895
7152	442.9314-005	Mantle	CH895
7153	442.9339-01	Mantle	CH895
7154	442.9339-005	Mantle	CH895
7155	442.9758-01	Mantle	CH895
7156	442.9758-005	Mantle	CH895
7157	452.0264-001	Mantle	CH895
7158	452.0264-005	Mantle	CH895
7159	452.4051-001	Mantle	CH895
7160	452.4051-005	Mantle	CH895
7161	BG00282784-01	Mantle	CH895
7162	BG00282784-05	Mantle	CH895
7163	BG00601852	Bottom Shell Arm Liner Kit	CH895
7164	452.6071-901	Arm Shield Kit	CH895
7165	452.6068-901	Rim Liner Tertiaty Kit	CH895
7166	BG00598672	Wearing Plate Kit Complete In Bottom	CH895
7167	452.6029-901	Rubber Sheet Kit For Feed Hopper	CH895
7168	452.3688-901	Rubber Sheet Kit For Feed Hopper	CH895
7169	452.2937-901	Distribution Box	CH895
7170	452.4051-001	Mantle	CH895
7171	452.4051-005	Mantle	CH895

7172	452.0264-001	Mantle	CH895
7173	452.0264-005	Mantle	CH895
7174	831.0016-00	Casting Compound,	CH895
7175	452.0579-001	Concave	CH895
7176	452.0579-005	Concave	CH895
7177	452.0263-001	Concave	CH895
7178	452.0263-005	Concave	CH895
7179	452.1067-001	Concave	CH895
7180	452.1067-005	Concave	CH895
7181	831.0016-00	Casting Compound	CH895
7182	873.1232-00	O-Ring For Spider Cap	CH895
7183	452.0418-001	Oil Seal Ring	CH895
7184	442.9270-00	Head Nut / Burning Ring	CH895
7185	442.9306-01	Burning Ring	CH895
7186	442.9266-01	Spider Bushing	CH895
7187	825.0182-00	Grease Tribol Tin	CH895
7188	873.1545-00	O-Ring	CH895
7189	452.2631-901	Step Bearing Set	CH895
7190	442.9294-01	Main Shaft Sleeve	CH895
7191	BG00663893	Dust Seal Ring	CH895
7192	442.9367-01	Retainer	CH895
7193	452.5801-901	Locating Bar Kit	CH895
7194	452.6114-001	Scraper	CH895
7195	BG00733156	Fastener Kit Concave + Support Ring	CH895
7196	BG00206187	Dowel Pin	CH895
7197	912.0155-00	Filter Insert	CH895
7198	912.0363-00	Safety Element And Main Element Kit	CH895
7199	452.0266-001	Spider Cap	CH895
7200	442.9248-01	Bottom Shell Bushing	CH895
7201	442.9357-01	Eccentric Bushing	CH895
7202	442.9358-01	Eccentric Bushing	CH895
7203	442.9359-01	Eccentric Bushing	CH895
7204	442.9360-01	Eccentric Bushing	CH895
7205	442.9249-02	Eccentric Wearing Plate	CH895
7206	442.9256-01	Hydroset Cylinder Bushing	CH895
7207	BG01309093	Pinion Shaft Repair Kit	CH895
7208	442.9807-01	Pinion Shaft	CH895
7209	442.9269-01	Inner Head Nut	CH895

7210	452.6045-001	Dust Seal Retaining Ring	CH895
7211	BG00505358	Main Shaft Assembly Excluding Mantle	CH895
7212	BG00509994	Top Shell Assembly Excluding Concave	CH895
7213	BG01283963	Pinion Shaft Housing Assembly	CH895
7214	902.1189-00	Directional Valve	CH895
7215	984.1678-00	Pressure Transmitter	CH895
7216	902.1201-00	Sealing Kit For Directional Valve	CH895

WWW.ONACASTING.COM