

## VSI Crusher Parts Number

| No | Part Number  | Description                    | Model   |
|----|--------------|--------------------------------|---------|
| 1  | MM0407469    | 690Std Basic Rotor Assembly    | B6150SE |
| 2  | B69274106G/W | 690 Open Sided Rotor Weldment  | B6150SE |
| 3  | B69274008A   | Top Plate                      | B6150SE |
| 4  | B80304013A   | Bolt-In Rotor Boss             | B6150SE |
| 5  | B69274170D   | Lipped Top Wear Plate Set      | B6150SE |
| 6  | B61274180A   | Lipped Bottom Wear Plate Set   | B6150SE |
| 7  | B69274007A   | Taper Lock                     | B6150SE |
| 8  | B691S7040A   | Feed Tube                      | B6150SE |
| 9  | B69274120B   | Distributor Plate              | B6150SE |
| 10 | B69274120C   | Distributor Plate              | B6150SE |
| 11 | 7001530521   | Distributor Bolt               | B6150SE |
| 12 | B69274030E   | Bolt On Feed Eye Ring Kit      | B6150SE |
| 13 | B69274031E   | Bolt-On Standard               | B6150SE |
| 14 | B69274032D   | Feed Eye Ring Bolt Set         | B6150SE |
| 15 | B69274032D/B | Feed Eye Ring Screw            | B6150SE |
| 16 | B96334032D/A | M16 Csk Copper Washer          | B6150SE |
| 17 | B69274135A   | Upper Wear Plate Set           | B6150SE |
| 18 | B69274136A   | Upper Wear Plate - High Chrome | B6150SE |
| 19 | B69274140A   | Lower Wear Plate Set           | B6150SE |
| 20 | B69274141A   | Lower Wear Plate - High Chrome | B6150SE |
| 21 | B69274055A   | Trail Plate Set                | B6150SE |
| 22 | B69274056A   | Trail Plate - Narrow           | B6150SE |
| 23 | B69274055B   | Trail Plate Set                | B6150SE |
| 24 | B69274056B   | Trail Plate - Wide             | B6150SE |
| 25 | B69274055C   | Trail Plate Set                | B6150SE |
| 26 | B69274056C   | Trail Plate - Straight         | B6150SE |
| 27 | B69274255B   | Trail Plate Set                | B6150SE |
| 28 | B69274256C   | Tungsten Trail Plate - Wide    | B6150SE |
| 29 | B69274048A   | Tip Set                        | B6150SE |
| 30 | B69274047A   | Tip - 690                      | B6150SE |
| 31 | B96394052D   | Taper Bolt                     | B6150SE |
| 32 | B96394053A   | Copper Washer                  | B6150SE |
| 33 | B69274048B   | Tip Set                        | B6150SE |
| 34 | B69274047B   | Tip - 690                      | B6150SE |
| 35 | B69274048C   | Tip Set                        | B6150SE |
| 36 | B69274047C   | Tip - 690                      | B6150SE |

|    |              |                                      |         |
|----|--------------|--------------------------------------|---------|
| 37 | B69274048D   | Tip Set                              | B6150SE |
| 38 | B69274047D   | Tip - 690                            | B6150SE |
| 39 | B69274060A   | Backup Tip Set                       | B6150SE |
| 40 | B69274061A   | Backup Tip                           | B6150SE |
| 41 | B96394150L/B | Tip/Cavity Wear Plate Bolt Set       | B6150SE |
| 42 | B69274050E   | Tip / Cavity Wear Plate Set          | B6150SE |
| 43 | B69274051A   | Tip Carrier Wear Plate               | B6150SE |
| 44 | B611S4CB     | Barmac B6150 Se Duopactor            | B6150SE |
| 45 | B6R1S4CB     | B6150Se Crusherassemblies/Drne       | B6150SE |
| 46 | B611S2430C   | El Full Base Liner Kt                | B6150SE |
| 47 | B691S3000BV  | Temperature                          | B6150SE |
| 48 | B90AS60B     | Grease Cartridge-Hightemperature     | B6150SE |
| 49 | B96AC10B     | Hydraulic Handpump Kt                | B6150SE |
| 50 | B96AC20B     | Electric/Hydraulic Power Pack        | B6150SE |
| 51 | B91AC50A     | Acr Kt                               | B6150SE |
| 52 | B96AC20B     | Electric/Hydraulic Power Pack        | B6150SE |
| 53 | B96A110C     | Safety Interlock Kt                  | B6150SE |
| 54 | B91AV20C     | Vsioperational Control System        | B6150SE |
| 55 | B50AP90B     | Vibration Mount Kit                  | B6150SE |
| 56 | B90AS20A     | Rotor Balance Machine-Deep Rotor     | B6150SE |
| 57 | B69AS00A     | Service Tool Kt                      | B6150SE |
| 58 | B91AV60A     | Vocs Strobe                          | B6150SE |
| 59 | B96AV14/100B | Vocs Siren                           | B6150SE |
| 60 | B61AP02D     | Support Frame                        | B6150SE |
| 61 | B96AP15      | Support Legset-Long                  | B6150SE |
| 62 | B96AP10      | Support Leg Set-Short                | B6150SE |
| 63 | B61AP20C     | Skid Frame Kt                        | B6150SE |
| 64 | B91AG00B     | Automatic Lubrication Kt             | B6150SE |
| 65 | B61AS40A     | Service Crane Assembly               | B6150SE |
| 66 | B96AS50A     | Chain Block                          | B6150SE |
| 67 | B71AW00A     | Base Water Spraykt                   | B6150SE |
| 68 | B61AL00C     | Non Stick Liner Kt                   | B6150SE |
| 69 | B611S5470C   | Chamber Gusset Kt                    | B6150SE |
| 70 | B611S1420A   | Transmission Case Assembly           | B6150SE |
| 71 | B611S1421A   | Transmission Case                    | B6150SE |
| 72 | B962S1024C   | Inspection Hole Cover Plate          | B6150SE |
| 73 | B962S1025A   | Inspection Hole Cover Plate Bolt Set | B6150SE |
| 74 | B601S1022A   | Transmission Case Bolt Set           | B6150SE |

|     |            |                                   |         |
|-----|------------|-----------------------------------|---------|
| 75  | B611S1410A | Motor Mount Assembly              | B6150SE |
| 76  | B611S1411A | Motor Mount                       | B6150SE |
| 77  | B611S1412A | Cover Plate                       | B6150SE |
| 78  | B691S1013B | Adjuster Rod Kit                  | B6150SE |
| 79  | B962S1051A | Adjuster Boss                     | B6150SE |
| 80  | B691S1052A | Adjuster Rod                      | B6150SE |
| 81  | B962S1014A | Adjuster Nut                      | B6150SE |
| 82  | B611S1418A | Support Bracket Kit               | B6150SE |
| 83  | B611S1417A | Support Bracket                   | B6150SE |
| 84  | B611S1419A | Tie Back Spacer                   | B6150SE |
| 85  | B962S1015C | Motor Mount Bolt Set              | B6150SE |
| 86  | B611S1430A | Belt Guard Assembly               | B6150SE |
| 87  | B601S1031A | Transmission Belt Guard           | B6150SE |
| 88  | B611S1432B | Transmission Panel                | B6150SE |
| 89  | B702S1035B | Base Belt Guard                   | B6150SE |
| 90  | B712S1434A | Transmission Panel Bolt Set       | B6150SE |
| 91  | B962S1138C | Base Belt Guard Bolt Set          | B6150SE |
| 92  | B712S1433A | Transmission Belt Guard Bolt Set  | B6150SE |
| 93  | B611S2400E | Crusher Base Assembly             | B6150SE |
| 94  | B611S2401E | Crusher Body                      | B6150SE |
| 95  | B601S1036A | Grease Duct                       | B6150SE |
| 96  | B712S1437A | Grease Duct Bolt Set              | B6150SE |
| 97  | B962S2003A | Top Taper Ring                    | B6150SE |
| 98  | B962S2004A | Bottom Taper Ring Outer           | B6150SE |
| 99  | B962S2005A | Bottom Taper Ring Inner           | B6150SE |
| 100 | B812S2010A | Grease Chute                      | B6150SE |
| 101 | B611S5420B | Toe Ring Kit                      | B6150SE |
| 102 | B611S5421B | Toe Ring                          | B6150SE |
| 103 | B611S5403B | Rubber Strip                      | B6150SE |
| 104 | B611S2445A | Vocs Conduit Kit                  | B6150SE |
| 105 | B611S2442A | Vocs Conduit                      | B6150SE |
| 106 | B611S2400E | Crusher Base Assembly (Continued) | B6150SE |
| 107 | B611S5410A | Door Kit                          | B6150SE |
| 108 | B611S5415A | Door Handle Hinge Pin Kit         | B6150SE |
| 109 | B611S5436A | Door Handle Pin                   | B6150SE |
| 110 | B611S5437A | Handle Bush                       | B6150SE |
| 111 | B611S5411B | Door                              | B6150SE |
| 112 | B611S5412A | Door Hinge Frame                  | B6150SE |

|     |              |                                   |         |
|-----|--------------|-----------------------------------|---------|
| 113 | B962S5017A   | Door Spring                       | B6150SE |
| 114 | B913S5416A   | Lock Pin                          | B6150SE |
| 115 | B913S5418A   | Lock Pin Latch Block              | B6150SE |
| 116 | B691S5014C   | Door Frame Hinge Pin Kit          | B6150SE |
| 117 | B691S5020A   | Hinge Pin Long                    | B6150SE |
| 118 | B611S5413A   | Door Handle                       | B6150SE |
| 119 | B913S5445A   | Latch Plate Kit                   | B6150SE |
| 120 | B913S5446A   | Door Handle Latch Plate           | B6150SE |
| 121 | B913S5447A   | Door Handle Shim                  | B6150SE |
| 122 | B962S5002B   | Swing Bolt Kit                    | B6150SE |
| 123 | B962S5027A   | Roof Swing Bolt                   | B6150SE |
| 124 | B962S5026A   | Swing Bolt Nut                    | B6150SE |
| 125 | B962S5028B   | Swing Bolt Pin                    | B6150SE |
| 126 | B611S2400E   | Crusher Base Assembly (Continued) | B6150SE |
| 127 | B913S2470A   | Divider Block Kit                 | B6150SE |
| 128 | B913S2471A   | Divider Block                     | B6150SE |
| 129 | B913S2475A   | Adaptor                           | B6150SE |
| 130 | B913S2472A   | Dowty Seal                        | B6150SE |
| 131 | B913S2473A   | Adaptor                           | B6150SE |
| 132 | B913S2474A   | Adaptor                           | B6150SE |
| 133 | B611S5460C   | Grease Hose Extension Kit         | B6150SE |
| 134 | B611S5461B   | Grease Extension Block            | B6150SE |
| 135 | B611S5462A   | Grease Hose                       | B6150SE |
| 136 | B501S2009A   | Grease Hose                       | B6150SE |
| 137 | B962S2024A   | Bulkhead Fitting                  | B6150SE |
| 138 | B903X2050B   | Vocs Hole Cover Plate Kit         | B6150SE |
| 139 | B903X2051B   | Vocs Hole Cover Plate             | B6150SE |
| 140 | B611S2400E   | Crusher Base Assembly (Continued) | B6150SE |
| 141 | B611S2430B   | Full Base Liner Kit               | B6150SE |
| 142 | B611S2430B/M | Full Base Liner Set               | B6150SE |
| 143 | B611S2431A/L | Base Liner                        | B6150SE |
| 144 | B611S2431A/R | Base Liner                        | B6150SE |
| 145 | B611S2432A   | Base Liner                        | B6150SE |
| 146 | B611S2433A/R | Base Liner                        | B6150SE |
| 147 | B611S2433A/L | Base Liner                        | B6150SE |
| 148 | B691S3000A/V | Shaft Line Assembly - Vocs        | B6150SE |
| 149 | B691S3001A   | Housing                           | B6150SE |
| 150 | B691S3002B   | Main Shaft                        | B6150SE |

|     |              |                                         |         |
|-----|--------------|-----------------------------------------|---------|
| 151 | B962S3004B   | Upper Retaining Ring                    | B6150SE |
| 152 | B962S3006C   | Top Seal Plate                          | B6150SE |
| 153 | B962S3007A   | O-Ring Seal (Shaft)                     | B6150SE |
| 154 | B962S3008C   | O-Ring Seal (Cartridge)                 | B6150SE |
| 155 | B962S3009A   | Inner V-Ring Seal                       | B6150SE |
| 156 | B962S3010A   | Outer V-Ring Seal                       | B6150SE |
| 157 | B962S3011A   | Grease Retaining Ring                   | B6150SE |
| 158 | B962S3012A   | Inner Spacer                            | B6150SE |
| 159 | B962S3013A   | Outer Spacer                            | B6150SE |
| 160 | B962S3015A   | Lower Retaining Ring                    | B6150SE |
| 161 | B962S3016A   | Lower Seal Plate                        | B6150SE |
| 162 | B962S3017A   | Bottom Cover                            | B6150SE |
| 163 | B962S3019A   | Bottom V-Ring Seal                      | B6150SE |
| 164 | B962S3021A   | Locknut                                 | B6150SE |
| 165 | B962S3022A   | Locknut Washer                          | B6150SE |
| 166 | B962S3025A   | Lower Seal Plate Key                    | B6150SE |
| 167 | B691S3003A   | Radial Bearing                          | B6150SE |
| 168 | B691S3060A   | B6900 Mk1 Vocs Plug Kit                 | B6150SE |
| 169 | B691S3026A   | Bottom Key                              | B6150SE |
| 170 | B962S3023B   | Top Key                                 | B6150SE |
| 171 | B962S3005A   | Upper Bearing Retaining Ring Screw      | B6150SE |
| 172 | B962S3014A   | Thrust Bearing                          | B6150SE |
| 173 | B962S3018A   | Lower Retaining Ring Bolt Set           | B6150SE |
| 174 | B962S3050A   | Top Seal Kit                            | B6150SE |
| 175 | B962S3007A   | O-Ring Seal (Shaft)                     | B6150SE |
| 176 | B962S3008C   | O-Ring Seal (Cartridge)                 | B6150SE |
| 177 | B962S3009A   | Inner V-Ring Seal                       | B6150SE |
| 178 | B962S3010A   | Outer V-Ring Seal                       | B6150SE |
| 179 | B962S3008A   | O-Ring Seal (Cartridge)                 | B6150SE |
| 180 | B962S3051A   | Bottom Seal Kit                         | B6150SE |
| 181 | B962S3007A   | O-Ring Seal (Shaft)                     | B6150SE |
| 182 | B962S3019A   | Bottom V-Ring Seal                      | B6150SE |
| 183 | B691S3000A/V | Shaft Line Assembly – Vocs              | B6150SE |
| 184 | B481S3029A   | Decal "Grease Warning"                  | B6150SE |
| 185 | B481S3031A   | Decal "Storage Warning"                 | B6150SE |
| 186 | B963S3032A   | Decal 'Grease Identification' - Castrol | B6150SE |
| 187 | B902S2016B   | Decal "Grease Bearings"                 | B6150SE |
| 188 | B902S2016X   | Grease Selection Decal                  | B6150SE |

|     |              |                                 |         |
|-----|--------------|---------------------------------|---------|
| 189 | B611S6400B   | Cavity Ring Assembly - Standard | B6150SE |
| 190 | B611S6400B/M | Cavity Ring - Standard          | B6150SE |
| 191 | B611SS6403C  | Cavity Ring Bolt Set            | B6150SE |
| 192 | B611S7400B   | Spider Assembly                 | B6150SE |
| 193 | B611S7401B   | Spider Frame                    | B6150SE |
| 194 | B712S7410A   | Spider Packer Kit               | B6150SE |
| 195 | B913S7414A   | Packer 6                        | B6150SE |
| 196 | B913S7413A   | Packer 12                       | B6150SE |
| 197 | B611S7420B   | Feed Kit Holder                 | B6150SE |
| 198 | B611S7430B   | Feed Kit – Standard Style       | B6150SE |
| 199 | B913S7432B   | Feed Tube Location Plate        | B6150SE |
| 200 | B913S7433A   | Feed Clamp Plate                | B6150SE |
| 201 | B913S7434A   | Spring Handle                   | B6150SE |
| 202 | B702S7040A   | Feed Tube                       | B6150SE |
| 203 | B611S7440B   | Wear Skirt Kit                  | B6150SE |
| 204 | B611S7441B   | Wear Skirt                      | B6150SE |
| 205 | B913S7450B   | Wedge Kit                       | B6150SE |
| 206 | B913S7451B   | Wedge                           | B6150SE |
| 207 | B611S9400A   | Hopper Assembly                 | B6150SE |
| 208 | B611S9401A   | Hopper                          | B6150SE |
| 209 | B611S9411A   | Cascade Window Shield           | B6150SE |
| 210 | B712S9420A   | Rubber Skirt Kit                | B6150SE |
| 211 | B812S9421B   | Rubber Skirt - Outer            | B6150SE |
| 212 | B812S9422B   | Rubber Skirt - Inner            | B6150SE |
| 213 | B712S9452B   | Control Plate - 260             | B6150SE |
| 214 | B712S9452C   | Control Plate - 200             | B6150SE |
| 215 | B611S9452D   | Control Plate - 160             | B6150SE |
| 216 | B611S9400A   | Hopper Assembly (Continued)     | B6150SE |
| 217 | B611S9430A   | Hopper Access Guard Kit         | B6150SE |
| 218 | B611S9431A   | Hopper Access Guard             | B6150SE |
| 219 | B611S9440A   | Spreader Plate Kit              | B6150SE |
| 220 | B712S9441A   | Spreader Plate                  | B6150SE |
| 221 | B611S9442A   | Spreader Plate Support          | B6150SE |
| 222 | B913S9443A   | Spreader Plate Spacer           | B6150SE |
| 223 | B611S9450A   | Control Gate Kit                | B6150SE |
| 224 | B611S9451A   | Control Gate                    | B6150SE |
| 225 | B913S9472B   | Clevis Pin                      | B6150SE |
| 226 | B913SH400B   | Hydraulic Ram Kit               | B6150SE |

|     |              |                                   |         |
|-----|--------------|-----------------------------------|---------|
| 227 | B702SH300B/S | Hydraulic Ram                     | B6150SE |
| 228 | B902SH322B   | Port Fitting                      | B6150SE |
| 229 | B913SH401A   | Hydraulic Hose                    | B6150SE |
| 230 | B611S8400C   | Roof Assembly                     | B6150SE |
| 231 | B611S8401C   | B6150 Roof                        | B6150SE |
| 232 | B611S8410B   | Roof Wear Ring Kit                | B6150SE |
| 233 | B611S8411B   | Roof Wear Ring                    | B6150SE |
| 234 | B913S8430B   | Ram Cover Kit                     | B6150SE |
| 235 | B913S8431B   | Ram Cover                         | B6150SE |
| 236 | B611SS1420A  | Transmission Case Assembly        | B6150SE |
| 237 | B902S2018A   | Decal "Warning - Do Not Open"     | B6150SE |
| 238 | B962S1023B   | Decal "Belt Tension"              | B6150SE |
| 239 | B611S2400C   | Crusher Base Assembly (Continued) | B6150SE |
| 240 | B962S5008B   | Decal "Danger - Do Not Open"      | B6150SE |
| 241 | B962S5031B   | Decal "Refit Safety Pin"          | B6150SE |
| 242 | B913S5407A   | Stripe Decal                      | B6150SE |
| 243 | B611S5405C   | Decal "Barmac B6150 Se Vsi"       | B6150SE |
| 244 | B962S2017C   | Lift Decal                        | B6150SE |
| 245 | B712S5406A   | Decal "Metso"                     | B6150SE |
| 246 | B611S8400C   | Roof Assembly (Continued)         | B6150SE |
| 247 | B902S9314A   | Decal "Do Not Clear"              | B6150SE |
| 248 | B913S8402A   | Decal "Replace Guard Warning"     | B6150SE |
| 249 | 1029300198   | Information Plate (Dust Warning)  | B6150SE |
| 250 | B962S8013A   | Decal "Direction Of Rotor"        | B6150SE |
| 251 | B61AD00A     | Decal Set                         | B6150SE |
| 252 | B902S2018A   | Decal 'Warning – Do Not Open'     | B6150SE |
| 253 | B962S1023B   | Decal 'Belt Tension'              | B6150SE |
| 254 | B962S5008B   | Decal 'Danger – Do Not Open'      | B6150SE |
| 255 | B962S5031B   | Decal 'Refit Safety Pin'          | B6150SE |
| 256 | B913S5407A   | Stripe Decal                      | B6150SE |
| 257 | B611S5405C   | Decal "Barmac B6150 Se Vsi"       | B6150SE |
| 258 | B962S2017C   | Lift Decal                        | B6150SE |
| 259 | B712S5406A   | Decal "Metso"                     | B6150SE |
| 260 | B902S9314A   | Decal 'Do Not Clear'              | B6150SE |
| 261 | B913S8402A   | Decal 'Replace Guard Warning'     | B6150SE |
| 262 | 1029300198   | Information Plate (Dust Warning)  | B6150SE |
| 263 | B962S8013A   | Decal "Direction Of Rotor"        | B6150SE |
| 264 | B611S1420A   | Transmission Case Assembly        | B6150SE |

|     |            |                                      |         |
|-----|------------|--------------------------------------|---------|
| 265 | B611S1421A | Transmission Case                    | B6150SE |
| 266 | B962S1024C | Inspection Hole Cover Plate          | B6150SE |
| 267 | B962S1025A | Inspection Hole Cover Plate Bolt Set | B6150SE |
| 268 | WASHER F12 | Washer                               | B6150SE |
| 269 | WASHER S12 | Washer                               | B6150SE |
| 270 | B601S1022A | Transmission Case Bolt Set           | B6150SE |
| 271 | B611S1410A | Motor Mount Assembly                 | B6150SE |
| 272 | B611S1411A | Motor Mount                          | B6150SE |
| 273 | B611S1412A | Cover Plate                          | B6150SE |
| 274 | B691S1013B | Adjuster Rod Kit                     | B6150SE |
| 275 | B962S1051A | Adjuster Boss                        | B6150SE |
| 276 | B691S1052A | Adjuster Rod                         | B6150SE |
| 277 | B962S1014A | Adjuster Nut                         | B6150SE |
| 278 | B611S1418A | Support Bracket Kit                  | B6150SE |
| 279 | B611S1417A | Support Bracket                      | B6150SE |
| 280 | B611S1419A | Tie Back Spacer                      | B6150SE |
| 281 | B962S1015C | Motor Mount Bolt Set                 | B6150SE |
| 282 | B611S1430A | Belt Guard Assembly                  | B6150SE |
| 283 | B601S1031A | Transmission Belt Guard              | B6150SE |
| 284 | B611S1432B | Transmission Panel                   | B6150SE |
| 285 | B702S1035B | Base Belt Guard                      | B6150SE |
| 286 | B712S1434A | Transmission Panel Bolt Set          | B6150SE |
| 287 | B962S1138C | Base Belt Guard Bolt Set             | B6150SE |
| 288 | B712S1433A | Transmission Belt Guard Bolt Set     | B6150SE |
| 289 | B6R1S2400E | Crusher Base Assembly                | B6150SE |
| 290 | B611S2401E | Crusher Body                         | B6150SE |
| 291 | B601S1036A | Grease Duct                          | B6150SE |
| 292 | B712S1437A | Grease Duct Bolt Set                 | B6150SE |
| 293 | B962S2003A | Top Taper Ring                       | B6150SE |
| 294 | B962S2004A | Bottom Taper Ring Outer              | B6150SE |
| 295 | B962S2005A | Bottom Taper Ring Inner              | B6150SE |
| 296 | B812S2010A | Grease Chute                         | B6150SE |
| 297 | B611S5420B | Toe Ring Kit                         | B6150SE |
| 298 | B611S5421B | Toe Ring                             | B6150SE |
| 299 | B611S5403B | Rubber Strip                         | B6150SE |
| 300 | B611S2445A | Vocs Conduit Kit                     | B6150SE |
| 301 | B611S2442A | Vocs Conduit                         | B6150SE |
| 302 | B903X2043A | 20Mm Half Saddle                     | B6150SE |

|     |            |                                   |         |
|-----|------------|-----------------------------------|---------|
| 303 | B962S2013A | Taper Ring Bolt Set               | B6150SE |
| 304 | B611S5480A | Roof Location Lug Kit             | B6150SE |
| 305 | B611S5481A | Roof Location Lug                 | B6150SE |
| 306 | B6R1S2400E | Crusher Base Assembly (Continued) | B6150SE |
| 307 | B611S5410A | Door Kit                          | B6150SE |
| 308 | B611S5415A | Door Handle Hinge Pin Kit         | B6150SE |
| 309 | B611S5436A | Door Handle Pin                   | B6150SE |
| 310 | B611S5437A | Handle Bush                       | B6150SE |
| 311 | B611S5411B | Door                              | B6150SE |
| 312 | B611S5412A | Door Hinge Frame                  | B6150SE |
| 313 | B962S5017A | Door Spring                       | B6150SE |
| 314 | B913S5416A | Lock Pin                          | B6150SE |
| 315 | B913S5418A | Lock Pin Latch Block              | B6150SE |
| 316 | B691S5014C | Door Frame Hinge Pin Kit          | B6150SE |
| 317 | B691S5020A | Hinge Pin Long                    | B6150SE |
| 318 | B611S5413A | Door Handle                       | B6150SE |
| 319 | B913S5445A | Latch Plate Kit                   | B6150SE |
| 320 | B913S5446A | Door Handle Latch Plate           | B6150SE |
| 321 | B913S5447A | Door Handle Shim                  | B6150SE |
| 322 | B962S5002B | Swing Bolt Kit                    | B6150SE |
| 323 | B962S5027A | Roof Swing Bolt                   | B6150SE |
| 324 | B962S5026A | Swing Bolt Nut                    | B6150SE |
| 325 | B962S5028B | Swing Bolt Pin                    | B6150SE |
| 326 | B6R1S2400E | Crusher Base Assembly (Continued) | B6150SE |
| 327 | B913S2470A | Divider Block Kit                 | B6150SE |
| 328 | B913S2471A | Divider Block                     | B6150SE |
| 329 | B913S2475A | Adaptor                           | B6150SE |
| 330 | B913S2472A | Dowty Seal                        | B6150SE |
| 331 | B913S2473A | Adaptor                           | B6150SE |
| 332 | B913S2474A | Adaptor                           | B6150SE |
| 333 | B611S5460C | Grease Hose Extension Kit         | B6150SE |
| 334 | B611S5461B | Grease Extension Block            | B6150SE |
| 335 | BOLT 10*75 | Hex Head Bolt                     | B6150SE |
| 336 | B611S5462A | Grease Extension Hose             | B6150SE |
| 337 | B501S2009A | Grease Hose                       | B6150SE |
| 338 | B962S2024A | Bulkhead Fitting                  | B6150SE |
| 339 | B903X2050B | Vocs Hole Cover Plate Kit         | B6150SE |
| 340 | B903X2051B | Vocs Hole Cover Plate             | B6150SE |

|     |              |                                    |         |
|-----|--------------|------------------------------------|---------|
| 341 | B6R1S2400E   | Crusher Base Assembly (Continued)  | B6150SE |
| 342 | B611S2430B   | Full Base Liner Kit                | B6150SE |
| 343 | B611S2430B/M | Base Liner Set                     | B6150SE |
| 344 | B611S2431A/L | Base Liner                         | B6150SE |
| 345 | B611S2431A/R | Base Liner                         | B6150SE |
| 346 | B611S2432A   | Base Liner                         | B6150SE |
| 347 | B611S2433A/R | Base Liner                         | B6150SE |
| 348 | B611S2433A/L | Base Liner                         | B6150SE |
| 349 | B691S3000A/V | Shaft Line Assembly - Vocs         | B6150SE |
| 350 | B691S3001A   | Housing                            | B6150SE |
| 351 | B691S3002B   | Main Shaft                         | B6150SE |
| 352 | B962S3004B   | Upper Retaining Ring               | B6150SE |
| 353 | B962S3006C   | Top Seal Plate                     | B6150SE |
| 354 | B962S3007A   | O-Ring Seal (Shaft)                | B6150SE |
| 355 | B962S3008C   | O-Ring Seal (Cartridge)            | B6150SE |
| 356 | B962S3009A   | Inner V-Ring Seal                  | B6150SE |
| 357 | B962S3010A   | Outer V-Ring Seal                  | B6150SE |
| 358 | B962S3011A   | Grease Retaining Ring              | B6150SE |
| 359 | B962S3012A   | Inner Spacer                       | B6150SE |
| 360 | B962S3013A   | Outer Spacer                       | B6150SE |
| 361 | B962S3015A   | Lower Retaining Ring               | B6150SE |
| 362 | B962S3016A   | Lower Seal Plate                   | B6150SE |
| 363 | B962S3017A   | Bottom Cover                       | B6150SE |
| 364 | B962S3019A   | Bottom V-Ring Seal                 | B6150SE |
| 365 | B962S3021A   | Locknut                            | B6150SE |
| 366 | B962S3022A   | Locknut Washer                     | B6150SE |
| 367 | B962S3025A   | Lower Seal Plate Key               | B6150SE |
| 368 | B691S3003A   | Radial Bearing                     | B6150SE |
| 369 | B691S3060A   | B6900 Mk I Vocs Plug Kit           | B6150SE |
| 370 | B962S3065B   | B6900 Vocs Rtd Wiring Loom         | B6150SE |
| 371 | B691S3061B   | Washer                             | B6150SE |
| 372 | B691S3026A   | Bottom Key                         | B6150SE |
| 373 | B962S3023B   | Top Key                            | B6150SE |
| 374 | B962S3005A   | Upper Bearing Retaining Ring Screw | B6150SE |
| 375 | B962S3014A   | Thrust Bearing                     | B6150SE |
| 376 | B962S3018A   | Lower Retaining Ring Bolt Set      | B6150SE |
| 377 | B962S3050A   | Top Seal Kit                       | B6150SE |
| 378 | B962S3007A   | O-Ring Seal (Shaft)                | B6150SE |

|     |              |                                         |         |
|-----|--------------|-----------------------------------------|---------|
| 379 | B962S3008C   | O-Ring Seal (Cartridge)                 | B6150SE |
| 380 | B962S3009A   | Inner V-Ring Seal                       | B6150SE |
| 381 | B962S3010A   | Outer V-Ring Seal                       | B6150SE |
| 382 | B962S3008A   | O-Ring Seal (Cartridge)                 | B6150SE |
| 383 | B962S3051A   | Bottom Seal Kit                         | B6150SE |
| 384 | B962S3007A   | O-Ring Seal (Shaft)                     | B6150SE |
| 385 | B962S3019A   | Bottom V-Ring Seal                      | B6150SE |
| 386 | B691S3000A/V | Shaft Line Assembly – Vocs              | B6150SE |
| 387 | B481S3029A   | Decal "Grease Warning"                  | B6150SE |
| 388 | B481S3031A   | Decal "Storage Warning"                 | B6150SE |
| 389 | B963S3032A   | Decal "Grease Identification" - Castrol | B6150SE |
| 390 | B902S2016A   | Decal "Grease Bearings"                 | B6150SE |
| 391 | B902S2016X   | Grease Selection Decal                  | B6150SE |
| 392 | B611S6400B   | Cavity Ring Assembly - Standard         | B6150SE |
| 393 | B611S6400B/M | Cavity Ring - Standard                  | B6150SE |
| 394 | B611SS6403C  | Cavity Ring Bolt Set                    | B6150SE |
| 395 | B611S7400B   | Spider Assembly                         | B6150SE |
| 396 | B611S7401B   | Spider Frame                            | B6150SE |
| 397 | B712S7410A   | Spider Packer Kit                       | B6150SE |
| 398 | B913S7414A   | Packer 6                                | B6150SE |
| 399 | B913S7413A   | Packer 12                               | B6150SE |
| 400 | B611S7420B   | Feed Kit Holder                         | B6150SE |
| 401 | B611S7430B   | Feed Kit – Standard Style               | B6150SE |
| 402 | B913S7432B   | Feed Tube Location Plate                | B6150SE |
| 403 | B913S7433A   | Feed Clamp Plate                        | B6150SE |
| 404 | B913S7434A   | Spring Handle                           | B6150SE |
| 405 | B702S7040A   | Feed Tube                               | B6150SE |
| 406 | B611S7440B   | Wear Skirt Kit                          | B6150SE |
| 407 | B611S7441B   | Wear Skirt                              | B6150SE |
| 408 | B913S7450B   | Wedge Kit                               | B6150SE |
| 409 | B913S7451B   | Wedge                                   | B6150SE |
| 410 | B611S9400A   | Hopper Assembly                         | B6150SE |
| 411 | B611S9401A   | Hopper                                  | B6150SE |
| 412 | B611S9411A   | Cascade Window Shield                   | B6150SE |
| 413 | B712S9420A   | Rubber Skirt Kit                        | B6150SE |
| 414 | B812S9421B   | Rubber Skirt - Outer                    | B6150SE |
| 415 | B812S9422B   | Rubber Skirt - Inner                    | B6150SE |
| 416 | B712S9452B   | Control Plate - 260                     | B6150SE |

|     |              |                                  |         |
|-----|--------------|----------------------------------|---------|
| 417 | B712S9452C   | Control Plate - 200              | B6150SE |
| 418 | B611S9452D   | Control Plate - 160              | B6150SE |
| 419 | B611S9400A   | Hopper Assembly (Continued)      | B6150SE |
| 420 | B611S9430A   | Hopper Access Guard Kit          | B6150SE |
| 421 | B611S9431A   | Hopper Access Guard              | B6150SE |
| 422 | B611S9440A   | Spreader Plate Kit               | B6150SE |
| 423 | B712S9441A   | Spreader Plate                   | B6150SE |
| 424 | B611S9442A   | Spreader Plate Support           | B6150SE |
| 425 | B913S9443A   | Spreader Plate Spacer            | B6150SE |
| 426 | B611S9450A   | Control Gate Kit                 | B6150SE |
| 427 | B611S9451A   | Control Gate                     | B6150SE |
| 428 | B913S9472B   | Clevis Pin                       | B6150SE |
| 429 | B702SH300B/S | Hydraulic Ram                    | B6150SE |
| 430 | B6R1S8400C   | Roof Assembly                    | B6150SE |
| 431 | B6R1S8401C   | B6150 Rl Roof                    | B6150SE |
| 432 | B611S8410B   | Roof Wear Ring Kit               | B6150SE |
| 433 | B611S8411B   | Roof Wear Ring                   | B6150SE |
| 434 | B913S8430B   | Ram Cover Kit                    | B6150SE |
| 435 | B913S8431B   | Ram Cover                        | B6150SE |
| 436 | B9R3S8405A   | Roof Stoper Kit                  | B6150SE |
| 437 | B9R3S8450A   | Hose Clamps                      | B6150SE |
| 438 | B6R1SR400A   | Roof Lifter Assembly             | B6150SE |
| 439 | B6R1SR411A   | Roof Lifter Pillar               | B6150SE |
| 440 | B6R1SR404A   | Roof Lifter Housing              | B6150SE |
| 441 | B6R1SR437A   | Gear Cover Kit                   | B6150SE |
| 442 | B6R1SR434A   | Gear Cover                       | B6150SE |
| 443 | B6R1SR410A   | Pivot Pin Kit                    | B6150SE |
| 444 | B6R1SR413A   | Roof Lifter Pivot Pin            | B6150SE |
| 445 | B6R1SR440A   | Safty Pin Kit                    | B6150SE |
| 446 | B6R1SR441A   | Safety Pin                       | B6150SE |
| 447 | B6R1SR495A   | Chain 6                          | B6150SE |
| 448 | B6R1SR418A   | Rl Housing Bolt Set              | B6150SE |
| 449 | B962S3019A   | Bottom V-Ring Seal               | B6150SE |
| 450 | B9R3SR431A   | Worm Gear                        | B6150SE |
| 451 | B9R3SR433A   | Hexagonal Drive                  | B6150SE |
| 452 | B6R1SR435A   | Ring Gear                        | B6150SE |
| 453 | B6R1SR406A   | Roof Lifter Taper Roller Bearing | B6150SE |
| 454 | B6R1SR402A   | Roof Lifter Top Bush             | B6150SE |

|     |             |                                    |         |
|-----|-------------|------------------------------------|---------|
| 455 | B9R3SR432A  | Drive Shaft                        | B6150SE |
| 456 | B9R3SR414A  | Roof Lifter Spacer                 | B6150SE |
| 457 | B6R1SR436A  | Ring Gear Key                      | B6150SE |
| 458 | B6R1SR400A  | Roof Lifter Assembly (Cont.)       | B6150SE |
| 459 | B6R1SR452A  | 4" Ram                             | B6150SE |
| 460 | B6R1SR455A  | Selector Valve Kit                 | B6150SE |
| 461 | B9R3SR453A  | Selector Valve                     | B6150SE |
| 462 | B9R3SR454A  | Load Hold Valve                    | B6150SE |
| 463 | B6R1SR460A  | Top Pin Kit                        | B6150SE |
| 464 | B6R1SR461A  | Top Ram Pin                        | B6150SE |
| 465 | B6R1SR465A  | Bottom Pin Kit                     | B6150SE |
| 466 | B6R1SR466A  | Bottom Ram Pin                     | B6150SE |
| 467 | B6R1SR451B  | Hose/Fittings Kit                  | B6150SE |
| 468 | B6R1SR451AA | Selector - Hand Pump Hose          | B6150SE |
| 469 | B6R1SR451AB | Ram - Hand Pump Hose               | B6150SE |
| 470 | B6R1SR451AC | Ram - Safety Valve Hose            | B6150SE |
| 471 | B6R1SR451AD | Safety Valve - Selector Valve Hose | B6150SE |
| 472 | B6R1SR451AE | Selector - Cascade Ram Hose        | B6150SE |
| 473 | B6R1SR451AF | Safety Valve - Cascade Ram Hose    | B6150SE |
| 474 | B9R3SR451AG | Nipple                             | B6150SE |
| 475 | B9R3SR451AH | Nipple                             | B6150SE |
| 476 | B9R3SR451AI | Nipple                             | B6150SE |
| 477 | B9R3SR451AJ | Adaptor                            | B6150SE |
| 478 | B9R3SR451AK | Adaptor                            | B6150SE |
| 479 | B9R3SR451BL | Nipple                             | B6150SE |
| 480 | B9R3SR451AM | Dowty Seal                         | B6150SE |
| 481 | B9R3SR451AN | Dowty Seal                         | B6150SE |
| 482 | B611SS1420A | Transmission Case Assembly         | B6150SE |
| 483 | B902S2018A  | Decal "Warning - Do Not Open"      | B6150SE |
| 484 | B962S1023B  | Decal "Belt Tension"               | B6150SE |
| 485 | B6R1S2400C  | Crusher Base Assembly (Continued)  | B6150SE |
| 486 | B962S5008B  | Decal "Danger - Do Not Open"       | B6150SE |
| 487 | B962S5031B  | Decal "Refit Safety Pin"           | B6150SE |
| 488 | B913S5407A  | Stripe Decal                       | B6150SE |
| 489 | B611S5405C  | Decal "Barmac B6150 Se Vsi"        | B6150SE |
| 490 | B962S2017C  | Lift Decal                         | B6150SE |
| 491 | B712S5406A  | Decal "Metso"                      | B6150SE |
| 492 | B6R1S8400C  | Roof Assembly (Continued)          | B6150SE |

|     |              |                                  |         |
|-----|--------------|----------------------------------|---------|
| 493 | B902S9314A   | Decal "Do Not Clear"             | B6150SE |
| 494 | B913S8402A   | Decal "Replace Guard Warning"    | B6150SE |
| 495 | 1029300198   | Information Plate (Dust Warning) | B6150SE |
| 496 | B962S8013A   | Decal "Direction Of Rotor"       | B6150SE |
| 497 | B6R1SR400A   | Roof Lifter Assembly (Continued) | B6150SE |
| 498 | B9R3S425A    | R1 Safety Pin Decal              | B6150SE |
| 499 | B6RAD00A     | Decal Set                        | B6150SE |
| 500 | B902S2018A   | Decal 'Warning – Do Not Open'    | B6150SE |
| 501 | B962S1023B   | Decal 'Belt Tension'             | B6150SE |
| 502 | B962S5008B   | Decal 'Danger – Do Not Open'     | B6150SE |
| 503 | B962S5031B   | Decal 'Refit Safety Pin'         | B6150SE |
| 504 | B913S5407A   | Stripe Decal                     | B6150SE |
| 505 | B611S5405C   | Decal "Barmac B6150 Se Vsi"      | B6150SE |
| 506 | B962S2017C   | Lift Decal                       | B6150SE |
| 507 | B712S5406A   | Decal "Metso"                    | B6150SE |
| 508 | B902S9314A   | Decal 'Do Not Clear'             | B6150SE |
| 509 | B913S8402A   | Decal 'Replace Guard Warning'    | B6150SE |
| 510 | 1029300198   | Information Plate (Dust Warning) | B6150SE |
| 511 | B962S8013A   | Decal "Direction Of Rotor"       | B6150SE |
| 512 | B9R3SR425A   | R1 Safety Pin Decal              | B6150SE |
| 513 | B611S2430C/M | El Full Base Liner Fabrication   | B6150SE |
| 514 | B611S2431C/L | El Base Liner                    | B6150SE |
| 515 | B611S2431C/R | El Base Liner                    | B6150SE |
| 516 | B611S2432A   | El Base Liner                    | B6150SE |
| 517 | B611S2433C/R | El Base Liner                    | B6150SE |
| 518 | B611S2433C/L | El Base Liner                    | B6150SE |
| 519 | B691S3000B/V | Shaft Line Assembly - Vocs       | B6150SE |
| 520 | B691S3001A   | Housing                          | B6150SE |
| 521 | B691S3002B   | Main Shaft                       | B6150SE |
| 522 | B962S3004B   | Upper Retaining Ring             | B6150SE |
| 523 | B962S3006C   | Top Seal Plate                   | B6150SE |
| 524 | B962S3007B   | O-Ring Seal (Shaft)              | B6150SE |
| 525 | B962S3008D   | O-Ring Seal (Cartridge)          | B6150SE |
| 526 | B962S3009B   | Inner V-Ring Seal                | B6150SE |
| 527 | B962S3010B   | Outer V-Ring Seal                | B6150SE |
| 528 | B962S3011A   | Grease Retaining Ring            | B6150SE |
| 529 | B962S3012A   | Inner Spacer                     | B6150SE |
| 530 | B962S3013A   | Outer Spacer                     | B6150SE |

|     |              |                                         |         |
|-----|--------------|-----------------------------------------|---------|
| 531 | B962S3015A   | Lower Retaining Ring                    | B6150SE |
| 532 | B962S3016A   | Lower Seal Plate                        | B6150SE |
| 533 | B962S3017A   | Bottom Cover                            | B6150SE |
| 534 | B962S3019A   | Bottom V-Ring Seal                      | B6150SE |
| 535 | B962S3021A   | Locknut                                 | B6150SE |
| 536 | B962S3022A   | Locknut Washer                          | B6150SE |
| 537 | B962S3025A   | Lower Seal Plate Key                    | B6150SE |
| 538 | B691S3003A   | Radial Bearing                          | B6150SE |
| 539 | B691S3060A   | B6900 Mk I Vocs Plug Kit                | B6150SE |
| 540 | B962S3065B   | B6900 Vocs Rtd Wiring Loom              | B6150SE |
| 541 | B691S3061B   | Dust Cap Washer                         | B6150SE |
| 542 | B691S3026A   | Bottom Key                              | B6150SE |
| 543 | B962S3023B   | Top Key                                 | B6150SE |
| 544 | B962S3005A   | Upper Bearing Retaining Ring Screw      | B6150SE |
| 545 | B962S3014A   | Thrust Bearing                          | B6150SE |
| 546 | B962S3018A   | Lower Retaining Ring Bolt Set           | B6150SE |
| 547 | B962S3050B   | Top Seal Kit                            | B6150SE |
| 548 | B962S3007B   | O-Ring Seal (Shaft)                     | B6150SE |
| 549 | B962S3008D   | O-Ring Seal (Cartridge)                 | B6150SE |
| 550 | B962S3009B   | Inner V-Ring Seal                       | B6150SE |
| 551 | B962S3010B   | Outer V-Ring Seal                       | B6150SE |
| 552 | B962S3008B   | O-Ring Seal (Cartridge)                 | B6150SE |
| 553 | B962S3051B   | Bottom Seal Kit                         | B6150SE |
| 554 | B962S3007B   | O-Ring Seal (Shaft)                     | B6150SE |
| 555 | B962S3019B   | Bottom V-Ring Seal                      | B6150SE |
| 556 | B691S3000B/V | Shaft Line Assembly – Vocs              | B6150SE |
| 557 | B481S3029A   | Decal "Grease Warning"                  | B6150SE |
| 558 | B481S3031A   | Decal "Storage Warning"                 | B6150SE |
| 559 | B963S3032B   | Decal 'Grease Identification' - Shc 220 | B6150SE |
| 560 | B902S2016B   | Decal "Grease Bearings"                 | B6150SE |
| 561 | B902S2016X   | Grease Selection Decal                  | B6150SE |
| 562 | B96AC11B     | Hydraulic Handpump                      | B6150SE |
| 563 | B902SH324B   | Hose Adapter                            | B6150SE |
| 564 | B96AC14B     | Handpump Bolt Set                       | B6150SE |
| 565 | B96AC30A     | Decal “Gate Position”                   | B6150SE |
| 566 | B96AC12B     | Seal Kit                                | B6150SE |
| 567 | B96AC15B     | Handpump Hose                           | B6150SE |
| 568 | B96AC21B     | Hydraulic Pump Unit                     | B6150SE |

|     |             |                                 |         |
|-----|-------------|---------------------------------|---------|
| 569 | B96AC21B/01 | Drive Coupling – Pump End       | B6150SE |
| 570 | B96AC21B/02 | Drive Coupling – Motor End      | B6150SE |
| 571 | B96AC21B/03 | Rubber Spider                   | B6150SE |
| 572 | B96AC21B/04 | Bell Housing                    | B6150SE |
| 573 | B96AC21B/05 | Pump                            | B6150SE |
| 574 | B96AC21A/06 | Directional Valve               | B6150SE |
| 575 | B96AC21A/07 | Rectifier Plug                  | B6150SE |
| 576 | B96AC21B/08 | Filler/Breather                 | B6150SE |
| 577 | B96AC21B/09 | Level Indicator                 | B6150SE |
| 578 | B96AC21B/10 | Reservoir                       | B6150SE |
| 579 | B96AC21B/11 | Relief Valve                    | B6150SE |
| 580 | B96AC21B/12 | Subplate                        | B6150SE |
| 581 | B96AC21B/13 | Directional Valve Bolt Set      | B6150SE |
| 582 | B96AC22A    | Electric Control Unit           | B6150SE |
| 583 | B96AC22A/01 | Transformer                     | B6150SE |
| 584 | B96AC22A/02 | Contactor                       | B6150SE |
| 585 | B96AC22A/03 | Overload                        | B6150SE |
| 586 | B96AC23AB   | Electric Motor                  | B6150SE |
| 587 | B96AC24AB   | Bolt Kit                        | B6150SE |
| 588 | B96AC26A    | Power Pack Hydraulic Hose       | B6150SE |
| 589 | B902SH350B  | Quick Coupler                   | B6150SE |
| 590 | B902SH325A  | Dowty Seat                      | B6150SE |
| 591 | B91AC53A    | Pressure Switch                 | B6150SE |
| 592 | B9R3S471A   | Adaptor                         | B6150SE |
| 593 | B9R3S472A   | Adaptor                         | B6150SE |
| 594 | B91AC51A    | Acr Control Box                 | B6150SE |
| 595 | B91AC57A    | Acr Plc Controller              | B6150SE |
| 596 | B91AC58A    | Acr Plc Snapin Io Module        | B6150SE |
| 597 | B91AV31A/2  | Vocs Power Supply Circuit Board | B6150SE |
| 598 | B91AC55A    | Power Transducer                | B6150SE |
| 599 | B91AC56A    | Current Transformer             | B6150SE |
| 600 | B91AC59A    | Acr Data Export Software        | B6150SE |
| 601 | B96AC21B    | Hydraulic Pump Unit             | B6150SE |
| 602 | B96AC21B/01 | Drive Coupling – Pump End       | B6150SE |
| 603 | B96AC21B/02 | Drive Coupling – Motor End      | B6150SE |
| 604 | B96AC21B/03 | Rubber Spider                   | B6150SE |
| 605 | B96AC21B/04 | Bell Housing                    | B6150SE |
| 606 | B96AC21B/05 | Pump                            | B6150SE |

|     |              |                                         |         |
|-----|--------------|-----------------------------------------|---------|
| 607 | B96AC21A/06  | Directional Valve                       | B6150SE |
| 608 | B96AC21A/07  | Rectifier Plug                          | B6150SE |
| 609 | B96AC21B/08  | Filler/Breather                         | B6150SE |
| 610 | B96AC21B/09  | Level Indicator                         | B6150SE |
| 611 | B96AC21B/10  | Reservoir                               | B6150SE |
| 612 | B96AC21B/11  | Relief Valve                            | B6150SE |
| 613 | B96AC21B/12  | Subplate                                | B6150SE |
| 614 | B96AC21B/13  | Directional Valve Bolt Set              | B6150SE |
| 615 | B96AC22A     | Electric Control Unit                   | B6150SE |
| 616 | B96AC22A/01  | Transformer                             | B6150SE |
| 617 | B96AC22A/02  | Contactor                               | B6150SE |
| 618 | B96AC22A/03  | Overload                                | B6150SE |
| 619 | B96AC23AB    | Electric Motor                          | B6150SE |
| 620 | B96AC24AB    | Bolt Kit                                | B6150SE |
| 621 | B96AC26A     | Power Pack Hydraulic Hose               | B6150SE |
| 622 | B902SH350B   | Quick Coupler                           | B6150SE |
| 623 | B902SH325A   | Dowty Seat                              | B6150SE |
| 624 | B91AC53A     | Pressure Switch                         | B6150SE |
| 625 | B9R3S471A    | Adaptor                                 | B6150SE |
| 626 | B9R3S472A    | Adaptor 90&deg;                         | B6150SE |
| 627 | B96AI11D     | Door Lock, Timer Box & Rotary Switch    | B6150SE |
| 628 | B96AI11B/401 | Key                                     | B6150SE |
| 629 | B96AI11B/402 | Key                                     | B6150SE |
| 630 | B96AI11C/300 | Rotary Switch                           | B6150SE |
| 631 | B96AI11C/400 | Basic Lock With Brass Internals         | B6150SE |
| 632 | B96AI11D/100 | Door Lock                               | B6150SE |
| 633 | B96AI11D/101 | Stainless Steel Self Aligning Bolt      | B6150SE |
| 634 | B96AI11B/102 | Rubber Seal                             | B6150SE |
| 635 | B96AI11B/103 | Stainless Steel Cap                     | B6150SE |
| 636 | B96AI11B/104 | Basic Lock With Stainless Steel         | B6150SE |
| 637 | B96AI11B/105 | Internal Cam                            | B6150SE |
| 638 | B96AI11D/200 | Timer Box                               | B6150SE |
| 639 | B96AI11D/202 | Fuse (5A)                               | B6150SE |
| 640 | B96AI11B/104 | Basic Lock With Stainless Steel         | B6150SE |
| 641 | B96AI11B/103 | Stainless Steel Cap                     | B6150SE |
| 642 | B96AI11B/102 | Rubber Seal To Suit Stainless Steel Cap | B6150SE |
| 643 | B96AI16B     | 4Mm Post Allen Key                      | B6150SE |
| 644 | B91AV21B     | Vocs Controller                         | B6150SE |

|     |            |                                        |         |
|-----|------------|----------------------------------------|---------|
| 645 | B91AV23A   | Vocs Controller Overlay                | B6150SE |
| 646 | B91AV21B/1 | Complete Controller Pcb                | B6150SE |
| 647 | B91AV21A/2 | Key Lock And Key                       | B6150SE |
| 648 | B91AV22B   | Vocs Data Sender                       | B6150SE |
| 649 | B91AV22B/1 | Data Sender Pcb                        | B6150SE |
| 650 | B91AV22A/3 | Vibration Sensor Block                 | B6150SE |
| 651 | B91AV26B   | Vocs Data Sender Bearing Rtd Cable     | B6150SE |
| 652 | B91AV36C   | Vocs Cable 50M                         | B6150SE |
| 653 | B91AV31A   | Vocs Power Supply                      | B6150SE |
| 654 | B91AV80A   | Power Filter                           | B6150SE |
| 655 | B91AV51A   | Vocs Data Logger                       | B6150SE |
| 656 | B91AV36B   | Vocs Cable 100M                        | B6150SE |
| 657 | B91AV52A   | Vocs Data Logger Software              | B6150SE |
| 658 | B50AP91-1  | Antivibration Mount                    | B6150SE |
| 659 | B50AP92B   | Vibration Mount Bolt Set               | B6150SE |
| 660 | B90AP94B   | Information Tag "Remove Bolts"         | B6150SE |
| 661 | B96AS21    | Rotor Balance Side Frame               | B6150SE |
| 662 | B90AS22B   | Rotor Balance End Bracket - Deep Rotor | B6150SE |
| 663 | B90AS24A   | Rotor Balance Shaft - Deep Rotor       | B6150SE |
| 664 | B69AS25    | Rotor Balance Shaft Washer             | B6150SE |
| 665 | B96AS26    | Rotor Balance Bearing                  | B6150SE |
| 666 | B96AS27B   | Rotor Balance Bolt Set                 | B6150SE |
| 667 | B96AS28    | Rotor Balance Taper Adapter            | B6150SE |
| 668 | B96AS29    | Rotor Balance Locknut                  | B6150SE |
| 669 | B69AS13    | Lifting Kit                            | B6150SE |
| 670 | B96AS10B   | Lifting Eye Bolt                       | B6150SE |
| 671 | B69AS12C   | Rotor Lifting Plate                    | B6150SE |
| 672 | B96AS14    | Belt Tensioner                         | B6150SE |
| 673 | B96AS15    | Distributor Bolt Socket                | B6150SE |
| 674 | B96AS16    | Podger Bar                             | B6150SE |
| 675 | B96AS17    | Swing Bolt Spanner                     | B6150SE |
| 676 | B90AS60A   | Grease Cartridge – Normal Temperature  | B6150SE |
| 677 | B90AS60B   | Grease Cartridge – High Temperature    | B6150SE |
| 678 | B61AP02D   | B6150 Support Frame                    | B6150SE |
| 679 | B96AP16    | Support Leg - Long                     | B6150SE |
| 680 | B96AP12    | Leg Bolt Set                           | B6150SE |
| 681 | B96AP11    | Support Leg - Short                    | B6150SE |
| 682 | B96AP12    | Leg Bolt Set                           | B6150SE |

|     |             |                                      |         |
|-----|-------------|--------------------------------------|---------|
| 683 | B61AP20C    | B6150 Skid Frame Kit                 | B6150SE |
| 684 | B61AP21C    | B6150 Skid Frame                     | B6150SE |
| 685 | B61AP22B    | Skid Frame Bolt Set                  | B6150SE |
| 686 | B91AG02B    | Auto-Lube Kit                        | B6150SE |
| 687 | B91AG02B/A  | Piston Pump 24V 2Kg & Timer          | B6150SE |
| 688 | B91AG02B/B  | Cycle Switch                         | B6150SE |
| 689 | B91AG02B/C  | Plug Connector Straight              | B6150SE |
| 690 | B91AG02B/D  | Plastic Tubing                       | B6150SE |
| 691 | B91AG02B/E  | Straight 6Mm 1/8 Bsp Push In Adaptor | B6150SE |
| 692 | B91AG02B/F  | Pump Element                         | B6150SE |
| 693 | B91AG02B/G  | Excess Pressure Valve                | B6150SE |
| 694 | B91AG02B/H  | Pump Electrical Plug & 1M Cable      | B6150SE |
| 695 | B91AG02B/I  | Quick Fill Nipple                    | B6150SE |
| 696 | B91AG02B/J  | Quick Fill Gun                       | B6150SE |
| 697 | B962S2024A  | Bulkhead Fitting                     | B6150SE |
| 698 | B91AG01B    | Finished Cabinet                     | B6150SE |
| 699 | B91AG01B/2  | Electrical Components                | B6150SE |
| 700 | B91AG03B/C1 | Contact Block                        | B6150SE |
| 701 | B91AG03B/H  | Pilot Light Red                      | B6150SE |
| 702 | B91AG03B/F  | Pilot Light Green                    | B6150SE |
| 703 | B91AG03B/L  | Legend Holder 'Reset'                | B6150SE |
| 704 | B91AG03B/J  | Legend Holder 'Run'                  | B6150SE |
| 705 | B91AG03B/K  | Legend Holder Alarm                  | B6150SE |
| 706 | B91AG03B/A  | Terminal 2.5Mm                       | B6150SE |
| 707 | B91AG03B/B1 | Terminal Fused                       | B6150SE |
| 708 | B91AG03B/B2 | Fused Terminal End Cover             | B6150SE |
| 709 | B91AG03B/E  | Terminal End Clamp                   | B6150SE |
| 710 | B91AG03B/D  | Earth Terminal 6Mm                   | B6150SE |
| 711 | B91AG03B/I  | Legend Holder 'Power On'             | B6150SE |
| 712 | B91AG03B/G1 | Rubber Boot                          | B6150SE |
| 713 | B91AG03B/G2 | Illuminated Push Button              | B6150SE |
| 714 | B91AG03B/G3 | Collar And Contact                   | B6150SE |
| 715 | B91AG03B/C2 | Relay Omron                          | B6150SE |
| 716 | B91AG03B/C3 | Relay Socket Omron                   | B6150SE |
| 717 | B91AVNG16A  | Gland 16Mm                           | B6150SE |
| 718 | B91AG04B    | Grease Hose 5M                       | B6150SE |
| 719 | B61AS41A    | Rotor Service Arm Bracket            | B6150SE |
| 720 | B61AS40A    | Crane Mount Bracket Bolt Set         | B6150SE |

|     |              |                                    |         |
|-----|--------------|------------------------------------|---------|
| 721 | B6AAS43A     | Rotor Service Arm                  | B6150SE |
| 722 | B96AS44      | Service Boom Mount Bush            | B6150SE |
| 723 | B96AS45      | Decal "Swl 1 Tonne"                | B6150SE |
| 724 | B90AS19      | Touch-Up Paint Kit                 | B6150SE |
| 725 | B90AS19/A    | Brush                              | B6150SE |
| 726 | B90AS19/B    | Paint                              | B6150SE |
| 727 | B90AS19/C    | Rust Proof Paint                   | B6150SE |
| 728 | B70AW02A     | Base Water Spray Delivery Hose     | B6150SE |
| 729 | B70AW09A     | 15Mm 45° Female Galv. Elbow        | B6150SE |
| 730 | B70AW14A     | 15Mm X 30Mm Galv. Barrel Nipple    | B6150SE |
| 731 | B71AW04A     | Base Water Spray Feed Hose         | B6150SE |
| 732 | B90AW01A     | Base Water Spray Bracket           | B6150SE |
| 733 | B90AW03A     | Pipe Tee                           | B6150SE |
| 734 | B90AW05A     | Long Pipe Bend                     | B6150SE |
| 735 | B90AW06A     | Strainer                           | B6150SE |
| 736 | B90AW07A     | Bonomi Ball Valve                  | B6150SE |
| 737 | B90AW08A     | Bulkhead Fitting                   | B6150SE |
| 738 | B90AW10A     | Fulljet Nozzle                     | B6150SE |
| 739 | B90AW11A     | Adjustable Joint                   | B6150SE |
| 740 | B90AW12A     | Base Water Spray Adaptor           | B6150SE |
| 741 | B90AW13A     | Locknut                            | B6150SE |
| 742 | B61AL02C     | Non Stick Liner Bracket            | B6150SE |
| 743 | B61AL05C     | Non Stick Liners                   | B6150SE |
| 744 | B61AL05C/R   | Non Stick Transmission Liner Right | B6150SE |
| 745 | B61AL05C/L   | Non Stick Transmission Liner Left  | B6150SE |
| 746 | B61AL06C     | Liner Spacer                       | B6150SE |
| 747 | B61AL04A     | Non Stick Liner Stiffener          | B6150SE |
| 748 | B61IS5470C   | Chamber Gusset Kit                 | B6150SE |
| 749 | B61IS5471C   | Chamber Gusset                     | B6150SE |
| 750 | B61IS5472A   | Cavity Ring Door Gusset            | B6150SE |
| 751 | B96334105K   | 840 Open Sided Bare Rotor          | B7150SE |
| 752 | B96334106F/W | 840 Open Sided Rotor Weldment      | B7150SE |
| 753 | B96394007A   | Rotor Taper Lock Mill              | B7150SE |
| 754 | B96394008A   | Top Plate                          | B7150SE |
| 755 | B96394013A   | Bolt-In Rotor Boss                 | B7150SE |
| 756 | B96334105L   | 840 Open Sided Bare Rotor          | B7150SE |
| 757 | B96334106F/W | 840 Open Sided Rotor Weldment      | B7150SE |
| 758 | B96394007B   | Rotor Taper Lock Mkiii             | B7150SE |

|     |            |                             |         |
|-----|------------|-----------------------------|---------|
| 759 | B96394008A | Top Plate                   | B7150SE |
| 760 | B962S7040B | Feed Tube                   | B7150SE |
| 761 | B96394120B | Distributor Plate           | B7150SE |
| 762 | B96394120C | Distributor Plate           | B7150SE |
| 763 | B96394120E | Distributor Plate           | B7150SE |
| 764 | B96394120F | Two Piece Distributor Plate | B7150SE |
| 765 | B96394121F | Two Piece Inner             | B7150SE |
| 766 | B96394122F | Two Piece Outer             | B7150SE |
| 767 | B96394025A | Distributor Bolt            | B7150SE |
| 768 | B96394025B | Distributor Bolt            | B7150SE |
| 769 | B96334030E | Bolt On Feed Eye Ring Kit   | B7150SE |
| 770 | B96334031E | Feed Eye Ring               | B7150SE |
| 771 | B96334135A | Upper Wear Plate Set        | B7150SE |
| 772 | B96334136A | Upper Wear Plate            | B7150SE |
| 773 | B96334140A | Lower Wear Plate Set        | B7150SE |
| 774 | B96334141A | Lower Wear Plate            | B7150SE |
| 775 | B96394055A | Trail Plate Set             | B7150SE |
| 776 | B96394056A | Trail Plate - Narrow        | B7150SE |
| 777 | B96394055E | Trail Plate Set             | B7150SE |
| 778 | B96394056E | Trail Plate                 | B7150SE |
| 779 | B96394055C | Trail Plate Set             | B7150SE |
| 780 | B96394056C | Trail Plate                 | B7150SE |
| 781 | B96394255C | Trail Plate Set             | B7150SE |
| 782 | B96394256C | Tungsten Edge               | B7150SE |
| 783 | B96394055B | Trail Plate Set             | B7150SE |
| 784 | B96394056B | Trail Plate                 | B7150SE |
| 785 | B96394055F | Trail Plate Set             | B7150SE |
| 786 | B96394056F | Trail Plate                 | B7150SE |
| 787 | B96394255B | Trail Plate Set             | B7150SE |
| 788 | B96394256B | Tungsten Edge               | B7150SE |
| 789 | B96394255F | Trail Plate Set             | B7150SE |
| 790 | B96394256F | Tungsten Trail Plate - Wide | B7150SE |
| 791 | B96394048F | Tip Set                     | B7150SE |
| 792 | B96394047F | Tip                         | B7150SE |
| 793 | B96394052D | Taper Bolt                  | B7150SE |
| 794 | B96394053A | Copper Washer               | B7150SE |
| 795 | B96394048H | Tip Set                     | B7150SE |
| 796 | B96394047H | Tip                         | B7150SE |

|     |            |                              |         |
|-----|------------|------------------------------|---------|
| 797 | B96394048J | Tip Set                      | B7150SE |
| 798 | B96394047J | Tip                          | B7150SE |
| 799 | B96394048L | Tip Set                      | B7150SE |
| 800 | B96394047L | Tip                          | B7150SE |
| 801 | B96394048N | Tip Set                      | B7150SE |
| 802 | B96394047N | Tip                          | B7150SE |
| 803 | B96394048P | Tip Set                      | B7150SE |
| 804 | B96394047P | Tip                          | B7150SE |
| 805 | B96394049E | Tip Set                      | B7150SE |
| 806 | B96394047E | Tip                          | B7150SE |
| 807 | B96394049G | Tip Set                      | B7150SE |
| 808 | B96394047G | Tip                          | B7150SE |
| 809 | B96394049I | Tip Set                      | B7150SE |
| 810 | B96394047I | Tip                          | B7150SE |
| 811 | B96394049K | Tip Set                      | B7150SE |
| 812 | B96394047K | Tip                          | B7150SE |
| 813 | B96394049M | Tip Set                      | B7150SE |
| 814 | B96394047M | Tip                          | B7150SE |
| 815 | B96394049O | Tip Set                      | B7150SE |
| 816 | B96394047O | Tip                          | B7150SE |
| 817 | B96394049S | Tip Set                      | B7150SE |
| 818 | B96394047S | Tip                          | B7150SE |
| 819 | B96394049T | Tip Set                      | B7150SE |
| 820 | B96394047T | Tip                          | B7150SE |
| 821 | B96394049Q | Tip Set                      | B7150SE |
| 822 | B96394047Q | Tip                          | B7150SE |
| 823 | B96394048R | Tip Set                      | B7150SE |
| 824 | B96394047R | Tip                          | B7150SE |
| 825 | B96394060B | Backup Tip Set               | B7150SE |
| 826 | B96394061B | Backup Tip                   | B7150SE |
| 827 | B96334170B | Top Wear Plate Set           | B7150SE |
| 828 | B96334171B | Top Wear Plate               | B7150SE |
| 829 | B96394172A | Top Wear Plate Bolt Set      | B7150SE |
| 830 | B96334170C | Lipped Top Wear Plate Set    | B7150SE |
| 831 | B96334171C | Lipped Top Wear Plate        | B7150SE |
| 832 | B96334180A | Lipped Bottom Wear Plate Set | B7150SE |
| 833 | B96334181A | Lipped Bottom Wear Plate     | B7150SE |
| 834 | B96394182A | Bottom Wear Plate Bolt Set   | B7150SE |

|     |              |                                    |         |
|-----|--------------|------------------------------------|---------|
| 835 | B96394150O/B | Cavity Wear Plate Bolt Set         | B7150SE |
| 836 | B96394052E   | Cwp Bolt - 82                      | B7150SE |
| 837 | B96394053A   | Copper Washer                      | B7150SE |
| 838 | B96394175A   | Cavity Bracket Set                 | B7150SE |
| 839 | B96394176A   | Cavity Wear Plate Bracket          | B7150SE |
| 840 | B96394067A   | Cavity Wear Plate Washer           | B7150SE |
| 841 | B96394050E   | Tip / Cavity Wear Plate Set        | B7150SE |
| 842 | B96394051A   | Tip Carrier Wear Plate             | B7150SE |
| 843 | B96394150M   | Tip / Cavity Wear Plate Set        | B7150SE |
| 844 | B96394151M   | Single Reversible                  | B7150SE |
| 845 | B96394050F   | Top Tip / Cavity Wear Plate Set    | B7150SE |
| 846 | B96394051F   | Top Tip Carrier Wear Plate         | B7150SE |
| 847 | B96394050G   | Bottom Tip / Cavity Wear Plate Set | B7150SE |
| 848 | B96394051G   | Bottom Tip Carrier Wear Plate      | B7150SE |
| 849 | B96394150N   | Outer Reversible Tip / Cavity Wear | B7150SE |
| 850 | B96394151N   | Outer Reversible                   | B7150SE |
| 851 | B90334105N   | Deep 840 Open Sided Bare Rotor     | B7150SE |
| 852 | B90334106G/W | Deep 840 Open Sided Rotor Weldment | B7150SE |
| 853 | B96394007B   | Rotor Taper Lock Mkiii             | B7150SE |
| 854 | B96394008A   | Top Plate                          | B7150SE |
| 855 | B90394055B   | Trail Plate Set                    | B7150SE |
| 856 | B90394056B   | Trail Plate - Wide                 | B7150SE |
| 857 | B90394060A   | Short Backup Tip Set               | B7150SE |
| 858 | B96394150N   | Outer Reversible Tip / Cavity Wear | B7150SE |
| 859 | B96394151N   | Outer Reversible                   | B7150SE |
| 860 | B712S4TA     | Barmac Top Half Assembly           | B7150SE |
| 861 | B712S1BA     | Dual Drne Base Assembly            | B7150SE |
| 862 | B96AC10B     | Hydraulic Handpump Kt              | B7150SE |
| 863 | B96A110C     | Safety Interlock Kt                | B7150SE |
| 864 | B90AP90      | Vibration Mount Kit                | B7150SE |
| 865 | B90AS20A     | Rotor Balance Machine-Deep Rotor   | B7150SE |
| 866 | B96AS00A     | Service Tool Kit                   | B7150SE |
| 867 | B712S5400A   | Crusher Chamber Assembly           | B7150SE |
| 868 | B712S5401A   | Crusher Chamber                    | B7150SE |
| 869 | B812S5420A   | Toe Ring Kit                       | B7150SE |
| 870 | B812S5421A   | Toe Ring                           | B7150SE |
| 871 | B812S5403A   | Rubber Strip                       | B7150SE |
| 872 | B712S5410A   | Chamber Bolt Set                   | B7150SE |

|     |              |                                      |         |
|-----|--------------|--------------------------------------|---------|
| 873 | B712S5480A   | Roof Locator Kit                     | B7150SE |
| 874 | B712S5481A   | Roof Locator                         | B7150SE |
| 875 | BOLT 24*80   | Bolt                                 | B7150SE |
| 876 | B712S5400A   | Crusher Chamber Assembly (Continued) | B7150SE |
| 877 | B962S5002B   | Swing Bolt Kit                       | B7150SE |
| 878 | B962S5026A   | Swing Bolt Nut                       | B7150SE |
| 879 | B962S5027A   | Roof Swing Bolt                      | B7150SE |
| 880 | B962S5028B   | Swing Bolt Pin                       | B7150SE |
| 881 | B712S5411B   | Door                                 | B7150SE |
| 882 | B902S5014A   | Door Frame Hinge Pin Kit             | B7150SE |
| 883 | B902S5032B   | Hinge Pin Long                       | B7150SE |
| 884 | B902S5033A   | Hinge Pin Sleeve                     | B7150SE |
| 885 | B913S5413A   | Door Handle                          | B7150SE |
| 886 | B913S5416A   | Lock Pin                             | B7150SE |
| 887 | B962S5017A   | Door Spring                          | B7150SE |
| 888 | B913S5412A   | Door Hinge Frame                     | B7150SE |
| 889 | B913S5445A   | Latch Plate Kit                      | B7150SE |
| 890 | B913S5446A   | Door Handle Latch Plate              | B7150SE |
| 891 | B913S5447A   | Door Handle Shim                     | B7150SE |
| 892 | B913S5415A   | Door Handle Hinge Pin Kit            | B7150SE |
| 893 | B913S5436A   | Door Handle Pin                      | B7150SE |
| 894 | B913S5437A   | Hinge Pin Sleeve                     | B7150SE |
| 895 | B913S5418A   | Lock Pin Latch Block                 | B7150SE |
| 896 | B712S6400C   | Cavity Ring Assembly - Coarse        | B7150SE |
| 897 | B712S6400C/M | Cavity Ring - Coarse                 | B7150SE |
| 898 | B913S6403C   | Cavity Ring Bolt Set                 | B7150SE |
| 899 | B812S7400C   | Spider Assembly                      | B7150SE |
| 900 | B812S7401C   | Spider Frame                         | B7150SE |
| 901 | B812S7420C   | Feed Kit Holder                      | B7150SE |
| 902 | B812S7440C   | Wear Skirt Kit                       | B7150SE |
| 903 | B812S7441C   | Wear Skirt                           | B7150SE |
| 904 | B913S7410A   | Spider Packer Kit                    | B7150SE |
| 905 | B913S7413A   | Packer 12                            | B7150SE |
| 906 | B913S7414A   | Packer 6                             | B7150SE |
| 907 | B913S7430C   | Feed Kit - Standard Style            | B7150SE |
| 908 | B913S7432B   | Feed Tube Location Plate             | B7150SE |
| 909 | B913S7433A   | Feed Clamp Plate                     | B7150SE |
| 910 | B913S7434A   | Spring Handle                        | B7150SE |

|     |              |                                      |         |
|-----|--------------|--------------------------------------|---------|
| 911 | B962S7040B   | Feed Tube                            | B7150SE |
| 912 | B913S7450B   | Wedge Kit                            | B7150SE |
| 913 | B913S7451B   | Wedge                                | B7150SE |
| 914 | B812S9400B   | Hopper Assembly                      | B7150SE |
| 915 | B812S9401B   | Hopper                               | B7150SE |
| 916 | B913S9452C   | Control Plate                        | B7150SE |
| 917 | B913S9452D   | Control Plate                        | B7150SE |
| 918 | B913S9452E   | Control Plate                        | B7150SE |
| 919 | B812S9452F   | Control Plate                        | B7150SE |
| 920 | B812S9411B   | Cascade Window Shield                | B7150SE |
| 921 | B812S9420B   | Rubber Skirt Kit                     | B7150SE |
| 922 | B812S9421B   | Rubber Skirt - Outer                 | B7150SE |
| 923 | B812S9422B   | Rubber Skirt - Inner                 | B7150SE |
| 924 | B812S9400B   | Hopper Assembly (Continued)          | B7150SE |
| 925 | B812S9470B   | Control Gate Kit                     | B7150SE |
| 926 | B812S9471B   | Control Gate                         | B7150SE |
| 927 | B913S9472B   | Clevis Pin                           | B7150SE |
| 928 | B913SH400B   | Hydraulic Ram Kit                    | B7150SE |
| 929 | B702SH300B/S | Hydraulic Ram                        | B7150SE |
| 930 | B902SH322B   | Port Fitting                         | B7150SE |
| 931 | B913SH401A   | Hydraulic Hose                       | B7150SE |
| 932 | B812S9430B   | Hopper Access Guard Kit              | B7150SE |
| 933 | B7M2S9431A   | Hopper Access Guard                  | B7150SE |
| 934 | B913S9440A   | Spreader Plate Kit                   | B7150SE |
| 935 | B913S9441A   | Spreader Plate                       | B7150SE |
| 936 | B913S9442A   | Spreader Plate Support               | B7150SE |
| 937 | B913S9443A   | Spreader Plate Spacer                | B7150SE |
| 938 | B712S8400C   | Roof Assembly                        | B7150SE |
| 939 | B712S8401C   | Roof                                 | B7150SE |
| 940 | B812S8410A   | Roof Wear Ring Kit                   | B7150SE |
| 941 | B812S8411A   | Roof Wear Ring                       | B7150SE |
| 942 | B913S8430B   | Ram Cover Kit                        | B7150SE |
| 943 | B913S8431B   | Ram Cover                            | B7150SE |
| 944 | B712S5400A   | Crusher Chamber Assembly (Continued) | B7150SE |
| 945 | B962S017C    | Lift Decal                           | B7150SE |
| 946 | B913S5406A   | Decal 'Metso'                        | B7150SE |
| 947 | B712S5405D   | Decal 'Barmac B7150 Se Vsi'          | B7150SE |
| 948 | B913S5407A   | Stripe Decal                         | B7150SE |

|     |            |                                      |         |
|-----|------------|--------------------------------------|---------|
| 949 | B962S5008B | Decal 'Danger – Do Not Open'         | B7150SE |
| 950 | B962S5031B | Decal 'Refit Safety Pin'             | B7150SE |
| 951 | B902S2016A | Decal "Grease Bearings"              | B7150SE |
| 952 | B712S8400C | Roof Assembly (Continued)            | B7150SE |
| 953 | B962S8013A | Decal 'Direction Of Rotor'           | B7150SE |
| 954 | B913S8402A | Decal 'Replace Guard Warning'        | B7150SE |
| 955 | B902S9314A | Decal 'Do Not Clear'                 | B7150SE |
| 956 | 1029300198 | Information Plate (Dust Warning)     | B7150SE |
| 957 | B712S1420A | Transmission Case Assembly           | B7150SE |
| 958 | B702S1026A | Transmission End Hatch               | B7150SE |
| 959 | B712S1421A | Transmission Case                    | B7150SE |
| 960 | B712S1422A | Transmission Case Bolt Set           | B7150SE |
| 961 | B962S1024C | Inspection Hole Cover Plate          | B7150SE |
| 962 | B962S1025A | Inspection Hole Cover Plate Bolt Set | B7150SE |
| 963 | B962S1027A | Transmission End Hatch Bolt Set      | B7150SE |
| 964 | B962S1010D | Motor Mount Assembly                 | B7150SE |
| 965 | B962S1015C | Motor Mount Bolt Set                 | B7150SE |
| 966 | B691S1013B | Adjuster Rod Kit                     | B7150SE |
| 967 | B691S1052A | Adjuster Rod                         | B7150SE |
| 968 | B962S1014A | Adjuster Nut                         | B7150SE |
| 969 | B962S1051A | Adjuster Boss                        | B7150SE |
| 970 | B962S1011C | Motor Mount                          | B7150SE |
| 971 | B962S1012A | Cover Plate                          | B7150SE |
| 972 | B962S1018A | Support Bracket Kit                  | B7150SE |
| 973 | B962S1017A | Support Bracket                      | B7150SE |
| 974 | B962S1019A | Tie Back Spacer                      | B7150SE |
| 975 | B963X1130B | Belt Guard Assembly – Dual Drive     | B7150SE |
| 976 | B963X1033B | Guard Bolt Set                       | B7150SE |
| 977 | B963X1031B | Transmission Belt Guard              | B7150SE |
| 978 | B963X1035C | Base Belt Guard                      | B7150SE |
| 979 | B712S2400E | Crusher Base Assembly                | B7150SE |
| 980 | B712S2401E | Crusher Base                         | B7150SE |
| 981 | B963X2022B | Gusset Wear Casting                  | B7150SE |
| 982 | B962S2003A | Top Taper Ring                       | B7150SE |
| 983 | B962S2004A | Bottom Taper Ring Outer              | B7150SE |
| 984 | B962S2005A | Bottom Taper Ring Inner              | B7150SE |
| 985 | B962S2013A | Taper Ring Bolt Set                  | B7150SE |
| 986 | B963X2025A | Gusset Casting Bolt Set              | B7150SE |

|      |              |                                   |         |
|------|--------------|-----------------------------------|---------|
| 987  | B903X2045A   | Vocs Ducting Kit                  | B7150SE |
| 988  | B903X2042A   | Vocs Conduit                      | B7150SE |
| 989  | B903X2043A   | 20Mm Half Saddle                  | B7150SE |
| 990  | B812S2010A   | Grease Chute                      | B7150SE |
| 991  | B702S1036A   | Grease Duct                       | B7150SE |
| 992  | B963X1137A   | Grease Duct Bolt Set              | B7150SE |
| 993  | B712S2400E   | Crusher Base Assembly (Continued) | B7150SE |
| 994  | B611S5460B   | Grease Hose Extension Kit         | B7150SE |
| 995  | B611S5461B   | Grease Extension Block            | B7150SE |
| 996  | B913S5462A   | Grease Extension Hose             | B7150SE |
| 997  | B903X2050B   | Vocs Hole Plate Kit               | B7150SE |
| 998  | B903X2051B   | Vocs Hole Cover Plate             | B7150SE |
| 999  | B962S2024A   | Bulkhead Fitting                  | B7150SE |
| 1000 | B913S2470A   | Divider Block Kit                 | B7150SE |
| 1001 | B913S2471A   | Divider Block                     | B7150SE |
| 1002 | B913S2475A   | Adaptor                           | B7150SE |
| 1003 | B913S2472A   | Dowty Seal 1/4 Bsp M              | B7150SE |
| 1004 | B913S2473A   | Adaptor                           | B7150SE |
| 1005 | B913S2474A   | Adaptor                           | B7150SE |
| 1006 | B501S2009A   | Grease Hose                       | B7150SE |
| 1007 | B712S2400E   | Crusher Base Assembly (Continued) | B7150SE |
| 1008 | B712S2430E   | Full Base Liner Kit               | B7150SE |
| 1009 | B712S2430E/M | Full Base Liner Fabrication       | B7150SE |
| 1010 | B712S2431A/L | Base Liner                        | B7150SE |
| 1011 | B712S2431A/R | Base Liner                        | B7150SE |
| 1012 | B712S2432A   | Base Liner                        | B7150SE |
| 1013 | B712S2435A/L | Base Liner                        | B7150SE |
| 1014 | B712S2435A/R | Base Liner                        | B7150SE |
| 1015 | B712S2436A/L | Base Liner                        | B7150SE |
| 1016 | B712S2436A/R | Base Liner                        | B7150SE |
| 1017 | B802S3000A/V | Shaft Line Assembly - Vocs        | B7150SE |
| 1018 | B802S3001A   | Housing                           | B7150SE |
| 1019 | B802S3002C   | Main Shaft                        | B7150SE |
| 1020 | B962S3003A   | Radial Bearing                    | B7150SE |
| 1021 | B962S3004B   | Upper Retaining Ring              | B7150SE |
| 1022 | B962S3005A   | Upper Retaining Ring Screw Set    | B7150SE |
| 1023 | B962S3006C   | Top Seal Plate                    | B7150SE |
| 1024 | B962S3007A   | O-Ring Seal (Shaft)               | B7150SE |

|      |              |                                         |         |
|------|--------------|-----------------------------------------|---------|
| 1025 | B962S3008C   | O-Ring Seal (Cartridge)                 | B7150SE |
| 1026 | B962S3009A   | Inner V-Ring Seal                       | B7150SE |
| 1027 | B962S3010A   | Outer V-Ring Seal                       | B7150SE |
| 1028 | B962S3011A   | Grease Retaining Ring                   | B7150SE |
| 1029 | B962S3012A   | Inner Spacer                            | B7150SE |
| 1030 | B962S3013A   | Outer Spacer                            | B7150SE |
| 1031 | B962S3014A   | Thrust Bearing                          | B7150SE |
| 1032 | B962S3015A   | Lower Retaining Ring                    | B7150SE |
| 1033 | B962S3016A   | Lower Seal Plate                        | B7150SE |
| 1034 | B962S3017A   | Bottom Cover                            | B7150SE |
| 1035 | B962S3018A   | Lower Retaining Ring Bolt Set           | B7150SE |
| 1036 | B962S3019A   | Bottom V-Ring Seal                      | B7150SE |
| 1037 | B962S3021A   | Locknut                                 | B7150SE |
| 1038 | B962S3022A   | Locknut Washer                          | B7150SE |
| 1039 | B962S3023B   | Top Key                                 | B7150SE |
| 1040 | B962S3025A   | Lower Seal Plate Key                    | B7150SE |
| 1041 | B962S3026A   | Bottom Key                              | B7150SE |
| 1042 | B962S3060B   | B7000 Mk Ii Vocs Plug Kit               | B7150SE |
| 1043 | B962S3065B   | Vocs Mk Ii M12 Plug Cover               | B7150SE |
| 1044 | B802S3061B   | B7000 Vocs Rtd Wiring Loom              | B7150SE |
| 1045 | B962S3050A   | Top Seal Kit                            | B7150SE |
| 1046 | B962S3007A   | O-Ring Seal (Shaft)                     | B7150SE |
| 1047 | B962S3008C   | O-Ring Seal (Cartridge)                 | B7150SE |
| 1048 | B962S3009A   | Inner V-Ring Seal                       | B7150SE |
| 1049 | B962S3010A   | Outer V-Ring Seal                       | B7150SE |
| 1050 | B962S3008A   | O-Ring Seal (Cartridge)                 | B7150SE |
| 1051 | B962S3051A   | Bottom Seal Kit                         | B7150SE |
| 1052 | B962S3007A   | O-Ring Seal (Shaft)                     | B7150SE |
| 1053 | B962S3019A   | Bottom V-Ring Seal                      | B7150SE |
| 1054 | B802S3000A/V | Shaft Line Assembly – Vocs              | B7150SE |
| 1055 | B902S2016B   | Decal 'Grease Bearings'                 | B7150SE |
| 1056 | B902S2016X   | Grease Selection Decal                  | B7150SE |
| 1057 | B962S3029A   | Decal 'Grease Warning'                  | B7150SE |
| 1058 | B962S3031A   | Decal 'Storage Warning'                 | B7150SE |
| 1059 | B963S3032A   | Decal 'Grease Identification' - Castrol | B7150SE |
| 1060 | B712S2400D   | Crusher Base Assembly (Continued)       | B7150SE |
| 1061 | B962S2017C   | Lift Decal                              | B7150SE |
| 1062 | B712S1420A   | Transmission Case Assembly              | B7150SE |

|      |              |                                         |         |
|------|--------------|-----------------------------------------|---------|
| 1063 | B962S1023B   | Decal "Belt Tension"                    | B7150SE |
| 1064 | B902S2018A   | Decal "Warning - Do Not Open"           | B7150SE |
| 1065 | B71AD00C     | Decal Set                               | B7150SE |
| 1066 | B962S017C    | Lift Decal                              | B7150SE |
| 1067 | B962S1016A   | Decal 'Belt Tension'                    | B7150SE |
| 1068 | B902S2018A   | Decal 'Warning – Do Not Open'           | B7150SE |
| 1069 | B96AC11B     | Hydraulic Handpump                      | B7150SE |
| 1070 | B902SH324B   | Hose Adapter                            | B7150SE |
| 1071 | B96AC14B     | Handpump Bolt Set                       | B7150SE |
| 1072 | B96AC30A     | Decal "Gate Position"                   | B7150SE |
| 1073 | B96AC12B     | Seal Kit                                | B7150SE |
| 1074 | B96AC15B     | Handpump Hose                           | B7150SE |
| 1075 | B96AI11D     | Door Lock, Timer Box & Rotary Switch    | B7150SE |
| 1076 | B96AI11B/401 | Key                                     | B7150SE |
| 1077 | B96AI11B/402 | Key                                     | B7150SE |
| 1078 | B96AI11C/300 | Rotary Switch                           | B7150SE |
| 1079 | B96AI11C/400 | Basic Lock With Brass Internals         | B7150SE |
| 1080 | B96AI11D/100 | Door Lock                               | B7150SE |
| 1081 | B96AI11D/101 | Stainless Steel Self Aligning Bolt      | B7150SE |
| 1082 | B96AI11B/102 | Rubber Seal To Suit Stainless Steel Cap | B7150SE |
| 1083 | B96AI11B/103 | Stainless Steel Cap                     | B7150SE |
| 1084 | B96AI11B/104 | Basic Lock With Stainless Steel         | B7150SE |
| 1085 | B96AI11B/105 | Internal Cam To Suit H31Cn/Le           | B7150SE |
| 1086 | B96AI11D/200 | Timer Box (H31Et1P55) – Complete        | B7150SE |
| 1087 | B96AI11D/202 | Fuse (5A)                               | B7150SE |
| 1088 | B96AI11B/104 | Basic Lock With Stainless Steel         | B7150SE |
| 1089 | B96AI11B/103 | Stainless Steel Cap (Including Spring   | B7150SE |
| 1090 | B96AI11B/102 | Rubber Seal To Suit Stainless Steel Cap | B7150SE |
| 1091 | B96AI16B     | 4Mm Post Allen Key                      | B7150SE |
| 1092 | B90AP91      | Antivibration Mount                     | B7150SE |
| 1093 | B90AP92      | Antivibration Mount Bolt Set            | B7150SE |
| 1094 | B90AP94      | Decal "Loosen Transport Bolts"          | B7150SE |
| 1095 | B96AS21      | Rotor Balance Side Frame                | B7150SE |
| 1096 | B90AS22B     | Rotor Balance End Bracket - Deep Rotor  | B7150SE |
| 1097 | B90AS24A     | Rotor Balance Shaft - Deep Rotor        | B7150SE |
| 1098 | B69AS25      | Rotor Balance Shaft Washer              | B7150SE |
| 1099 | B96AS26      | Rotor Balance Bearing                   | B7150SE |
| 1100 | B96AS27B     | Rotor Balance Bolt Set                  | B7150SE |

|      |              |                                       |         |
|------|--------------|---------------------------------------|---------|
| 1101 | B96AS28      | Rotor Balance Taper Adapter           | B7150SE |
| 1102 | B96AS29      | Rotor Balance Locknut                 | B7150SE |
| 1103 | B96AS13      | Lifting Kit                           | B7150SE |
| 1104 | B96AS10B     | Lifting Eye Bolt                      | B7150SE |
| 1105 | B96AS12C     | Rotor Lifting Plate                   | B7150SE |
| 1106 | B96AS14      | Belt Tensioner                        | B7150SE |
| 1107 | B96AS15      | Distributor Bolt Socket               | B7150SE |
| 1108 | B96AS16      | Podger Bar                            | B7150SE |
| 1109 | B96AS17      | Swing Bolt Spanner                    | B7150SE |
| 1110 | B90AS60A     | Grease Cartridge – Normal Temperature | B7150SE |
| 1111 | B90AS60B     | Grease Cartridge - High Temperature   | B7150SE |
| 1112 | MM0407480    | RC840 Basic Rotor Assembly            | B7150SE |
| 1113 | MM0400931    | RC840 Deep Rotor Weldment             | B7150SE |
| 1114 | B96394008A   | Top Plate                             | B7150SE |
| 1115 | B96394009B   | Top Plate Bolt Set                    | B7150SE |
| 1116 | B96394013A   | Bolt-In Rotor Boss                    | B7150SE |
| 1117 | B96394015A   | Rotor Boss Bolt Set                   | B7150SE |
| 1118 | B96334170C   | Lipped Top Wear Plate Set             | B7150SE |
| 1119 | B96334180A   | Lipped Bottom Wear Plate              | B7150SE |
| 1120 | MM1074295    | Top Wear Plate Set                    | B7150SE |
| 1121 | MM1074292    | Bottom Wear Plate Set                 | B7150SE |
| 1122 | 00920314358S | Wear Plate Retaining Screw            | B7150SE |
| 1123 | MM0401058    | Wear Plate Keeper Set                 | B7150SE |
| 1124 | MM0401053    | Upper Cam Lock Set                    | B7150SE |
| 1125 | MM0401056    | Lower Cam Lock Set                    | B7150SE |
| 1126 | B96394007A   | Mkii Taper Lock                       | B7150SE |
| 1127 | B96394007B   | Mkiii Taper Lock                      | B7150SE |
| 1128 | B962S7040B   | Feed Tube                             | B7150SE |
| 1129 | B96394120B   | Distributor Plate                     | B7150SE |
| 1130 | B96394120C   | Distributor Plate                     | B7150SE |
| 1131 | B96394120E   | Distributor Plate                     | B7150SE |
| 1132 | B96394120F   | Distributor Plate                     | B7150SE |
| 1133 | B96394121F   | Two Piece Inner                       | B7150SE |
| 1134 | B96394122F   | Two Piece Outer                       | B7150SE |
| 1135 | 7001530521   | Distributor Bolt                      | B7150SE |
| 1136 | MM0401051    | Upper Wear Plate Set                  | B7150SE |
| 1137 | MM0401087    | Upper Wear Plate                      | B7150SE |
| 1138 | MM0401052    | Lower Wear Plate Set                  | B7150SE |

|      |              |                                  |         |
|------|--------------|----------------------------------|---------|
| 1139 | MM0401088    | Lower Wear Plate                 | B7150SE |
| 1140 | MM1373583    | Tip Set                          | B7150SE |
| 1141 | MM1373588    | Tip                              | B7150SE |
| 1142 | MM1424007    | Tip Set                          | B7150SE |
| 1143 | MM1424008    | Tip                              | B7150SE |
| 1144 | MM1374009    | Tip Set                          | B7150SE |
| 1145 | MM1374010    | Tip                              | B7150SE |
| 1146 | MM1423069    | Tip Set                          | B7150SE |
| 1147 | MM1423072    | Tip                              | B7150SE |
| 1148 | MM1424026    | Tip Set                          | B7150SE |
| 1149 | MM1424027    | Tip                              | B7150SE |
| 1150 | MM1423814    | Tip Set                          | B7150SE |
| 1151 | MM14238810   | Tip                              | B7150SE |
| 1152 | MM1422526    | Backup Tip Set                   | B7150SE |
| 1153 | MM1422527    | Backup Tip                       | B7150SE |
| 1154 | MM1133905    | Trail Plate Set                  | B7150SE |
| 1155 | MM1133898    | Trail Plate - Narrow             | B7150SE |
| 1156 | MM1133902    | Trail Plate Set                  | B7150SE |
| 1157 | MM1133891    | Trail Plate                      | B7150SE |
| 1158 | MM1135561    | Trail Plate Set                  | B7150SE |
| 1159 | MM1135478    | Tungsten Trail Plate             | B7150SE |
| 1160 | MM0401067    | Retaining Bar                    | B7150SE |
| 1161 | MM0401067    | Reversible Cavity Wear Plate     | B7150SE |
| 1162 | MM0401066    | Reversible Cavity Wear Plate Set | B7150SE |
| 1163 | MM0401086    | Cavity Wear Plate X 3            | B7150SE |
| 1164 | MM1115360    | Crusher Body                     | B7150SE |
| 1165 | MM1066892    | Base Assembly                    | B7150SE |
| 1166 | MM1066966    | Motor Control Racks              | B7150SE |
| 1167 | B712S2430E   | Protection Plate Assembly        | B7150SE |
| 1168 | B802S3000A/V | Main Shaft Assembly              | B7150SE |
| 1169 | MM1103775    | Cavity Ring Assembly             | B7150SE |
| 1170 | MM1115361    | Crusher Components               | B7150SE |
| 1171 | MM5000330    | Upper Wear Ring                  | B7150SE |
| 1172 | B7R2S9400A   | Feed Hopper                      | B7150SE |
| 1173 | MM1101524    | Chamber                          | B7150SE |
| 1174 | B812S7401C   | Coupling Buffer Blocks           | B7150SE |
| 1175 | B812S7420C   | Supports                         | B7150SE |
| 1176 | B913S7430D   | Feeder Assembly                  | B7150SE |

|      |              |                                    |         |
|------|--------------|------------------------------------|---------|
| 1177 | B913S7451B   | Wedges                             | B7150SE |
| 1178 | MM5000304    | Upper Wear Ring                    | B7150SE |
| 1179 | B812S9401B   | Feed Hopper                        | B7150SE |
| 1180 | B702SH300B/S | Hydraulic Cylinders                | B7150SE |
| 1181 | B812S9420B   | Rubber Assembly                    | B7150SE |
| 1182 | B812S9470B   | Door Assembly                      | B7150SE |
| 1183 | B812S9430B   | Arm Guard                          | B7150SE |
| 1184 | B712S2401H   | Crusher Foundation                 | B7150SE |
| 1185 | B712S1420B   | Cabinet                            | B7150SE |
| 1186 | B962S1010D   | Electric Motor Bracket Assembly    | B7150SE |
| 1187 | MM1117836    | Engine Bracket                     | B7150SE |
| 1188 | B712S2430E/M | Abrasion Resistant Discs           | B7150SE |
| 1189 | B712S2435A/L | Protection Plate                   | B7150SE |
| 1190 | B712S2431A/L | Protection Plate                   | B7150SE |
| 1191 | B712S2431A/R | Protection Plate                   | B7150SE |
| 1192 | B712S2436A/R | Protection Plate                   | B7150SE |
| 1193 | B712S2436A/L | Protection Plate                   | B7150SE |
| 1194 | B712S2435A/R | Protection Plate                   | B7150SE |
| 1195 | B712S2432A   | Protection Plate                   | B7150SE |
| 1196 | B802S3001A   | Bearing Housing                    | B7150SE |
| 1197 | B802S3002C   | Main Shaft                         | B7150SE |
| 1198 | MM0308785    | Bearing                            | B7150SE |
| 1199 | N11484540    | 990Dtr Rotor Assembly              | B9100SE |
| 1200 | MM0407477    | 990Dtr Basic Rotor Assembly        | B9100SE |
| 1201 | B90394106G/W | Deep 990 Open Sided Rotor Weldment | B9100SE |
| 1202 | B96394008A   | Top Plate                          | B9100SE |
| 1203 | B96394013A   | Bolt-In Rotor Boss                 | B9100SE |
| 1204 | B96394170C   | Lipped Top Wear Plate Set          | B9100SE |
| 1205 | B96394180A   | Lipped Bottom Wear Plate Set       | B9100SE |
| 1206 | B96394007B   | Taper Lock                         | B9100SE |
| 1207 | B962S7040B   | Feed Tube                          | B9100SE |
| 1208 | B96394120B   | Distributor Plate                  | B9100SE |
| 1209 | B96394120C   | Distributor Plate                  | B9100SE |
| 1210 | B96394120E   | Distributor Plate                  | B9100SE |
| 1211 | B96394120F   | Two Piece Distributor Plate        | B9100SE |
| 1212 | B96394121F   | Two Piece Inner                    | B9100SE |
| 1213 | B96394122F   | Two Piece Outer                    | B9100SE |
| 1214 | 7001530521   | Distributor Bolt                   | B9100SE |

|      |              |                                  |         |
|------|--------------|----------------------------------|---------|
| 1215 | B96394030E   | Bolt On Feed Eye Ring Kit        | B9100SE |
| 1216 | B96394031E   | Feed Eye Ring - Bolt-On Standard | B9100SE |
| 1217 | B96334032D   | Feed Eye Ring Bolt Set           | B9100SE |
| 1218 | B96334032D/A | M16 Csk Copper Washer            | B9100SE |
| 1219 | B96394135A   | Upper Wear Plate Set             | B9100SE |
| 1220 | B96394136A   | Upper Wear Plate                 | B9100SE |
| 1221 | B96394140A   | Lower Wear Plate Set             | B9100SE |
| 1222 | B96394141A   | Lower Wear Plate                 | B9100SE |
| 1223 | B90394055A   | Trail Plate Set                  | B9100SE |
| 1224 | B90394056A   | Trail Plate - Narrow             | B9100SE |
| 1225 | B90394055B   | Trail Plate Set                  | B9100SE |
| 1226 | B90394056B   | Trail Plate - Wide               | B9100SE |
| 1227 | B90394255B   | Trail Plate Set                  | B9100SE |
| 1228 | B90394256B   | Tungsten Trail Plate             | B9100SE |
| 1229 | B96394049E   | Tip Set                          | B9100SE |
| 1230 | B96394047E   | Tip                              | B9100SE |
| 1231 | B96394052D   | Taper Bolt 74                    | B9100SE |
| 1232 | B96394053A   | Copper Washer                    | B9100SE |
| 1233 | B96394049G   | Tip Set                          | B9100SE |
| 1234 | B96394047G   | Tip                              | B9100SE |
| 1235 | B96394049I   | Tip Set                          | B9100SE |
| 1236 | B96394047I   | Tip                              | B9100SE |
| 1237 | B96394049K   | Tip Set                          | B9100SE |
| 1238 | B96394047K   | Tip                              | B9100SE |
| 1239 | B96394049M   | Tip Set                          | B9100SE |
| 1240 | B96394047M   | Tip                              | B9100SE |
| 1241 | B96394049O   | Tip Set                          | B9100SE |
| 1242 | B96394047O   | Tip                              | B9100SE |
| 1243 | B96394049Q   | Tip Set                          | B9100SE |
| 1244 | B96394047Q   | Tip                              | B9100SE |
| 1245 | B96394060B   | Backup Tip Set                   | B9100SE |
| 1246 | B96394061B   | Backup Tip                       | B9100SE |
| 1247 | B90394060A   | Short Backup Tip Set             | B9100SE |
| 1248 | B90394061A   | Short Backup Tip                 | B9100SE |
| 1249 | B96394150O/B | Cavity Wear Plate Bolt Set       | B9100SE |
| 1250 | B96394052E   | Cwp Bolt                         | B9100SE |
| 1251 | B96394053A   | Copper Washer                    | B9100SE |
| 1252 | B96394150N   | Outer Reversible Tip             | B9100SE |

|      |            |                                    |         |
|------|------------|------------------------------------|---------|
| 1253 | B96394151N | Outer Reversible                   | B9100SE |
| 1254 | B96394150O | Middle Reversible Tip              | B9100SE |
| 1255 | B96394151O | Middle Reversible                  | B9100SE |
| 1256 | B9R3S4TC   | B9100Se Crusher Top Half Assembly  | B9100SE |
| 1257 | B913S1BA   | B9100Se Crusher Bottom Half        | B9100SE |
| 1258 | B96AC10B   | Hydraulic Handpump Kit             | B9100SE |
| 1259 | B96AI10C   | Safety Interlock Kit               | B9100SE |
| 1260 | B91AV20C   | Vsi Operational Control System     | B9100SE |
| 1261 | B90AP90    | Vibration Mount Kit                | B9100SE |
| 1262 | B90AS20A   | Rotor Balance Machine - Deep Rotor | B9100SE |
| 1263 | B96AS00A   | Service Tool Kit                   | B9100SE |
| 1264 | B9R3S5400C | Crushing Chamber Assembly          | B9100SE |
| 1265 | B913S5420A | Toe Ring Kit                       | B9100SE |
| 1266 | B913S5421A | Toe Ring                           | B9100SE |
| 1267 | B962V5003A | Rubber Strip                       | B9100SE |
| 1268 | B962S5010B | Chamber Bolt Set                   | B9100SE |
| 1269 | BOLT 24*50 | Bolt                               | B9100SE |
| 1270 | B913S5401C | Crushing Chamber                   | B9100SE |
| 1271 | B9R3S5400C | Crushing Chamber Assembly          | B9100SE |
| 1272 | B902S5014A | Door Frame Hinge Pin Kit           | B9100SE |
| 1273 | B902S5032B | Hinge Pin Long                     | B9100SE |
| 1274 | B902S5033A | Hinge Pin Sleeve                   | B9100SE |
| 1275 | B913S5412A | Door Hinge Frame                   | B9100SE |
| 1276 | B913S5416A | Lock Pin                           | B9100SE |
| 1277 | B913S5418A | Lock Pin Latch Block               | B9100SE |
| 1278 | B913S5413A | Door Handle                        | B9100SE |
| 1279 | B962S5017A | Door Spring                        | B9100SE |
| 1280 | B913S5411B | Door                               | B9100SE |
| 1281 | B913S5415A | Door Handle Hinge Pin Kit          | B9100SE |
| 1282 | B913S5436A | Door Handle Pin                    | B9100SE |
| 1283 | B913S5437A | Hinge Pin Sleeve                   | B9100SE |
| 1284 | B913S5445A | Latch Plate Kit                    | B9100SE |
| 1285 | B913S5446A | Door Handle Latch Plate            | B9100SE |
| 1286 | B913S5447A | Door Handle Shim                   | B9100SE |
| 1287 | B962S5002B | Swing Bolt Kit                     | B9100SE |
| 1288 | B962S5026A | Swing Bolt Nut                     | B9100SE |
| 1289 | B962S5027A | Roof Swing Bolt                    | B9100SE |
| 1290 | B962S5028B | Swing Bolt Pin                     | B9100SE |

|      |              |                               |         |
|------|--------------|-------------------------------|---------|
| 1291 | B913S6400E   | Cavity Ring Assmblly - Coarse | B9100SE |
| 1292 | B913S6400E/M | Cavity Ring - Coarse          | B9100SE |
| 1293 | B913S6403C   | Cavity Ring Bolt Set          | B9100SE |
| 1294 | B913S7400C   | Spider Assembly               | B9100SE |
| 1295 | B913S7430C   | Feed Kit - Standard Style     | B9100SE |
| 1296 | B913S7432B   | Feed Tube Location Plate      | B9100SE |
| 1297 | B913S7433A   | Feed Clamp Plate              | B9100SE |
| 1298 | B913S7434A   | Spring Handle                 | B9100SE |
| 1299 | B962S7040B   | Feed Tube                     | B9100SE |
| 1300 | B913S7401C   | Spider Frame                  | B9100SE |
| 1301 | B913S7420C   | Feed Kit Holder               | B9100SE |
| 1302 | B913S7440C   | Wear Skirt Kit                | B9100SE |
| 1303 | B913S7441C   | Wear Skirt                    | B9100SE |
| 1304 | B913S7410A   | Spider Packer Kit             | B9100SE |
| 1305 | B913S7413A   | Packer 12                     | B9100SE |
| 1306 | B913S7414A   | Packer 6                      | B9100SE |
| 1307 | B913S7450B   | Wedge Kit                     | B9100SE |
| 1308 | B913S7451B   | Wedge                         | B9100SE |
| 1309 | B9R3S8400D   | Roof Assembly                 | B9100SE |
| 1310 | B9R3S8401D   | Roof Lifter Roof              | B9100SE |
| 1311 | B913S8410A   | Roof Wear Ring Kit            | B9100SE |
| 1312 | B913S8411B   | Roof Wear Ring                | B9100SE |
| 1313 | B913S8430B   | Ram Cover Kit                 | B9100SE |
| 1314 | B913S8431B   | Ram Cover                     | B9100SE |
| 1315 | B9R3S8450A   | Hose Clamp                    | B9100SE |
| 1316 | B913S9400B   | Hopper Assembly               | B9100SE |
| 1317 | B913S9411B   | Cascade Window Shield         | B9100SE |
| 1318 | B913S9401B   | Hopper                        | B9100SE |
| 1319 | B913S9420B   | Rubber Skirt Kit              | B9100SE |
| 1320 | B913S9421B   | Rubber Skirt - Outer          | B9100SE |
| 1321 | B913S9422B   | Rubber Skirt - Inner          | B9100SE |
| 1322 | BOLT 10*40   | Bolt M10 X 40 Grade 8.8       | B9100SE |
| 1323 | B913S9452D   | Control Plate - 280           | B9100SE |
| 1324 | B913S9452C   | Control Plate - 340           | B9100SE |
| 1325 | B913S9452E   | Control Plate – 220           | B9100SE |
| 1326 | B913S9400B   | Hopper Assembly               |         |
| 1327 | B913S9430B   | Hopper Access Guard Kit       | B9100SE |
| 1328 | B913S9431B   | Hopper Access Guard           | B9100SE |

|      |              |                                  |         |
|------|--------------|----------------------------------|---------|
| 1329 | B913S9440A   | Spreader Plate Kit               | B9100SE |
| 1330 | B913S9441A   | Spreader Plate                   | B9100SE |
| 1331 | B913S9442A   | Spreader Plate Support           | B9100SE |
| 1332 | B913S9443A   | Spreader Plate Spacer            | B9100SE |
| 1333 | B913S9470B   | Control Gate Kit                 | B9100SE |
| 1334 | B913S9471B   | Control Gate                     | B9100SE |
| 1335 | B913S9472B   | Clevis Pin                       | B9100SE |
| 1336 | B702SH300B/S | Hydraulic Ram                    | B9100SE |
| 1337 | B9R3SR400C   | Roof Lifter Assembly             | B9100SE |
| 1338 | B963S3019A   | Bottom V-Ring Seal               | B9100SE |
| 1339 | B9R3SR414A   | Roof Lifter Spacer               | B9100SE |
| 1340 | B9R3SR402C   | Top Bush                         | B9100SE |
| 1341 | B9R3SR411C   | Roof Lifter Pillar               | B9100SE |
| 1342 | B9R3SR403B   | Roof Lifter Top Seal V-Ring      | B9100SE |
| 1343 | B9R3SR431A   | Worm Gear                        | B9100SE |
| 1344 | B9R3SR432A   | Drive Shaft                      | B9100SE |
| 1345 | B9R3SR433A   | Hexagonal Drive                  | B9100SE |
| 1346 | B9R3SR418B   | Roof Lifter Bolt Set             | B9100SE |
| 1347 | B9R3SR404C   | Roof Lifter Housing              | B9100SE |
| 1348 | B9R3SR437A   | Gear Cover Kit                   | B9100SE |
| 1349 | B9R3SR434A   | Gear Cover                       | B9100SE |
| 1350 | B9R3SR410C   | Pivot Pin Kit                    | B9100SE |
| 1351 | B9R3SR413C   | Pivot Pin                        | B9100SE |
| 1352 | B9R3SR435A   | Ring Gear                        | B9100SE |
| 1353 | B9R3SR436A   | Ring Gear Key                    | B9100SE |
| 1354 | B9R3SR440A   | Safety Pin Kit                   | B9100SE |
| 1355 | B9R3SR441A   | Safety Pin                       | B9100SE |
| 1356 | B9R3SR406C   | Roof Lifter Taper Roller Bearing | B9100SE |
| 1357 | B9R3SR400C   | Roof Lifter Assembly (Cont.)     | B9100SE |
| 1358 | B9R3SR451B   | Hose/Fittings Kit                | B9100SE |
| 1359 | B9R3SR454A   | Load Hold Valve                  | B9100SE |
| 1360 | B9R3SR455A   | Selector Valve Kit               | B9100SE |
| 1361 | B9R3SR453A   | Selector Valve                   | B9100SE |
| 1362 | B9R3SR452A   | 5" Ram                           | B9100SE |
| 1363 | B9R3SR465A   | Short Cylinder Pin Kit           | B9100SE |
| 1364 | B9R3SR466A   | Short Cylinder Pin               | B9100SE |
| 1365 | B9R3SR460A   | Long Cylinder Pin Kit            | B9100SE |
| 1366 | B9R3SR461A   | Long Cylinder Pin                | B9100SE |

|      |            |                                   |         |
|------|------------|-----------------------------------|---------|
| 1367 | B9R3S5400C | Crushing Chamber Assembly (Cont.) | B9100SE |
| 1368 | B913S5407A | Stripe Decal                      | B9100SE |
| 1369 | B913S5405C | Decal "Barmac B9100Se Rl Vsi"     | B9100SE |
| 1370 | B913S5406A | Decal "Metso"                     | B9100SE |
| 1371 | B962S2017C | Lift Decal                        | B9100SE |
| 1372 | B962S5009E | Nameplate                         | B9100SE |
| 1373 | B962S5031B | Decal "Refit Safety Pin"          | B9100SE |
| 1374 | B962S5008B | Decal "Danger – Do Not Open"      | B9100SE |
| 1375 | B9R3S8400D | Roof Assembly (Cont.)             | B9100SE |
| 1376 | B902S9314A | Decal "Do Not Clear"              | B9100SE |
| 1377 | B913S8402A | Decal "Replace Guard Warning"     | B9100SE |
| 1378 | B962S8013A | Decal "Direction Of Rotor"        | B9100SE |
| 1379 | 1029300198 | Information Plate (Dust Warning)  | B9100SE |
| 1380 | B9R3SR425A | Rl Safety Pin Decal               | B9100SE |
| 1381 | B91AD00A   | 9100 Decal Set                    | B9100SE |
| 1382 | B913S5407A | Stripe Decal                      | B9100SE |
| 1383 | B913S5405C | Decal "Barmac B9100 Vsi"          | B9100SE |
| 1384 | B913S5406A | Decal "Metso"                     | B9100SE |
| 1385 | B962S2017C | Lift Decal                        | B9100SE |
| 1386 | B962S5031B | Decal "Refit Safety Pin"          | B9100SE |
| 1387 | B962S5008B | Decal "Danger – Do Not Open"      | B9100SE |
| 1388 | B902S9314A | Decal "Do Not Clear"              | B9100SE |
| 1389 | B913S8402A | Decal "Replace Guard Warning"     | B9100SE |
| 1390 | B962S8013A | Decal "Direction Of Rotor"        | B9100SE |
| 1391 | 1029300198 | Information Plate (Dust Warning)  | B9100SE |
| 1392 | B903X2000B | Crusher Base Assembly             | B9100SE |
| 1393 | B902S2018A | Decal "Warning – Do Not Open"     | B9100SE |
| 1394 | B913S5409C | Nameplate                         | B9100SE |
| 1395 | B962S2017C | Lift Decal                        | B9100SE |
| 1396 | B963X1020B | Transmission Case Assembly – Xhd  | B9100SE |
| 1397 | B902S2018A | Decal "Warning – Do Not Open"     | B9100SE |
| 1398 | B962S1023B | Decal "Belt Tension"              | B9100SE |
| 1399 | B96AD06A   | Decal Set – Dual Drive            | B9100SE |
| 1400 | B902S2018A | Decal "Warning – Do Not Open"     | B9100SE |
| 1401 | B962S2017C | Lift Decal                        | B9100SE |
| 1402 | B962S1023B | Decal "Belt Tension"              | B9100SE |
| 1403 | B903X2000B | Crusher Base Assembly             | B9100SE |
| 1404 | B611S5460B | Grease Hose Extension Kit         | B9100SE |

|      |              |                                             |         |
|------|--------------|---------------------------------------------|---------|
| 1405 | B611S5461B   | Grease Extension Block                      | B9100SE |
| 1406 | B913S5462A   | Grease Extension Hose                       | B9100SE |
| 1407 | B903S2002A   | Base Inspection Door Kit                    | B9100SE |
| 1408 | B903S2018A   | Crusher Base Inspection Door                | B9100SE |
| 1409 | B903X2001B   | Crusher Base                                | B9100SE |
| 1410 | B962S2013A   | Taper Ring Bolt Set                         | B9100SE |
| 1411 | B963S2003A   | Top Taper Ring                              | B9100SE |
| 1412 | B963X2012A   | Plastic Grommet Set                         | B9100SE |
| 1413 | B963X2022B   | Gusset Wear Casting                         | B9100SE |
| 1414 | B963X2025A   | Gusset Casting Bolt Set                     | B9100SE |
| 1415 | B903X2045A   | Vocs Ducting Kit                            | B9100SE |
| 1416 | B903X2042A   | Vocs Conduit                                | B9100SE |
| 1417 | B903X2043A   | 20Mm Half Saddle                            | B9100SE |
| 1418 | B903X2050A   | Vocshole Plate Kit                          | B9100SE |
| 1419 | B903X2051A   | Vocs Hole Plate                             | B9100SE |
| 1420 | B962S2024A   | Bulkhead Fitting                            | B9100SE |
| 1421 | B963S2004A   | Bottom Taper Ring Outer                     | B9100SE |
| 1422 | B963S2005A   | Bottom Taper Ring Inner                     | B9100SE |
| 1423 | B963X1136A   | Grease Duct                                 | B9100SE |
| 1424 | B963X1137A   | Grease Duct Bolt Set                        | B9100SE |
| 1425 | B963X2009A   | Grease Hose                                 | B9100SE |
| 1426 | B963X2010A   | Grease Chute                                | B9100SE |
| 1427 | B913S2470A   | Divider Block Kit                           | B9100SE |
| 1428 | B913S2471A   | Divider Block                               | B9100SE |
| 1429 | B913S2472A   | Dowty Seal – $\frac{1}{4}$ ; Bsp            | B9100SE |
| 1430 | B913S2473A   | Adaptor 1/8 Bspt M – $\frac{1}{4}$ ; Bspt M | B9100SE |
| 1431 | B913S2474A   | Adaptor 1/8 Bspp F – 1/8 Bspp F             | B9100SE |
| 1432 | B913S2475A   | Adaptor 1/8 Bsp M – 7/16 Jic M              | B9100SE |
| 1433 | B903X2000B   | Crusher Base Assembly                       | B9100SE |
| 1434 | B903X2030C   | Full Base Liner Kit                         | B9100SE |
| 1435 | B903X2030C/M | Full Base Liner Fabrication                 | B9100SE |
| 1436 | B903X2040A   | Hatch Liner                                 | B9100SE |
| 1437 | B903X2035A/R | Base Liner                                  | B9100SE |
| 1438 | B903X2033A/R | Base Liner                                  | B9100SE |
| 1439 | B903X2034C/R | Base Liner                                  | B9100SE |
| 1440 | B903X2031A/L | Base Liner                                  | B9100SE |
| 1441 | B903X2031A/R | Base Liner                                  | B9100SE |
| 1442 | B903X2032A   | Base Liner                                  | B9100SE |

|      |              |                                       |         |
|------|--------------|---------------------------------------|---------|
| 1443 | B903X2033A/L | Base Liner                            | B9100SE |
| 1444 | B903X2034C/L | Base Liner                            | B9100SE |
| 1445 | B903X2035A/L | Base Liner                            | B9100SE |
| 1446 | B903X2036A   | Base Liner                            | B9100SE |
| 1447 | B903X2038A/L | Base Liner                            | B9100SE |
| 1448 | B903X2038A/R | Base Liner                            | B9100SE |
| 1449 | B903X2039A   | Base Liner '38' Rh                    | B9100SE |
|      |              | Base Liner Bolt Set                   |         |
| 1450 | B963S3000A/V | Shaft Line Assembly - Vocs            | B9100SE |
| 1451 | B963S3001A   | Housing                               | B9100SE |
| 1452 | B963S3002A   | Main Shaft                            | B9100SE |
| 1453 | B963S3003A   | Radial Bearing                        | B9100SE |
| 1454 | B963S3004A   | Upper Bearing Retaining Ring          | B9100SE |
| 1455 | B963S3005A   | Upper Bearing Retaining Ring Screw    | B9100SE |
| 1456 | B963S3006A   | Top Seal Plate                        | B9100SE |
| 1457 | B963S3007A   | Top O-Ring Seal (Shaft)               | B9100SE |
| 1458 | B963S3008C   | O-Ring Seal (Cartridge)               | B9100SE |
| 1459 | B963S3009A   | Inner V-Ring Seal                     | B9100SE |
| 1460 | B963S3010A   | Outer V-Ring Seal                     | B9100SE |
| 1461 | B963S3011A   | Grease Retaining Ring                 | B9100SE |
| 1462 | B963S3023A   | Top Key                               | B9100SE |
| 1463 | B963S3000A/V | Shaft Line Assembly - Vocs            | B9100SE |
| 1464 | B963S3003A   | Radial Bearing                        | B9100SE |
| 1465 | B963S3012A   | Inner Spacer                          | B9100SE |
| 1466 | B963S3013A   | Outer Spacer                          | B9100SE |
| 1467 | B963S3014A   | Trhust Bearing                        | B9100SE |
| 1468 | B963S3015A   | Lower Bearing Retaining Ring          | B9100SE |
| 1469 | B963S3016A   | Lower Seal Plate                      | B9100SE |
| 1470 | B963S3017A   | Bottom Cover                          | B9100SE |
| 1471 | B963S3018A   | Lower Bearing Retaining Ring Bolt Set | B9100SE |
| 1472 | B963S3019A   | Bottom V-Ring Seal                    | B9100SE |
| 1473 | B963S3020A   | Bottom O-Ring Seal (Shaft)            | B9100SE |
| 1474 | B963S3021A   | Locknut                               | B9100SE |
| 1475 | B963S3022A   | Locknut Washer                        | B9100SE |
| 1476 | B963S3025A   | Lower Seal Plate Key                  | B9100SE |
| 1477 | B963S3026A   | Bottom Key                            | B9100SE |
| 1478 | B963S3060A   | B9600 Mk Iii Vocs Plug Kit            | B9100SE |
| 1479 | B963S3065B   | Vocs Mk Iii M12 Plug Cover            | B9100SE |

|      |              |                                      |         |
|------|--------------|--------------------------------------|---------|
| 1480 | B963S3061B   | Mk Iii Vocs Rtd Wiring Loom          | B9100SE |
| 1481 | B963S3000A/V | Shaft Line Assembly – Vocs           | B9100SE |
| 1482 | B962S3029A   | Decal “Grease Warning”               | B9100SE |
| 1483 | B962S3031A   | Decal “Storage Warning”              | B9100SE |
| 1484 | B962S3032A   | Decal “Grease Identification”        | B9100SE |
| 1485 | B902S2016B   | Decal “Grease Bearings”              | B9100SE |
| 1486 | B902S2016X   | Grease Selection Decal               | B9100SE |
| 1487 | B963S3050A   | Top Seal Kit                         | B9100SE |
| 1488 | B963S3007A   | Top O-Ring Seal (Shaft)              | B9100SE |
| 1489 | B963S3008C   | O-Ring Seal (Cartridge)              | B9100SE |
| 1490 | B963S3009A   | Inner V-Ring Seal                    | B9100SE |
| 1491 | B963S3010A   | Outer V-Ring Seal                    | B9100SE |
| 1492 | B963S3008A   | O-Ring Seal (Cartridge)              | B9100SE |
| 1493 | B963S3051A   | Bottom Seal Kit                      | B9100SE |
| 1494 | B963S3019A   | Bottom V-Ring Seal                   | B9100SE |
| 1495 | B963S3020A   | Bottom O-Ring Seal (Shaft)           | B9100SE |
| 1496 | B962S1010D   | Motor Mount Assembly                 | B9100SE |
| 1497 | B962S1015C   | Motor Mount Bolt Set                 | B9100SE |
| 1498 | B962S1011C   | Motor Mount                          | B9100SE |
| 1499 | B962S1012A   | Cover Plate                          | B9100SE |
| 1500 | B962S1018A   | Support Bracket Kit                  | B9100SE |
| 1501 | B962S1017A   | Support Bracket                      | B9100SE |
| 1502 | B962S1019A   | Tie Back Spacer                      | B9100SE |
| 1503 | B691S1013B   | Adjuster Rod Kit                     | B9100SE |
| 1504 | B691S1052A   | Adjuster Rod                         | B9100SE |
| 1505 | B962S1014A   | Adjuster Nut                         | B9100SE |
| 1506 | B962S1051A   | Adjuster Boss                        | B9100SE |
| 1507 | B963X1020B   | Transmission Case Assembly - Xhd     | B9100SE |
| 1508 | B962S1026A   | Transmission End Hatch               | B9100SE |
| 1509 | B963X1021B   | Transmission Case                    | B9100SE |
| 1510 | B963X1022A   | Transmission Case Bolt Set           | B9100SE |
| 1511 | B962S1024C   | Inspection Hole Cover Plate          | B9100SE |
| 1512 | B962S1025A   | Inspection Hole Cover Plate Bolt Set | B9100SE |
| 1513 | B962S1027A   | Transmission End Hatch Bolt Set      | B9100SE |
| 1514 | B963X1130B   | Belt Guard Assembly - Dual Drive     | B9100SE |
| 1515 | B963X1033B   | Guard Bolt Set                       | B9100SE |
| 1516 | B963X1031B   | Transmission Belt Guard              | B9100SE |
| 1517 | B963X1035C   | Base Belt Guard                      | B9100SE |

|      |              |                                         |         |
|------|--------------|-----------------------------------------|---------|
| 1518 | B96AC11B     | Hydraulic Handpump                      | B9100SE |
| 1519 | B902SH324B   | Hose Adapter                            | B9100SE |
| 1520 | B96AC14B     | Handpump Bolt Set                       | B9100SE |
| 1521 | B96AC30A     | Decal "Gate Position"                   | B9100SE |
| 1522 | B96AC12B     | Seal Kit                                | B9100SE |
| 1523 | B96AC15B     | Handpump Hose                           | B9100SE |
| 1524 | B96AI11D     | Door Lock, Timer Box & Rotary Switch    | B9100SE |
| 1525 | B96AI11B/401 | Key                                     | B9100SE |
| 1526 | B96AI11B/402 | Key                                     | B9100SE |
| 1527 | B96AI11C/300 | Rotary Switch                           | B9100SE |
| 1528 | B96AI11C/400 | Basic Lock With Brass Internals         | B9100SE |
| 1529 | B96AI11D/100 | Door Lock                               | B9100SE |
| 1530 | B96AI11D/101 | Stainless Steel Self Aligning Bolt      | B9100SE |
| 1531 | B96AI11B/102 | Rubber Seal To Suit Stainless Steel Cap | B9100SE |
| 1532 | B96AI11B/103 | Stainless Steel Cap                     | B9100SE |
| 1533 | B96AI11B/104 | Basic Lock With Stainless Steel         | B9100SE |
| 1534 | B96AI11B/105 | Internal Cam To Suit H31Cn/Le           | B9100SE |
| 1535 | B96AI11D/200 | Timer Box                               | B9100SE |
| 1536 | B96AI11D/202 | Fuse (5A)                               | B9100SE |
| 1537 | B96AI11B/104 | Basic Lock With Stainless Steel         | B9100SE |
| 1538 | B96AI11B/103 | Stainless Steel Cap                     | B9100SE |
| 1539 | B96AI11B/102 | Rubber Seal To Suit Stainless Steel Cap | B9100SE |
| 1540 | B96AI16B     | 4Mm Post Allen Key                      | B9100SE |
| 1541 | B91AV21B     | Vocs Controller                         | B9100SE |
| 1542 | B91AV23A     | Vocs Controller Overlay                 | B9100SE |
| 1543 | B91AV21B/1   | Complete Controller Pcb                 | B9100SE |
| 1544 | B91AV21A/2   | Key Lock And Key                        | B9100SE |
| 1545 | B91AV22B     | Vocs Data Sender                        | B9100SE |
| 1546 | B91AV22B/1   | Data Sender Pcb                         | B9100SE |
| 1547 | B91AV22A/3   | Vibration Sensor Block                  | B9100SE |
| 1548 | B91AV26B     | Vocs Data Sender Bearing Rtd Cable      | B9100SE |
| 1549 | B91AV31A     | Vocs Power Supply                       | B9100SE |
| 1550 | B91AV80A     | Power Filter                            | B9100SE |
| 1551 | B91AV51A     | Vocs Data Logger                        | B9100SE |
| 1552 | B91AV52A     | Vocs Data Logger Software               | B9100SE |
| 1553 | B91AV36B     | Vocs Cable 100M                         | B9100SE |
| 1554 | B90AP91      | Antivibration Mount                     | B9100SE |
| 1555 | B90AP92      | Antivibration Mount Bolt Set            | B9100SE |

|      |           |                                        |         |
|------|-----------|----------------------------------------|---------|
| 1556 | B90AP94   | Decal “Loosen Transport Bolts”         | B9100SE |
| 1557 | B96AS21   | Rotor Balance Side Frame               | B9100SE |
| 1558 | B90AS22B  | Rotor Balance End Bracket - Deep Rotor | B9100SE |
| 1559 | B90AS24A  | Rotor Balance Shaft - Deep Rotor       | B9100SE |
| 1560 | B69AS25   | Rotor Balance Shaft Washer             | B9100SE |
| 1561 | B96AS26   | Rotor Balance Bearing                  | B9100SE |
| 1562 | B96AS27B  | Rotor Balance Bolt Set                 | B9100SE |
| 1563 | B96AS28   | Rotor Balance Taper Adapter            | B9100SE |
| 1564 | B96AS29   | Rotor Balance Locknut                  | B9100SE |
| 1565 | B96AS13   | Lifting Kit                            | B9100SE |
| 1566 | B96AS10B  | Lifting Eye Bolt                       | B9100SE |
| 1567 | B96AS12C  | Rotor Lifting Plate                    | B9100SE |
| 1568 | B96AS14   | Belt Tensioner                         | B9100SE |
| 1569 | B96AS15   | Distributor Bolt Socket                | B9100SE |
| 1570 | B96AS16   | Podger Bar                             | B9100SE |
| 1571 | B96AS17   | Swing Bolt Spanner                     | B9100SE |
| 1572 | B90AS19   | Touch-Up Paint Kit                     | B9100SE |
| 1573 | B90AS19/A | Brush                                  | B9100SE |
| 1574 | B90AS19/B | Paint                                  | B9100SE |
| 1575 | B90AS19/C | Rust Proof Paint                       | B9100SE |
| 1576 | B90AS60A  | Grease Cartridge                       | B9100SE |