

Gyratory Crusher Spare Parts Number

No	Part Number	Description	Model
1	454.2715-901	Spider	CG820
2	454.2908-901	Liner - Spider hub	CG820
3	454.2523-901	Spherical bearing	CG820
4	847.0038-00	Spring washer	CG820
5	841.0605-00	Screw	CG820
6	454.2536-001	Retainer - Spherical bearing	CG820
7	454.2537-001	Special washer	CG820
8	454.2539-001	Special washer	CG820
9	873.1457-00	O-ring	CG820
10	840.1256-00	Screw	CG820
11	454.2540-001	Holder - Grease seal	CG820
12	454.2097-001	Seal - Spherical bearing	CG820
13	454.2541-001	Pin - Oil seal holder	CG820
14	454.2621-001	Scraper - Spherical bearing	CG820
15	454.2679-901	Stud spider/upper topshell As.	CG820
16	454.2680-901	Bolt Spider/Upper topshell As.	CG820
17	454.3058-901	Liner - Spider rim	CG820
18	454.3056-001	Pin - Spider rim liner	CG820
19	454.3057-001	Packing - Spider rim liner	CG820
20	454.3053-001	Liner	CG820
21	454.3054-001	Liner	CG820
22	454.3055-001	Liner	CG820
23	454.2846-901	Square head bolt	CG820
24	863.0058-00	Disc spring	CG820
25	454.2831-001	Spider cap	CG820
26	454.2906-001	Pin - Spider cap	CG820
27	873.1456-00	O-ring	CG820
28	454.2533-001	Bushing - Spherical bearing	CG820
29	840.0047-00	Screw	CG820
30	847.0350-00	Tab washer	CG820
31	842.0314-00	Screw	CG820
32	454.3093-901	Liner - Spider arm	CG820
33	454.3079-001	Liner	CG820
34	454.3092-001	Pin - Spider arm liner	CG820
35	454.2834-901	Square head bolt - Spider arm liner	CG820
36	454.2774-001	Spring - Spider arm liner	CG820

37	454.2542-001	Spring seat - Spider arm liner	CG820
38	454.5738-901	Cover - spherical bearing	CG820
39	454.3056-001	Pin - Spider rim liner	CG820
40	454.3057-001	Packing - Spider rim liner	CG820
41	454.3053-001	Liner - Spider rim	CG820
42	454.3055-001	Liner - Spider rim	CG820
43	454.3054-001	Liner - Spider rim	CG820
44	454.3484-901	Cover Spherical bearing	CG820
45	840.0077-00	Screw	CG820
46	847.0351-00	Tab Washer	CG820
47	873.1464-00	O-ring	CG820
48	900.0717-00	Filter Plug	CG820
49	454.5739-901	Holder	CG820
50	454.5440-901	Holder	CG820
51	454.3522-001	Indicating instrument	CG820
52	454.5154-001	Temperature sensor	CG820
53	454.1706-001	Topshell- Lower	CG820
54	454.3003-901	Concave support ring set	CG820
55	454.2685-001	Shim	CG820
56	454.2686-001	Shim	CG820
57	454.2544-001	Shim	CG820
58	454.2648-901	Bolt - Upper-/Lower topshell	CG820
59	454.3040-901	Concave Row Assembly	CG820
60	454.2788-901	Concave Row, Key	CG820
61	454.2781-901	Concave Row	CG820
62	454.2785-901	Concave Row	CG820
63	454.2786-901	Concave Row	CG820
64	454.3042-901	Concave Row Assembly	CG820
65	454.2795-901	Concave Row, Key	CG820
66	454.2791-901	Concave Row , bolt	CG820
67	454.2793-901	Concave Row, bolt	CG820
68	454.3043-901	Concave Row Assembly	CG820
69	454.2801-901	Concave Row, Key	CG820
70	454.2799-901	Concave Row	CG820
71	454.3044-901	Concave Row Assembly	CG820
72	454.2808-901	Concave Row, Key	CG820
73	454.2804-901	Concave Row	CG820
74	454.2806-901	Concave Row	CG820

75	454.2631-901	Retaining bolt	CG820
76	454.2637-901	Retaining bolt	CG820
77	454.2637-901	Retaining bolt	CG820
78	454.2637-901	Retaining bolt	CG820
79	831.0016-00	Casting compound kg	CG820
80	454.2647-001	Jack screw	CG820
81	454.3775-001	Topshell - Upper	CG820
82	454.2545-001	Mainshaft	CG820
83	454.2546-001	Mainshaft sleeve	CG820
84	454.3789-001	Stopper - Mainshaft sleeve	CG820
85	841.0629-00	Screw	CG820
86	847.0199-00	Spring washer	CG820
87	454.2547-001	Protective ring - Mainshaft	CG820
88	841.0610-00	Screw	CG820
89	841.0520-00	Screw	CG820
90	454.2550-001	Threaded collar - Mainshaft	CG820
91	454.2551-001	Head nut	CG820
92	454.2552-001	Locking pin	CG820
93	900.2972-00	Plug	CG820
94	914.0090-00	Lubrication nipple	CG820
95	454.3999-001	Wire Aluminium0	CG820
96	831.0082-00	Sealing compound Sikasil tran	CG820
97	454.2650-001	Holder - Dust seal ring	CG820
98	454.2555-901	Dust seal ring	CG820
99	454.2656-901	Retainer - Dust seal ring	CG820
100	841.0611-00	Screw	CG820
101	847.0371-00	Spring washer	CG820
102	840.1251-00	Screw	CG820
103	454.3523-901	Oil splash curtain Set	CG820
104	454.2657-001	Special washer	CG820
105	840.0667-00	Screw	CG820
106	454.3927-001	Mantle	CG820
107	831.0016-00	Casting compound kg	CG820
108	454.3788-001	Lifting eye bolt	CG820
109	454.4564-001	Bottomshell	CG820
110	454.2559-001	Bottomshell bushing	CG820
111	454.2560-001	Key Bottomshell bushing	CG820
112	454.2937-901	Liner set - Bottomshell hub	CG820

113	840.0670-00	Screw	CG820
114	847.0373-00	Tab washer	CG820
115	840.1250-00	Screw	CG820
116	847.0200-00	Spring washer	CG820
117	847.0026-00	Washer	CG820
118	900.0215-00	Plug	CG820
119	454.3506-901	Pipe - Return oil outlet	CG820
120	840.0077-00	Screw	CG820
121	847.0038-00	Washer FBB	CG820
122	454.3510-001	Gasket	CG820
123	454.2563-901	Liner Narrow arm	CG820
124	454.2564-901	Liner Pinionshaft arm	CG820
125	454.2563-901	Liner Narrow arm	CG820
126	454.2564-901	Liner Pinionshaft arm	CG820
127	454.3420-901	Pipe Oil inlet	CG820
128	454.3422-901	Pipe Air inlet	CG820
129	454.3993-901	Liner set - Bottomshell	CG820
130	454.2572-001	Countersunk head bolt	CG820
131	847.0371-00	Spring washer	CG820
132	454.2573-001	Special washer	CG820
133	845.0013-00	Nut	CG820
134	454.3566-901	Eccentric with key Alt.	CG820
135	454.2582-001	Key Spiral bevel gear	CG820
136	454.2583-001	Eccentric support plate	CG820
137	454.2587-001	Eccentric bushing	CG820
138	454.2588-001	Eccentric wearing plate	CG820
139	454.2584-901	Gear and pinion set	CG820
140	841.0609-00	Screw	CG820
141	847.0372-00	Spring washer	CG820
142	841.0610-00	Screw	CG820
143	873.1460-00	O-ring	CG820
144	841.0612-00	Screw	CG820
145	847.0200-00	Spring washer	CG820
146	841.0608-00	Screw	CG820
147	454.3783-001	Pinionshaft housing	CG820
148	454.2296-001	Adjustment ring	CG820
149	840.1132-00	Screw	CG820
150	847.0044-00	Spring washer	CG820

151	873.1461-00	O-ring	CG820
152	900.2970-00	Plug	CG820
153	900.0717-00	Filter plug	CG820
154	900.2696-00	Reducer	CG820
155	454.3782-001	Oil level gauge -HYDAC FSA	CG820
156	454.3797-001	Pinionshaft	CG820
157	845.0423-00	Lock nut	CG820
158	899.0500-00	Locking clip	CG820
159	847.0030-00	Washer	CG820
160	840.0009-00	Screw	CG820
161	454.3802-001	Bearing cover - Pinion end	CG820
162	454.3799-001	Special washer	CG820
163	873.1008-00	V-ring	CG820
164	873.1455-00	O-ring	CG820
165	840.1254-00	Screw	CG820
166	454.1065-001	Labyrinth collar	CG820
167	842.0230-00	Screw	CG820
168	454.1060-001	Bearing cover - Outer end	CG820
169	873.1029-00	V-ring	CG820
170	847.0044-00	Spring washer	CG820
171	873.1455-00	O-ring	CG820
172	840.1237-00	Screw	CG820
173	873.1463-00	Oil seal ring	CG820
174	454.3760-001	Roller bearing Spherical	CG820
175	454.3803-001	Roller bearing Cylindrical	CG820
176	454.3804-001	Spacer - Pinion end	CG820
177	454.1070-001	Spacer - Outer end	CG820
178	454.1066-001	Retainer - Pinion end	CG820
179	454.1068-001	Special washer	CG820
180	840.1080-00	Screw	CG820
181	454.2267-001	Parallel key	CG820
182	454.3440-001	Key	CG820
183	454.3540-901	Oil outlet - Overflow line	CG820
184	454.3502-901	Piping -overflow piping B	CG820
185	454.3542-001	Hose	CG820
186	900.1262-00	L-adapter	CG820
187	900.3060-00	Adapter	CG820
188	902.0061-00	Ball valve	CG820

189	840.1277-00	Screw	CG820
190	873.0386-00	Seal	CG820
191	984.0217-00	Rotation sensor	CG820
192	454.3783-001	Pinionshaft housing	CG820
193	454.3797-001	Pinionshaft	CG820
194	454.3802-001	Bearing cover - Pinion end	CG820
195	454.1065-001	Labyrinth collar	CG820
196	454.1060-001	Bearing cover - Outer end	CG820
197	454.3760-001	Roller bearing Spherical	CG820
198	454.3803-001	Roller bearing Cylindrical	CG820
199	454.1070-001	Spacer - Outer end	CG820
200	454.2296-001	Adjustment ring	CG820
201	454.1066-001	Retainer - Pinion end	CG820
202	454.2267-001	Parallel key	CG820
203	454.3440-001	Key	CG820
204	845.0423-00	Lock nut	CG820
205	873.1008-00	V-ring	CG820
206	873.1029-00	V-ring	CG820
207	840.1132-00	Screw	CG820
208	847.0044-00	Spring washer	CG820
209	873.1461-00	O-ring	CG820
210	873.1455-00	O-ring	CG820
211	840.1254-00	Screw	CG820
212	840.1237-00	Screw	CG820
213	873.1463-00	Oil seal ring	CG820
214	842.0230-00	Screw	CG820
215	454.3540-901	Piping -Overflow piping	CG820
216	454.3542-001	Hose	CG820
217	900.1262-00	L-adapter	CG820
218	900.3060-00	Adapter	CG820
219	902.0061-00	Ball valve	CG820
220	900.2970-00	Plug	CG820
221	900.0717-00	Filter plug	CG820
222	900.2696-00	Reducer	CG820
223	454.3782-001	Oil level gauge	CG820
224	840.1277-00	Screw	CG820
225	873.0386-00	Seal Tredo	CG820
226	899.0500-00	Locking clip	CG820

227	847.0030-00	Washer	CG820
228	840.0009-00	Screw	CG820
229	454.1067-001	V-belt pulley	CG820
230	454.1068-001	Special washer	CG820
231	840.1080-00	Screw	CG820
232	454.4632-001	Spacer ring	CG820
233	984.0217-00	Rotation sensor	CG820
234	454.2951-901	Hydroset cylinder	CG820
235	454.3038-001	Hydroset cylinder cover	CG820
236	454.2978-901	Stud - Hydroset cylinder	CG820
237	454.2988-901	Bolt -Hydroset cylinder Cover	CG820
238	873.1459-00	O-ring	CG820
239	454.3041-001	Piston - Hydroset	CG820
240	454.2591-001	Guide bushing	CG820
241	454.2592-001	Concave adapter	CG820
242	454.2593-001	Convex adapter	CG820
243	454.3012-901	V-packing	CG820
244	454.2595-001	Shim	CG820
245	454.3779-001	Shim	CG820
246	454.3780-001	Shim	CG820
247	454.2596-001	Stopper V-packing	CG820
248	454.2597-001	Special washer	CG820
249	840.0065-00	Screw	CG820
250	454.3007-001	Scraper	CG820
251	454.2958-001	Back-up ring	CG820
252	454.3631-001	Stopper - Hydroset piston	CG820
253	873.1531-00	O-ring	CG820
254	454.3790-901	Step bearing set	CG820
255	840.1255-00	Screw	CG820
256	454.2557-001	Special washer	CG820
257	454.2965-001	Pin - Piston wearing plate	CG820
258	454.2598-001	Retaining boss	CG820
259	454.2599-001	Retaining plate	CG820
260	454.2600-001	Special washer	CG820
261	454.2601-001	Special washer	CG820
262	840.0046-00	Screw	CG820
263	454.2602-001	Elbow	CG820
264	873.1451-00	O-ring	CG820

265	841.0615-00	Screw	CG820
266	847.0371-00	Spring washer	CG820
267	873.1462-00	O-ring	CG820
268	840.1252-00	Screw	CG820
269	900.2292-00	Measuring nipple	CG820
270	873.0111-00	O-ring	CG820
271	984.0421-00	Position sensor	CG820
272	841.0239-00	Screw	CG820
273	454.3050-901	Retainer	CG820
274	840.0065-00	Screw	CG820
275	873.0778-00	O-ring	CG820
276	454.3051-001	Special washer	CG820
277	452.1427-001	Protection	CG820
278	840.0065-00	Screw	CG820
279	847.0016-00	Washer	CG820
280	454.2997-001	Protection Segment	CG820
281	840.0065-00	Screw	CG820
282	847.0036-00	Spring washer	CG820
283	845.0009-00	Nut	CG820
284	454.5445-001	Sign product name	CG820
285	126.0446-001	SANDVIK logotype silver	CG820
286	126.0383-001	Risk of crushing	CG820
287	126.0384-001	Warning flying fragments	CG820
288	126.5007-01	Identification plate	CG820
289	126.0385-001	Warning sign read manual	CG820
290	885.0267-00	Warning sign Danger	CG820
291	454.5450-001	Logotypy - spider cap	CG820
292	126.0450-001	Warning sign, Hot surfaces	CG820
293	126.0700-002	Sign rotation direction	CG820
294	454.3916-901	Hydraulic jacks	CG820
295	454.3915-901	Hydraulic jack Assembly	CG820
296	454.3776-001	Retaining ring	CG820
297	853.0834-00	Pin	CG820
298	454.3918-901	Hydraulic jack inc pump&hose	CG820
299	900.2809-00	Hose coupling hose	CG820
300	454.5390-901	Air filter	CG820
301	900.1722-00	Hose clip	CG820
302	906.0609-00	Overpressure fan	CG820

303	819.0231-00	Hose	CG820
304	900.3040-00	Fitting cross	CG820
305	900.2515-00	Bushing	CG820
306	900.3043-00	Bushing	CG820
307	923.0535-00	Pressure gauge	CG820
308	984.1589-00	Pressure transmitter	CG820
309	900.3044-00	Fitting union	CG820
310	902.1107-00	Valve	CG820
311	900.3041-00	Hose coupling Hose	CG820
312	900.0253-00	Plug	CG820
313	899.0483-00	Mounting band	CG820
314	912.0262-00	Air cleaner	CG820
315	900.2806-00	Reducer	CG820
316	900.3042-00	Reducer	CG820
317	912.0261-00	Top spin	CG820
318	900.2804-00	Clamp	CG820
319	900.2807-00	Clamp	CG820
320	912.0263-00	Air filter element	CG820
321	900.2084-00	Clamping ring	CG820
322	923.0539-00	Thermostat	CG820
323	902.1112-00	Pilot operated check valve	CG820
324	902.1113-00	Pressure relief valve	CG820
325	902.1114-00	Coil	CG820
326	923.0540-00	Pressure gauge	CG820
327	902.1115-00	Directional valve	CG820
328	902.1116-00	Manifold	CG820
329	912.0334-00	Filter	CG820
330	912.0338-00	Filter element	CG820
331	912.0335-00	Clogging indicator	CG820
332	984.1616-00	Level switch	CG820
333	972.1260-00	Electric motor	CG820
334	930.0385-00	Spider	CG820
335	923.0538-00	Level gauge	CG820
336	912.0333-00	Air breather	CG820
337	912.0336-00	Air breather element	CG820
338	984.1611-00	Heater	CG820
339	902.1111-00	Ball valve	CG820
340	906.0612-00	Pump	CG820

341	984.1617-00	Pressure transmitter	CG820
342	902.1117-00	Valve	CG820
343	923.0541-00	Pressure gauge	CG820
344	984.1504-00	Pressure transmitter	CG820
345	902.1118-00	Safety valve	CG820
346	902.1119-00	Slow return valve	CG820
347	454.5678-001	Flange	CG820
348	873.0399-00	O-ring	CG820
349	454.5677-001	Flange	CG820
350	840.0677-00	Screw	CG820
351	845.0012-00	Nut	CG820
352	847.0124-00	Washer	CG820
353	454.5664-901	Gasket kit	CG820
354	873.1518-00	O-ring	CG820
355	873.1519-00	O-ring	CG820
356	873.1536-00	Sealing ring	CG820
357	873.1533-00	Sealing ring	CG820
358	900.3061-00	Bleeder	CG820
359	984.1610-00	Level gauge	CG820
360	984.1611-00	Heater	CG820
361	984.1612-00	Temperature transmitter	CG820
362	454.5743-901	Repair kit	CG820
363	972.1256-00	Electric motor	CG820
364	930.0385-00	Spider	CG820
365	906.0611-00	Pump	CG820
366	902.1108-00	Check valve	CG820
367	984.1134-00	Level transmitter	CG820
368	902.1125-00	Motor valve	CG820
369	984.1008-00	Level switch	CG820
370	912.0333-00	Air breather	CG820
371	912.0336-00	Air breather element	CG820
372	912.0330-00	Filter	CG820
373	912.0337-00	Filter element	CG820
374	912.0331-00	Clogging indicator	CG820
375	984.1613-00	Temperature transmitter	CG820
376	984.1503-00	Temperature transmitter	CG820
377	984.1614-00	Temperature transmitter	CG820
378	984.1615-00	Flow transmitter	CG820

379	967.0186-00	Proximity switch	CG820
380	910.0168-00	Cooler	CG820
381	902.1109-00	Control valve	CG820
382	902.1110-00	Actuator	CG820
383	912.0332-00	Filter	CG820
384	902.1126-00	Check valve	CG820
385	910.0173-00	Air-oil cooler	CG820
386	972.1258-00	Motor	CG820
387	902.1126-00	Check valve	CG820
388	912.0322-00	Air breather	CG820
389	900.3064-00	Reducer	CG820
390	873.0386-00	Seal ring	CG820
391	914.0225-00	Grease pump	CG820
392	900.1538-00	Elbow adapter	CG820
393	873.0382-00	Seal tread	CG820
394	900.2243-00	Adapter hexagon socket	CG820
395	873.0384-00	Seal tread	CG820
396	900.2519-00	Adapter	CG820
397	964.2645-00	Connector	CG820
398	984.1645-00	Ultrasonic sensor	CG820
399	BG00978409	Spider assembly	CG830
400	BG01068133	Spider	CG830
401	454.1338-901	Spherical bearing	CG830
402	842.0314-00	Screw	CG830
403	BG01011136	Spider cap	CG830
404	BG01011179	Pin - spider cap	CG830
405	873.1432-00	O-ring	CG830
406	BG01014183	Bolt spider/upper top shell	CG830
407	BG01014382	Stud spider/upper top shell	CG830
408	454.1026-001	Bushing - spherical bearing	CG830
409	847.0350-00	Tab washer	CG830
410	840.0047-00	Screw	CG830
411	BG01011195	Retainer - spherical bearing	CG830
412	BG01012875	Special washer	CG830
413	873.1433-00	O-ring	CG830
414	841.0598-00	Screw	CG830
415	BG01013036	Holder-grease seal	CG830
416	454.1032-001	Pin - oil seal holder	CG830

417	454.1461-001	Seal - spherical bearing	CG830
418	454.1025-001	Scraper - spherical bearing	CG830
419	BG01070990	Arm shield - spider arm	CG830
420	BG01070997	Arm shield, spider arm	CG830
421	454.1484-001	Pin	CG830
422	BG01013124	Square head bolt - spider arm	CG830
		shield	
423	454.1480-001	Spring seat - spider arm shield	CG830
424	BG01013123	Spring - spider arm shield	CG830
425	BG01013749	Cover - automatic lubrication	CG830
426	BG01065836	Liner set - spider rim	CG830
427	BG01013630	Square head bolt - rim liner	CG830
428	BG01065838	Liner	CG830
429	BG01065839	Liner	CG830
430	BG01065840	Liner	CG830
431	BG01669223	Seal	CG830
432	454.1484-001	Pin	CG830
433	BG01013749	Cover automatic lubrication	CG830
434	BG01013649	Cover, spherical bearing	CG830
435	BG01014043	Holder, grease level sensor	CG830
436	BG01013825	Holder, grease level sensor	CG830
437	847.0351-00	Washer	CG830
438	840.0649-00	Screw	CG830
439	900.0717-00	Plug, filter	CG830
440	873.1562-00	O-ring	CG830
441	BG01013787	Sensor, temperature	CG830
442	454.3522-001	Grease level sensor	CG830
443	964.3194-00	Gland	CG830
444	BG00978384	Top shell assembly	CG830
445	BG01048244	Top shell upper	CG830
446	BG01048245	Top shell lower	CG830
447	BG01045685	Ring, support, concave set	CG830
448	BG01047669	Shim	CG830
449	BG01047675	Shim	CG830
450	831.0016-00	Compound, casting	CG830
451	454.1491-001	Shim	CG830
452	BG01047809	Concave set	CG830
453	BG01048061	Concave set	CG830

454	BG01048089	Concave set	CG830
455	BG01048108	Concave set	CG830
456	BG00978384	Top shell assembly	CG830
457	BG01044658	Bolt	CG830
458	BG01046281	Screw, retainer	CG830
459	BG01047241	Screw, retainer	CG830
460	454.2391-001	Screw, Jack	CG830
461	831.0016-00	Casting compound	CG830
462	BG01047809	Concave set	CG830
463	BG01047812	Key concave	CG830
464	BG01047816	Transition concave left	CG830
465	BG01047820	Transition concave right	CG830
466	BG01047826	Concave	CG830
467	BG01048061	Concave set	CG830
468	BG01048066	Key concave	CG830
469	BG01048070	bolt concave	CG830
470	BG01048073	bolt concave	CG830
471	BG01048089	Concave set	CG830
472	BG01048091	Key concave	CG830
473	BG01048094	Concave	CG830
474	BG01048108	Concave set	CG830
475	BG01048111	Key concave	CG830
476	BG01048113	bolt concave	CG830
477	BG01048120	bolt concave	CG830
478	BG00978427	Main shaft assembly	CG830
479	BG00997757	Main shaft	CG830
480	BG00997806	Mantle set	CG830
481	BG00997807	Upper mantle	CG830
482	BG00997810	Lower mantle	CG830
483	BG01002164	Sleeve, main shaft	CG830
484	BG00998055	Collar, threaded - main shaft	CG830
485	BG00998059	Head nut	CG830
486	BG01003817	Washer, special	CG830
487	899.0546-00	Hoist ring	CG830
488	BG00998121	Ring, burning	CG830
489	BG00998128	Stopper - main shaft sleeve	CG830
490	BG00998153	Holder - dust seal ring	CG830
491	BG00998161	Retainer - dust seal ring	CG830

492	840.1231-00	Screw	CG830
493	840.1050-00	Screw	CG830
494	840.1080-00	Screw	CG830
495	BG01003865	Dust seal ring	CG830
496	454.1569-001	Pin, locking	CG830
497	841.0599-00	Screw	CG830
498	847.0199-00	Washer, spring FBB 36,5x56,5	CG830
499	BG01003851	Washer, special	CG830
500	BG01004319	Wire aluminum	CG830
501	831.0016-00	Compound, casting	CG830
502	831.0082-00	Compound, sealing sikasil	CG830
503	BG00998404	Oil set, splash curtain	CG830
504	BG00998262	Ring, protecting - main shaft	CG830
505	841.0596-00	Screw	CG830
506	900.2973-00	Plug	CG830
507	BG00978427	Main shaft assembly	CG830
508	BG00997757	Main shaft	CG830
509	BG00997806	Mantle set	CG830
510	BG00997807	Upper mantle	CG830
511	BG00997810	Lower mantle	CG830
512	BG01002164	Sleeve, main shaft	CG830
513	BG00998055	Collar, threaded - main shaft	CG830
514	BG00998059	Head nut	CG830
515	BG01003817	Washer, special	CG830
516	899.0546-00	Hoist ring	CG830
517	BG00998121	Ring, burning	CG830
518	BG00998128	Stopper - main shaft sleeve	CG830
519	BG00998153	Holder - dust seal ring	CG830
520	BG00998161	Retainer - dust seal ring	CG830
521	840.1231-00	Screw	CG830
522	840.1050-00	Screw	CG830
523	840.1080-00	Screw	CG830
524	BG01003865	Dust seal ring	CG830
525	454.1569-001	Pin, locking	CG830
526	841.0599-00	Screw	CG830
527	847.0199-00	Washer, spring	CG830
528	BG01003851	Washer, special	CG830
529	BG01004319	Wire aluminum	CG830

530	831.0016-00	Compound, casting	CG830
531	831.0082-00	Compound, sealing sikasil	CG830
532	BG00998404	Oil set, splash curtain	CG830
533	BG00998262	Ring, protecting - main shaft	CG830
534	841.0596-00	Screw	CG830
535	900.2973-00	Plug R	CG830
536	BG00978380	Bottom shell assembly	CG830
537	BG01059553	Bottom shell	CG830
538	BG01019173	Dust collar	CG830
539	454.1130-001	Retainer - oil splash ring	CG830
540	454.1131-001	Washer, Special	CG830
541	841.0602-00	Screw	CG830
542	847.0199-00	Washer, spring	CG830
543	873.1428-00	O-Ring	CG830
544	840.1169-00	Screw	CG830
545	BG01020352	Stopper rubber	CG830
546	BG01019069	Splash ring, oil	CG830
547	BG01027042	Liner set - bottom shell frame	CG830
548	BG01023341	Liner set - bottom shell hub	CG830
549	454.1133-001	Bushing, bottom shell	CG830
550	454.1134-001	Key - bottom shell bushing	CG830
551	454.2054-001	Countersunk head bolt	CG830
552	454.2056-001	Washer	CG830
553	845.0221-00	Nut	CG830
554	840.1232-00	Screw	CG830
555	847.0341-00	Washer	CG830
556	847.0200-00	Washer, spring	CG830
557	840.0710-00	Screw	CG830
558	847.0352-00	Washer, tab 2L 37 FZB	CG830
559	BG01020361	Pipe - air transfer S355J2H	CG830
560	BG01020571	Liner - pinionshaft arm	CG830
561	BG01022595	Piece, mounting - liner	CG830
562	BG01020439	Liner - narrow arm	CG830
563	BG01022969	Piece, mounting - liner	CG830
564	BG01022587	Piece, mounting - liner	CG830
565	BG01043234	Piping, air oil inlet	CG830
566	BG01042004	Piping, oil inlet	CG830
567	900.0216-00	Plug	CG830

568	840.1278-00	Screw	CG830
569	BG01063059	Gasket Aramid fibres	CG830
570	840.0068-00	Screw	CG830
571	847.0036-00	Washer, Spring	CG830
572	BG01043747	Pipe - return oil outlet	CG830
573	BG00978380	Bottom shell assembly	CG830
574	BG01059553	Bottom shell	CG830
575	BG01019173	Dust collar	CG830
576	454.1130-001	Retainer - oil splash ring	CG830
577	454.1131-001	Washer, Special	CG830
578	841.0602-00	Screw	CG830
579	847.0199-00	Washer, spring	CG830
580	873.1428-00	O-Ring	CG830
581	840.1169-00	Screw	CG830
582	BG01020352	Stopper rubber	CG830
583	BG01019069	Splash ring, oil	CG830
584	BG01027042	Liner set - bottom shell frame	CG830
585	BG01023341	Liner set - bottom shell hub	CG830
586	454.1133-001	Bushing, bottom shell	CG830
587	454.1134-001	Key - bottom shell bushing	CG830
588	454.2054-001	Countersunk head bolt	CG830
589	454.2056-001	Washer	CG830
590	845.0221-00	Nut	CG830
591	840.1232-00	Screw	CG830
592	847.0341-00	Washer	CG830
593	847.0200-00	Washer, spring	CG830
594	840.0710-00	Screw	CG830
595	847.0352-00	Washer, tab	CG830
596	BG01020361	Pipe - air transfer	CG830
597	BG01020571	Liner - pinionshaft arm	CG830
598	BG01022595	Piece, mounting - liner	CG830
599	BG01020439	Liner - narrow arm	CG830
600	BG01022969	Piece, mounting - liner	CG830
601	BG01022587	Piece, mounting - liner	CG830
602	BG01043234	Piping, air oil inlet	CG830
603	BG01042004	Piping, oil inlet	CG830
604	900.0216-00	Plug	CG830
605	840.1278-00	Screw	CG830

606	BG01063059	Gasket Aramid fibres	CG830
		NBR binder	
607	840.0068-00	Screw	CG830
608	847.0036-00	Washer, Spring	CG830
609	BG01043747	Pipe	CG830
610	BG01043747	Pipe	CG830
611	BG01043756	Pipe	CG830
612	BG01043757	Flange	CG830
613	454.5843-001	Seal	CG830
614	845.0009-00	Nut	CG830
615	840.0070-00	Screw	CG830
616	BG01043234	Pipe - air oil outlet	CG830
617	BG01042080	Piping	CG830
618	873.1483-00	O-ring	CG830
619	454.3969-001	Flange	CG830
620	847.0040-00	Spring washer	CG830
621	840.0668-00	Screw	CG830
622	454.3970-001	Rubber gasket	CG830
623	BG01042004	Piping - oil inlet	CG830
624	BG01042080	Piping	CG830
625	873.1483-00	O-ring	CG830
626	454.3969-001	Flange	CG830
627	847.0040-00	Spring washer	CG830
628	840.0668-00	Screw	CG830
629	454.3970-001	Rubber gasket	CG830
630	900.3302-00	O-ring	CG830
631	841.0271-00	Screw	CG830
632	873.1295-00	O-ring	CG830
633	BG00978436	Eccentric assembly	CG830
634	BG00979455	Eccentric support plate	CG830
635	454.1436-001	Eccentric wear plate	CG830
636	BG00981206	Eccentric with key	CG830
637	BG00979686	Eccentric bushing	CG830
638	454.1438-001	Key - spiral bevel gear	CG830
639	BG00979800	Gear and pinion set	CG830
640	841.0593-00	Screw	CG830
641	847.0199-00	Washer, Spring	CG830
642	841.0594-00	Screw	CG830

643	873.1700-00	O-ring	CG830
644	841.0596-00	Screw	CG830
645	841.0601-00	Screw	CG830
646	847.0046-00	Washer, spring	CG830
647	BG00979399	Counterweight lower	CG830
648	840.1267-00	Screw	CG830
649	873.1701-00	O-ring	CG830
650	BG00978394	Pinion shaft housing assembly	CG830
651	BG00985217	Pinion shaft housing	CG830
652	BG00986360	Shaft, drive	CG830
653	BG00986403	Cover, bearing -pinion end	CG830
654	BG00987264	Cover, bearing -coupling side	CG830
655	873.1704-00	O-ring	CG830
656	BG00987398	Spacer -coupling side	CG830
657	873.1705-00	O-ring	CG830
658	454.1143-001	Collar, labyrinth	CG830
659	454.1145-001	Washer, special	CG830
660	454.1146-001	Ring, adjustment for backlash	CG830
661	454.1147-001	Key, parallel	CG830
662	454.1144-001	Retainer-pinion end	CG830
663	840.1236-00	Screw	CG830
664	840.1233-00	Screw	CG830
665	847.0026-00	Washer	CG830
666	840.1041-00	Screw	CG830
667	840.1235-00	Screw	CG830
668	454.1140-001	Washer, special	CG830
669	454.1351-001	Bearing	CG830
670	873.1029-00	Ring	CG830
671	873.1427-00	Ring, seal, oil	CG830
672	873.1441-00	Ring	CG830
673	873.1430-00	O-ring	CG830
674	873.1431-00	O-ring	CG830
675	845.0419-00	Nut, lock	CG830
676	899.0486-00	Clip, locking	CG830
677	454.1362-001	Key, parallel	CG830
678	842.0230-00	Screw	CG830
679	454.1343-001	Bearing	CG830
680	900.0142-00	Bushing	CG830

681	900.0717-00	Plug, filter	CG830
682	900.0212-00	Plug	CG830
683	454.5833-901	Pipe, pressure	CG830
684	873.0386-00	Ring, Seal	CG830
685	914.0221-00	Gauge, oil level	CG830
686	873.1702-00	Seal ring type	CG830
687	964.2506-00	Reducer	CG830
688	964.2444-00	Gland skin top	CG830
689	900.2967-00	Plug	CG830
690	984.1747-00	Sensor, temperature bearing Pt100	CG830
691	984.1748-00	Sensor, temperature bearing	CG830
692	BG00741332	Clamp cable	CG830
693	984.0217-00	Rotation sensor	CG830
694	BG00978394	Pinion shaft housing assembly	CG830
695	BG00985217	Pinion shaft housing	CG830
696	BG00986360	Shaft, drive	CG830
697	BG00986403	Cover, bearing -pinion end	CG830
698	BG00987264	Cover, bearing -coupling side	CG830
699	873.1704-00	O-ring	CG830
700	BG00987398	Spacer -coupling side	CG830
701	873.1705-00	O-ring	CG830
702	454.1143-001	Collar, labyrinth	CG830
703	454.1145-001	Washer, special	CG830
704	454.1146-001	Ring, adjustment for backlash	CG830
705	454.1147-001	Key, parallel	CG830
706	454.1144-001	Retainer	CG830
707	840.1236-00	Screw	CG830
708	840.1233-00	Screw	CG830
709	847.0026-00	Washer	CG830
710	840.1041-00	Screw	CG830
711	840.1235-00	Screw	CG830
712	454.1140-001	Washer, special	CG830
713	454.1351-001	Bearing	CG830
714	873.1029-00	Ring	CG830
715	873.1427-00	Ring, seal, oil	CG830
716	873.1441-00	Ring	CG830
717	873.1430-00	O-ring	CG830
718	873.1431-00	O-ring	CG830

719	845.0419-00	Nut, lock	CG830
720	899.0486-00	Clip, locking	CG830
721	454.1362-001	Key, parallel	CG830
722	842.0230-00	Screw	CG830
723	454.1343-001	Bearing	CG830
724	900.0142-00	Bushing	CG830
725	900.0717-00	Plug, filter	CG830
726	900.0212-00	Plug	CG830
727	454.5833-901	Pipe, pressure	CG830
728	873.0386-00	Ring, Seal	CG830
729	914.0221-00	Gauge, oil level	CG830
730	873.1702-00	Seal ring type	CG830
731	964.2506-00	Reducer	CG830
732	964.2444-00	Gland skin top	CG830
733	900.2967-00	Plug	CG830
734	984.1747-00	Sensor, temperature bearing	CG830
735	984.1748-00	Sensor, temperature bearing Pt100	CG830
736	BG00741332	Clamp cable	CG830
737	BG00978417	Hydroset cylinder assembly	CG830
738	BG00989527	Cylinder, Hydroset	CG830
739	BG00993054	Bearing, thrust set	CG830
740	BG00991253	Piston -Hydroset	CG830
741	BG00991964	Bushing, guide	CG830
742	454.1408-001	Ring, backup	CG830
743	454.1407-001	Scraper	CG830
744	454.1152-001	Plate, retainer	CG830
745	454.1153-001	Washer, special	CG830
746	840.0068-00	Screw	CG830
747	BG00992105	Adapter, concave	CG830
748	454.1375-901	Seal	CG830
749	BG00992449	Adapter, convex	CG830
750	454.1405-001	Shim	CG830
751	454.5831-001	Shim	CG830
752	454.5832-001	Shim	CG830
753	454.1149-001	Stopper V-packing	CG830
754	454.1406-001	Washer, special	CG830
755	840.0066-00	Screw	CG830
756	873.1436-00	O-ring	CG830

757	BG00991042	Cover	CG830
758	BG00993913	Bolt -Hydroset cylinder cover	CG830
759	BG01010469	Elbow	CG830
760	873.1706-00	O-ring	CG830
761	900.2292-00	Test point	CG830
762	873.1489-00	O-ring	CG830
763	BG00992474	Stopper - Hydroset piston	CG830
764	454.1151-001	piston wearing plate	CG830
765	847.0042-00	Washer, spring	CG830
766	841.0673-00	Screw	CG830
767	873.0778-00	O-ring	CG830
768	454.3639-901	Retainer	CG830
769	454.3051-001	Washer, special	CG830
770	873.0111-00	O-ring	CG830
771	984.0476-00	Sensor, position	CG830
772	841.0239-00	Screw	CG830
773	452.1427-001	Protection	CG830
774	847.0016-00	Washer	CG830
775	840.0065-00	Screw	CG830
776	873.1435-00	O-ring	CG830
777	BG00993720	Hydroset cylinder	CG830
778	BG00994918	Protection segment	CG830
779	BG00994918	Protection segment	CG830
780	847.0036-00	Washer, spring	CG830
781	845.0009-00	Nut	CG830
782	900.3298-00	Flange	CG830
783	BG01004014	Washer, special	CG830
784	840.1349-00	Screw	CG830
785	873.1509-00	O-ring	CG830
786	841.0286-00	Screw	CG830
787	BG01099081	Flange square	CG830
788	841.0611-00	Screw	CG830
789	BG00978417	Hydroset cylinder assembly	CG830
790	BG00989527	Cylinder, Hydroset	CG830
791	BG00993054	Bearing, thrust set	CG830
792	BG00991253	Piston -Hydroset	CG830
793	BG00991964	Bushing, guide	CG830
794	454.1408-001	Ring, backup	CG830

795	454.1407-001	Scraper	CG830
796	454.1152-001	Plate, retainer	CG830
797	454.1153-001	Washer, special	CG830
798	840.0068-00	Screw	CG830
799	BG00992105	Adapter, concave	CG830
800	454.1375-901	Seal	CG830
801	BG00992449	Adapter, convex	CG830
802	454.1405-001	Shim	CG830
803	454.5831-001	Shim	CG830
804	454.5832-001	Shim	CG830
805	454.1149-001	Stopper V-packing	CG830
806	454.1406-001	Washer, special	CG830
807	840.0066-00	Screw	CG830
808	873.1436-00	O-ring	CG830
809	BG00991042	Cover	CG830
810	BG00993913	Bolt -Hydroset cylinder cover	CG830
811	BG01010469	Elbow	CG830
812	873.1706-00	O-ring	CG830
813	900.2292-00	Test point	CG830
814	873.1489-00	O-ring	CG830
815	BG00992474	Stopper - Hydroset piston	CG830
816	454.1151-001	Pin -piston wearing plate	CG830
817	847.0042-00	Washer, spring FBB 32,3x48,3	CG830
818	841.0673-00	Screw	CG830
819	873.0778-00	O-ring	CG830
820	454.3639-901	Retainer	CG830
821	454.3051-001	Washer, special	CG830
822	873.0111-00	O-ring	CG830
823	984.0476-00	Sensor, position 630 mm, 5-pin	CG830
824	841.0239-00	Screw	CG830
825	452.1427-001	Protection	CG830
826	847.0016-00	Washer	CG830
827	840.0065-00	Screw	CG830
828	873.1435-00	O-ring	CG830
829	BG00993720	Stud -Hydroset cylinder	CG830
830	BG00994918	Protection segment	CG830
831	BG00994918	Protection segment	CG830
832	847.0036-00	Washer, spring	CG830

833	845.0009-00	Nut	CG830
834	900.3298-00	Flange with o-ring groove	CG830
835	BG01004014	Washer, special	CG830
836	840.1349-00	Screw	CG830
837	873.1509-00	O-ring	CG830
838	841.0286-00	Screw	CG830
839	BG01099081	Flange square	CG830
840	841.0611-00	Screw	CG830
841	BG00993720	Hydroset cylinder	CG830
842	BG00993719	Stud Hydroset cylinder	CG830
843	847.0386-00	Washer	CG830
844	845.0342-00	Nut	CG830
845	BG00993723	Cover weldment	CG830
846	BG01154505	Board, signs	CG830
847	126.0383-001	Sign, Warning Risk of crushing	CG830
848	126.0384-001	Sign, Warning Flying Fragments	CG830
849	BG01129066	Product, Sign	CG830
850	126.5007-01	Identification Plate	CG830
851	126.0385-001	Sign, Mandatory Read Manual	CG830
852	885.0267-00	Sign, Warning Danger	CG830
853	126.0450-001	Sign, Warning Hot Surfaces	CG830
854	126.0700-002	Sign, Information Rotation Direction	CG830
855	BG01129915	Sign, Sandvik White	CG830
856	BG01171743	Hydraulic Jacks	CG830
857	BG01171488	Hydraulic Cylinder	CG830
858	BG01171494	Hydraulic Manifold	CG830
859	BG01171712	Hose	CG830
860	BG01171462	Hose	CG830
861	BG01172147	Pump, Hand, Hydraulic P801	CG830
862	BG01172164	Pressure gauge with holder	CG830
863	BG01172171	Hose	CG830
864	454.4098-901	Dust seal air pressure unit	CG830
865	900.2809-00	Hose coupling hose	CG830
866	454.5390-901	Air filter	CG830
867	900.1722-00	Hose clip	CG830
868	906.0609-00	Dust seal air pressure fan	CG830
869	BG01122138	Dust seal air pressure connection	CG830
870	900.3040-00	Fitting cross	CG830

871	900.2515-00	Bushing	CG830
872	900.3043-00	Bushing	CG830
873	923.0535-00	Gauge, pressure	CG830
874	984.1589-00	Transmitter, pressure	CG830
875	900.0176-00	Nipple, hexagon	CG830
876	900.3041-00	Coupling, hose	CG830
877	819.0231-00	Hose	CG830
878	900.1266-00	Pipe	CG830
879	902.1107-00	Valve	CG830
880	819.0231-00	Hose	CG830
881	900.1722-00	Clip, hose	CG830
882	900.0659-00	Adapter	CG830
883	900.3157-00	Flange	CG830
884	841.0269-00	Screw	CG830
885	873.1295-00	O-Ring	CG830
886	454.5390-901	Air filter	CG830
887	899.0483-00	Mounting band	CG830
888	912.0262-00	Air cleaner connection	CG830
889	900.2806-00	Reducer	CG830
890	900.3042-001	Reducer, bushing	CG830
891	912.0261-00	Top spin	CG830
892	900.2804-00	Clamp	CG830
893	900.2807-00	Clamp	CG830
894	912.0363-00	Air filter kit	CG830
895	914.0404-00	Main element	CG830
896	900.2084-00	Clamping ring	CG830
897	923.0539-00	Thermostat	CG830
898	902.1112-00	Check valve	CG830
899	902.1113-00	Pressure relief valve	CG830
900	902.1114-00	Coil 24	CG830
901	923.0540-00	Pressure gauge	CG830
902	902.1115-00	Directional valve	CG830
903	902.1116-00	Manifold	CG830
904	912.0334-00	Return filter	CG830
905	912.0338-00	Filter element	CG830
906	912.0335-00	Clogging indicator	CG830
907	984.1648-00	Level switch	CG830
908	972.1261-00	Electric motor	CG830

909	930.0389-00	Spider	CG830
910	923.0548-00	Level gauge	CG830
911	912.0333-00	Air breather	CG830
912	912.0336-00	Air breather element	CG830
913	984.1611-00	Heater	CG830
914	902.1111-00	Ball valve	CG830
915	906.0629-00	Pump	CG830
916	930.0429-00	Coupling	CG830
917	BG01127759	Balance cylinder module	CG830
918	984.1619-00	Pressure transmitter	CG830
919	902.1120-00	Valve	CG830
920	923.0541-00	Pressure gauge	CG830
921	984.1504-00	Pressure transmitter	CG830
922	902.1118-00	Safety valve	CG830
923	902.1119-00	Slow return valve	CG830
924	873.1538-01	Seal ring	CG830
925	855.0229-00	Retain ring	CG830
926	BG01271442	Balance cylinder seal kit	CG830
927	873.1492-00	O-ring	CG830
928	873.1493-00	O-ring	CG830
929	873.1537-00	Seal ring	CG830
930	873.1534-00	Seal ring	CG830
931	900.3061-00	Measuring nipple	CG830
932	984.1610-00	Level gauge	CG830
933	984.1611-00	Heater	CG830
934	984.1612-00	Temperature transmitter,	CG830
935	454.5744-901	Repair kit	CG830
936	972.1257-00	Motor	CG830
937	930.0389-00	Spider	CG830
938	906.0628-00	Pump	CG830
939	902.1108-00	Check valve	CG830
940	984.1630-00	Level transmitter	CG830
941	902.1125-00	Motor valve	CG830
942	930.0429-00	Coupling	CG830
943	912.0274-00	Filter cartridge	CG830
944	912.0331-00	Clogging indicator	CG830
945	984.1613-00	Temperature transmitter	CG830
946	984.1503-00	Temperature transducer	CG830

947	984.1614-00	Temperature transmitter	CG830
948	984.1615-00	Flow transmitter	CG830
949	967.0186-00	Proximity switch	CG830
950	910.0172-00	Cooler	CG830
951	902.1109-00	Control valve	CG830
952	912.0332-00	Filter, bronze	CG830
953	926.1126-00	Check valve	CG830
954	910.0208-00	Air-oil cooler	CG830
955	972.1258-00	Motor,	CG830
956	BG01077454	Hose	CG830
957	BG01075224	Hose	CG830
958	454.6001-901	Greasing unit, spherical bearing	CG830
959	914.0237-00	Grease pump	CG830
960	900.0654-00	Adapter	CG830
961	900.1538-00	Adapter	CG830
962	873.0382-00	Ring, Seal Tredo	CG830
963	454.5662-001	Hydraulic hose	CG830
964	454.5663-001	Hydraulic hose	CG830
965	900.2519-00	Adapter	CG830
966	964.2645-00	Connector, Pre-wired, Female	CG830
967	873.0384-00	Ring, Seal Tredo	CG830
968	984.1645-00	Ultrasonic sensor	CG830
969	914.0239-00	Pump element	CG830
970	912.0363-00	Air filter kit	CG830
971	912.0338-00	Filter element, Hydroset tank	CG830
972	912.0336-00	Filter element, Lubrication tank	CG830
973	BG00997807	Upper mantle	CG830
974	BG00997810	Lower mantle	CG830
975	831.0016-00	Casting compound	CG830
976	BG01047809	Concave set	CG830
977	BG01048061	Concave set	CG830
978	BG01048089	Concave set	CG830
979	BG01048108	Concave set	CG830
980	831.0016-00	Casting compound	CG830
981	454.1461-001	Seal - Spherical bearing	CG830
982	454.1025-001	Scraper - Spherical bearing	CG830
983	454.1026-001	Bushing - Spherical bearing	CG830
984	BG01070990	Arm shield - spider arm	CG830

985	BG01013124	Square head bolt - spider arm shield	CG830
986	BG01011136	Spider Cap	CG830
987	873.1432-00	O-ring	CG830
988	BG01014183	Bolt spider/upper top shell	CG830
989	BG01014382	Stud spider/upper top shell	CG830
990	454.3522-001	Grease level sensor	CG830
991	BG01013787	Sensor, temperature	CG830
992	BG01045685	Ring, support, concave set	CG830
993	BG01046281	Screw, Retainer	CG830
994	BG01047241	Screw, Retainer, Row	CG830
995	BG01002164	Sleeve, main shaft	CG830
996	BG00998262	Ring, protecting - main shaft	CG830
997	841.0596-00	Screw	CG830
998	900.2973-00	Plug	CG830
999	BG00998059	Head nut	CG830
1000	454.1569-001	Pin, locking	CG830
1001	BG01003865	Dust seal ring	CG830
1002	BG00998404	Oil set, splash curtain	CG830
1003	BG00998055	Collar, threaded	CG830
1004	BG00998121	Burning ring	CG830
1005	BG01004319	Wire Aluminium	CG830
1006	454.1133-001	Bushing, bottom shell	CG830
1007	454.1134-001	Key - bottom shell bushing	CG830
1008	BG01020439	Liner - narrow arm	CG830
1009	BG01020571	Liner - pinionshaft arm	CG830
1010	BG01019069	Oil splash ring	CG830
1011	BG00979686	Eccentric bushing	CG830
1012	454.1436-001	Eccentric wear plate	CG830
1013	BG00979800	Gear and pinion set	CG830
1014	873.1700-00	O-ring	CG830
1015	873.1701-00	O-ring	CG830
1016	BG00986360	Shaft, drive	CG830
1017	BG00986403	Cover, bearing -pinion end	CG830
1018	873.1029-00	Ring	CG830
1019	873.1431-00	O-ring	CG830
1020	BG00987264	Cover, bearing -coupling side	CG830
1021	873.1441-00	Ring	CG830
1022	873.1427-00	Ring, seal, oil	CG830

1023	454.1351-001	Bearing	CG830
1024	454.1343-001	Bearing	CG830
1025	984.1747-00	Sensor, temperature bearing	CG830
1026	984.1748-00	Sensor, temperature bearing	CG830
1027	984.0217-00	Rotation sensor	CG830
1028	873.1430-00	O-ring	CG830
1029	873.1704-00	O-ring	CG830
1030	873.1705-00	O-ring	CG830
1031	984.1747-01	Ring, seal, oil	CG830
1032	873.1435-00	O-ring	CG830
1033	BG00992105	Adapter, concave	CG830
1034	BG00992449	Adapter, convex	CG830
1035	454.1375-901	Seal	CG830
1036	454.1407-001	Scraper	CG830
1037	454.1408-001	Ring, backup	CG830
1038	BG00993054	Bearing, thrust set	CG830
1039	873.1436-00	O-ring	CG830
1040	984.0476-00	Sensor, position	CG830
1041	873.1706-00	O-ring	CG830
1042	902.1113-00	Pressure relief valve	CG830
1043	902.1114-00	Coil	CG830
1044	902.1115-00	Directional vavle	CG830
1045	902.1116-00	Manifold	CG830
1046	984.1648-00	Level switch	CG830
1047	930-0389-00	Spider	CG830
1048	906.0629-00	Pump	CG830
1049	984.1619-00	Pressure transmitter	CG830
1050	984.1504-00	Pressure transmitter	CG830
1051	902.1118-00	Safety valve	CG830
1052	873.1492-00	O-ring	CG830
1053	873.1493-00	O-ring	CG830
1054	873.1537-00	Seal ring	CG830
1055	873.1534-00	Seal ring	CG830
1056	BG01241442	Balance cylinder seal kit	CG830
1057	984.1611-00	Heater	CG830
1058	984.1612-00	Temperature transmitter	CG830
1059	454.5744-901	Repair kit	CG830
1060	902.1108-00	Check valve	CG830

1061	984.1630-00	Level transmitter	CG830
1062	902.1125-00	Motor valve	CG830
1063	984.1008-00	Liquid Level switch	CG830
1064	912.0331-00	Clogging indicator	CG830
1065	984.1613-00	Temperature transmitter	CG830
1066	984.1503-00	Temperature transmitter	CG830
1067	984.1614-00	Temperature transmitter	CG830
1068	984.1615-00	Flow transmitter	CG830
1069	967.0186-00	Proximity switch	CG830
1070	902.1109-00	Control valve	CG830
1071	902.1110-00	Actuator	CG830
1072	972.1258-00	Motor	CG830
1073	984.1645-00	Ultrasonic sensor	CG830
1074	914.0239-00	Pump element	CG830
1075	454.2985-901	Spider	CG850
1076	454.2874-901	Spider Bearing Liner	CG850
1077	454.2532-901	Spherical bearing	CG850
1078	847.0038-00	Spring washer	CG850
1079	841.0623-00	Screw	CG850
1080	454.3118-001	Retainer-Spherical bearing	CG850
1081	454.3119-001	Special washer	CG850
1082	841.0598-00	Screw	CG850
1083	842.0314-00	Screw	CG850
1084	454.3124-001	Holder-Grease seal	CG850
1085	454.3129-001	Seal-Spherical bearing	CG850
1086	454.3097-001	Pin-Oil seal holder	CG850
1087	454.3108-001	Scraper-Spherical bearing	CG850
1088	454.2718-001	Spider cap	CG850
1089	454.3136-001	Pin-Spider cap	CG850
1090	873.1481-00	O-ring	CG850
1091	454.3028-001	Liner - Spider arm	CG850
1092	454.3029-001	Pin - Spider arm liner	CG850
1093	454.2721-901	Bolt Spider/Upper Topshell	CG850
1094	454.2744-901	Stud Spider/Upper Topshell	CG850
1095	454.3134-901	Square head bolt - rim liner	CG850
1096	863.0071-00	Disc spring	CG850
1097	454.3122-001	Bushing - Spherical bearing	CG850
1098	847.0350-00	Tab washer	CG850

1099	840.0047-00	Screw	CG850
1100	454.3132-901	Square head bolt - arm liner	CG850
1101	454.1480-001	Spring seat - Spider arm liner	CG850
1102	454.1478-001	Spring - Spider arm liner	CG850
1103	454.4008-901	Cover - Automatic Lub.	CG850
1104	873.1514-00	O-ring	CG850
1105	454.2864-901	Liner set - Spider rim	CG850
1106	454.2862-001	Pin - Spider rim liner	CG850
1107	454.2863-001	Packing - Spider rim liner	CG850
1108	454.2859-001	Liner - Spider rim	CG850
1109	454.2860-001	Liner - Spider rim	CG850
1110	454.2861-001	Liner - Spider rim	CG850
1111	454.2859-001	Liner - Spider rim	CG850
1112	454.2860-001	Liner - Spider rim	CG850
1113	454.2861-001	Liner - Spider rim	CG850
1114	454.2863-001	Packing - Spider rim liner	CG850
1115	454.2862-001	Pin - Spider rim liner	CG850
1116	454.4002-901	Cover Spherical bearing	CG850
1117	847.0351-00	Tab Washer	CG850
1118	940.0077-00	Screw	CG850
1119	873.1515-00	O-ring	CG850
1120	900.0717-00	Filter Plug	CG850
1121	454.4006-901	Holder - Grease seal sensor	CG850
1122	454.4007-901	Holder - Grease seal sensor	CG850
1123	454.3522-001	Indicating instrument - grease level	CG850
1124	454.5729-001	Temperature sensor	CG850
1125	454.3001-001	Topshell Lower	CG850
1126	454.2884-901	Bolt	CG850
1127	454.3366-001	Shim	CG850
1128	831.0016-00	Casting compound kg	CG850
1129	454.3935-901	Concave set - Row 1 assembly	CG850
1130	454.3685-901	Concave Row 1, Key	CG850
1131	454.3679-901	Concave Row	CG850
1132	454.3681-901	Concave Row	CG850
1133	454.4373-901	Concave Row	CG850
1134	454.3936-901	Concave Row	CG850
1135	454.3620-901	Concave Row, Key assembly	CG850
1136	454.3596-901	Concave Row	CG850

1137	454.3602-901	Concave Row	CG850
1138	454.3937-901	Concave set	CG850
1139	454.3622-901	Concave Row	CG850
1140	454.3617-901	Concave Row assembly	CG850
1141	454.3938-901	Concave set	CG850
1142	454.3605-901	Concave Row	CG850
1143	454.3609-901	Concave Row	CG850
1144	454.3607-901	Concave Row	CG850
1145	454.3399-901	Concave Row	CG850
1146	454.3365-901	Concave Row	CG850
1147	454.3365-901	Concave Row	CG850
1148	454.3365-901	Concave Row	CG850
1149	454.3413-901	Concave support ring set	CG850
1150	454.3411-001	Shim	CG850
1151	454.3412-001	Shim	CG850
1152	454.3628-001	Jack screw	CG850
1153	454.4338-001	Topshell with jacks	CG850
1154	454.4591-901	Hydraulic jack	CG850
1155	454.3095-001	Mainshaft	CG850
1156	454.3065-001	Mainshaft sleeve	CG850
1157	454.3035-001	Stopper - Mainshaft sleeve	CG850
1158	841.0629-00	Screw	CG850
1159	847.0199-00	Spring washer	CG850
1160	454.3064-001	Threaded collar - Mainshaft	CG850
1161	454.2750-001	Burning ring	CG850
1162	454.3427-001	Locking pin	CG850
1163	900.2973-00	Plug	CG850
1164	914.0093-00	Lubrication nipple	CG850
1165	454.4018-001	Wire Aluminium	CG850
1166	831.0082-00	Sealing compound Sikasil tran	CG850
1167	454.4210-001	Head nut	CG850
1168	454.3318-001	Holder - Dust seal ring	CG850
1169	454.3989-001	Washer	CG850
1170	454.3032-001	Retainer - Dust seal ring	CG850
1171	454.3320-001	Special washer	CG850
1172	840.1254-00	Screw	CG850
1173	840.1231-00	Screw	CG850
1174	454.4042-901	Oil splash curtain set	CG850

1175	840.1237-00	Screw	CG850
1176	454.3066-001	Dust seal ring	CG850
1177	454.3433-001	Pin - Mainshaft step	CG850
1178	454.3031-001	Retainer - Mainshaft step	CG850
1179	454.3069-001	Special washer	CG850
1180	840.1262-00	Screw	CG850
1181	454.4395-901	Mantle	CG850
1182	831.0016-00	Casting compound	CG850
1183	454.3033-001	Lifting eye bolt	CG850
1184	454.4211-901	Protective ring - Mainshaft	CG850
1185	841.0624-00	Screw	CG850
1186	841.0602-00	Screw	CG850
1187	847.0199-00	Spring washer	CG850
1188	454.2987-001	Bottomshell	CG850
1189	454.3564-901	Liner set - Bottomshell hub	CG850
1190	847.0026-00	Washer	CG850
1191	847.0200-00	Spring washer	CG850
1192	840.1250-00	Screw	CG850
1193	454.3979-001	Bottomshell bushing	CG850
1194	454.3981-001	Key - Bottomshell bushing	CG850
1195	847.0385-00	Tab washer	CG850
1196	840.0710-00	Screw	CG850
1197	900.0216-00	Plug	CG850
1198	454.3967-001	Gasket	CG850
1199	847.0138-00	Washer	CG850
1200	840.1266-00	Screw	CG850
1201	454.5570-901	Pipe - Return oil outlet	CG850
1202	454.3389-901	Dust collar	CG850
1203	454.3379-001	Retainer - Oil splash ring	CG850
1204	847.0199-00	Spring washer	CG850
1205	454.3378-001	Special washer	CG850
1206	840.1169-00	Screw	CG850
1207	873.1482-00	O-ring	CG850
1208	454.2713-001	Oil splash ring	CG850
1209	454.3377-001	Pipe guide	CG850
1210	454.4027-001	Pipe - Air transfer	CG850
1211	840.1278-00	Screw	CG850
1212	841.0602-00	Screw	CG850

1213	454.3588-901	Liner set - Bottomshell frame	CG850
1214	454.3965-001	Countersunk head bolt	CG850
1215	454.3587-001	Special washer	CG850
1216	845.0221-00	Nut	CG850
1217	847.0199-00	Spring washer	CG850
1218	454.3403-901	Liner - Narrow arm	CG850
1219	454.3407-901	Liner - Pinionshaft arm	CG850
1220	454.5537-901	Pipe - Air inlet	CG850
1221	454.5536-901	Pipe - Oil inlet	CG850
1222	454.3146-001	Eccentric support plate	CG850
1223	454.3289-001	Eccentric wearing plate	CG850
1224	454.4070-901	Eccentric with key Alt.	CG850
1225	454.3302-001	Eccentric bushing	CG850
1226	454.3337-901	Gear and pinion set	CG850
1227	454.3352-001	Key - Spiral bevel gear	CG850
1228	847.0199-00	Spring washer	CG850
1229	841.0616-00	Screw	CG850
1230	841.0617-00	Screw	CG850
1231	873.1484-00	O-ring	CG850
1232	841.0607-00	Screw	CG850
1233	847.0046-00	Spring washer	CG850
1234	841.0618-00	Screw	CG850
1235	454.3146-001	Eccentric support plate	CG850
1236	454.3289-001	Eccentric wearing plate	CG850
1237	454.4070-901	Eccentric with key Alt.	CG850
1238	454.3302-001	Eccentric bushing	CG850
1239	454.3337-901	Gear and pinion set	CG850
1240	454.3352-001	Key - Spiral bevel gear	CG850
1241	847.0199-00	Spring washer	CG850
1242	841.0616-00	Screw	CG850
1243	841.0617-00	Screw	CG850
1244	873.1484-00	O-ring	CG850
1245	841.0607-00	Screw	CG850
1246	847.0046-00	Spring washer	CG850
1247	841.0618-00	Screw	CG850
1248	454.3090-001	Pinionshaft	CG850
1249	845.0432-00	Lock nut	CG850
1250	899.0486-00	Locking clip	CG850

1251	840.0020-00	Screw	CG850
1252	847.0031-00	Spring washer	CG850
1253	454.3081-001	Spacer - Outer end	CG850
1254	454.3085-001	Labyrinth collar	CG850
1255	842.0230-00	Screw	CG850
1256	454.3083-001	Bearing cover - Pinion end	CG850
1257	873.1486-00	O-ring	CG850
1258	454.3950-001	Special washer	CG850
1259	873.0910-00	V-ring	CG850
1260	840.1235-00	Screw	CG850
1261	454.3072-001	Bearing cover - Outer end	CG850
1262	873.1486-00	O-ring	CG850
1263	847.0026-00	Washer	CG850
1264	873.1516-00	Oil seal ring	CG850
1265	873.1008-00	V-ring	CG850
1266	840.1041-00	Screw	CG850
1267	454.3086-001	Retainer - Pinion end	CG850
1268	454.3087-001	Special washer	CG850
1269	840.1265-00	Screw	CG850
1270	454.3082-001	Key	CG850
1271	454.3080-001	Spacer - Pinion end	CG850
1272	454.3953-001	Parallel key	CG850
1273	454.3955-901	Oil outlet - Overflow line	CG850
1274	454.3958-901	Piping	CG850
1275	902.0061-00	Ball valve	CG850
1276	900.3060-00	Adapter	CG850
1277	900.1262-00	L-adapter	CG850
1278	454.3968-001	Hose	CG850
1279	873.0386-00	Seal ring	CG850
1280	454.3987-001	Bearing	CG850
1281	454.3988-001	Bearing	CG850
1282	840.1234-00	Screw	CG850
1283	984.0217-00	Rotation sensor	CG850
1284	454.5538-901	Hydroset cylinder	CG850
1285	454.3179-901	Stud - Hydroset cylinder	CG850
1286	454.3643-001	Hydroset cylinder cover	CG850
1287	873.1487-00	O-ring	CG850
1288	873.1488-00	O-ring	CG850

1289	454.3194-901	Bolt - Hydroset cylinder cover	CG850
1290	454.3946-901	Step bearing set	CG850
1291	454.3641-001	Piston - Hydroset	CG850
1292	984.0476-00	Position sensor	CG850
1293	873.0111-00	O-ring	CG850
1294	841.0239-00	Screw	CG850
1295	454.3258-001	Guide bushing	CG850
1296	454.3266-001	Concave adapter	CG850
1297	454.3267-001	Convex adapter	CG850
1298	454.4087-901	V-packing	CG850
1299	454.3268-001	Shim	CG850
1300	454.3268-002	Shim	CG850
1301	454.3268-003	Shim	CG850
1302	454.3285-001	Stopper - V-packing	CG850
1303	454.3286-001	Special washer	CG850
1304	840.0066-00	Screw	CG850
1305	454.3431-001	Scraper	CG850
1306	454.3432-001	Back-up ring	CG850
1307	454.3426-001	Stopper - Hydroset piston	CG850
1308	873.1489-00	O-ring	CG850
1309	454.3387-001	Retaining plate	CG850
1310	454.3388-001	Special washer	CG850
1311	840.0068-00	Screw	CG850
1312	454.3217-901	Protection segment	CG850
1313	847.0036-00	Spring washer	CG850
1314	840.0065-00	Screw	CG850
1315	845.0009-00	Nut	CG850
1316	454.3154-001	Elbow	CG850
1317	873.1491-00	O-ring	CG850
1318	847.0199-00	Spring washer	CG850
1319	841.0595-00	Screw	CG850
1320	454.3323-001	Pin - Piston wearing plate	CG850
1321	900.2292-00	Measuring nipple	CG850
1322	452.1427-001	Protection	CG850
1323	840.0065-00	Screw	CG850
1324	847.0016-00	Washer	CG850
1325	454.3639-901	Retainer	CG850
1326	873.0778-00	O-ring	CG850

1327	454.3051-001	Special washer	CG850
1328	840.0066-00	Screw	CG850
1329	454.5525-001	Flange Welding	CG850
1330	454.5571-001	Packing	CG850
1331	847.0038-00	Spring washer	CG850
1332	840.0650-00	Screw	CG850
1333	126.0383-001	Risk of crushing	CG850
1334	126.0384-001	Warning flying fragments	CG850
1335	126.0446-001	SANDVIK logotype	CG850
1336	454.5441-001	Sign product name	CG850
1337	126.5007-01	Identification plate	CG850
1338	126.0385-001	Warning sign read manual	CG850
1339	885.0267-00	Warning sign Danger	CG850
1340	454.5450-001	Logotypy - spider cap	CG850
1341	126.0450-001	Warning sign, Hot surfaces	CG850
1342	126.0700-002	Sign rotation direction	CG850
1343	454.4590-901	Hydraulic jacks	CG850
1344	454.4589-901	Hydraulic jack Assembly	CG850
1345	454.4588-901	Hydraulic jack inc pump&hose	CG850
1346	454.4340-001	Retaining ring	CG850
1347	853.0117-00	Pin	CG850
1348	900.2809-00	Hose	CG850
1349	454.5390-901	Air filter	CG850
1350	900.1722-00	Hose clip	CG850
1351	906.0609-00	Overpressure fan	CG850
1352	819.0231-00	Hose	CG850
1353	454.5540-901	Overpressure connection	CG850
1354	454.5551-001	Flange gasket	CG850
1355	454.5545-901	Adapte	CG850
1356	847.0016-00	Washer	CG850
1357	840.0074-00	Screw	CG850
1358	845.0009-00	Nut	CG850
1359	454.5552-001	Packing	CG850
1360	847.0138-00	Washer	CG850
1361	840.0652-00	Screw	CG850
1362	845.0010-00	Nut	CG850
1363	900.3040-00	Fitting	CG850
1364	900.2515-00	Bushing	CG850

1365	900.3043-00	Bushing	CG850
1366	923.0535-00	Pressure gauge	CG850
1367	984.1589-00	Pressure transmitter	CG850
1368	900.3044-00	Fitting union	CG850
1369	902.1107-00	Valve	CG850
1370	900.3041-00	Hose coupling	CG850
1371	900.2315-00	Adapter	CG850
1372	454.5544-001	Flange Screwed	CG850
1373	899.0483-00	Mounting band	CG850
1374	912.0262-00	Air cleaner	CG850
1375	900.2806-00	Reducer	CG850
1376	900.3042-00	Reducer	CG850
1377	912.0261-00	Top spin	CG850
1378	900.2804-00	Clamp	CG850
1379	900.2807-00	Clamp	CG850
1380	912.0263-00	Air filter element	CG850
1381	900.2084-00	Clamping ring	CG850
1382	923.0539-00	Thermostat	CG850
1383	902.1112-00	Pilot operated check valve	CG850
1384	902.1113-00	Pressure relief valve	CG850
1385	902.1114-00	Coil	CG850
1386	923.0540-00	Pressure gauge	CG850
1387	902.1115-00	Directional valve	CG850
1388	902.1116-00	Manifold	CG850
1389	912.0334-00	Filter	CG850
1390	912.0338-00	Filter element	CG850
1391	912.0335-00	Clogging indicator	CG850
1392	984.0476-00	Level switch	CG850
1393	972.1261-00	Electric motor	CG850
1394	930.0389-00	Spider	CG850
1395	923.0548-00	Level gauge	CG850
1396	912.0333-00	Air breather	CG850
1397	912.0336-00	Air breather element	CG850
1398	984.1611-00	Heater	CG850
1399	902.1111-00	Ball valve	CG850
1400	906.0629-00	Pump	CG850
1401	984.1619-00	Pressure transmitter	CG850
1402	902.1120-00	Valve	CG850

1403	923.0541-00	Pressure gauge	CG850
1404	984.1504-00	Pressure transmitter	CG850
1405	923.0485-00	Safety valve	CG850
1406	454.2887-00	Slow return valve	CG850
1407	873.1538-01	Seal ring	CG850
1408	855.0229-00	Retain ring	CG850
1409	873.1492-00	O-ring	CG850
1410	873.1493-00	O-ring	CG850
1411	873.1537-00	Seal ring	CG850
1412	873.1534-00	Seal ring	CG850
1413	900.3061-00	Measuring nipple	CG850
1414	984.1610-00	Level gauge	CG850
1415	984.1611-00	Heater	CG850
1416	984.1612-00	Temperature transmitter	CG850
1417	454.5744-901	Repair kit	CG850
1418	972.1257-00	Electric motor	CG850
1419	930.0389-00	Spider	CG850
1420	906.0628-00	Pump	CG850
1421	902.1108-00	Check valve	CG850
1422	984.1134-00	Level transmitter	CG850
1423	902.1125-00	Motor valve	CG850
1424	984.1008-00	Level switch	CG850
1425	912.0333-00	Air breather	CG850
1426	912.0336-00	Air breather element	CG850
1427	912.0330-00	Filter	CG850
1428	912.0337-00	Filter element	CG850
1429	912.0331-00	Clogging indicator	CG850
1430	984.1613-00	Temperature transmitter	CG850
1431	984.1503-00	Temperature transmitter	CG850
1432	984.1614-00	Temperature transmitter	CG850
1433	984.1615-00	Flow transmitter	CG850
1434	967.0186-00	Proximity switch	CG850
1435	910.0172-00	Cooler	CG850
1436	902.1109-00	Control valve	CG850
1437	902.1110-00	Actuator	CG850
1438	912.0332-00	Filter	CG850
1439	902.1126-00	Check valve	CG850
1440	910.0174-00	Air-oil cooler	CG850

1441	972.1259-00	Motor	CG850
1442	902.1126-00	Check valve	CG850
1443	454.4735-001	Hose	CG850
1444	454.4809-001	Hose	CG850
1445	912.0322-00	Air breather	CG850
1446	454.4796-001	Hose	CG850
1447	900.1538-00	Elbow adapter	CG850
1448	873.0382-00	Seal	CG850
1449	900.2243-00	Adapter hexagon socket	CG850
1450	873.0384-00	Seal	CG850
1451	900.2519-00	Adapter	CG850
1452	964.2645-00	Connector	CG850
1453	984.1645-00	Ultrasonic sensor	CG850